

**ANNEX 5**

**RESOLUTION MSC.460(101)  
(adopted on 14 June 2019)**

**AMENDMENTS TO THE INTERNATIONAL CODE FOR  
THE CONSTRUCTION AND EQUIPMENT OF SHIPS CARRYING DANGEROUS  
CHEMICALS IN BULK (IBC CODE)**

THE MARITIME SAFETY COMMITTEE,

RECALLING Article 28(b) of the Convention on the International Maritime Organization concerning the functions of the Committee,

RECALLING ALSO resolution MSC.4(48), by which it adopted the International Code for the Construction and Equipment of Ships Carrying Dangerous Chemicals in Bulk ("the IBC Code"), which has become mandatory under chapter VII of the International Convention for the Safety of Life at Sea (SOLAS), 1974 ("the Convention"),

RECALLING FURTHER article VIII(b) and regulation VII/8.1 of the Convention concerning the procedure for amending the IBC Code,

HAVING CONSIDERED, at its 101st session, amendments to the IBC Code proposed and circulated in accordance with article VIII(b)(i) of the Convention,

1 ADOPTS, in accordance with article VIII(b)(iv) of the Convention, amendments to the IBC Code, the text of which is set out in the annex to the present resolution;

2 DETERMINES, in accordance with article VIII(b)(vi)(2)(bb) of the Convention, that the amendments shall be deemed to have been accepted on 1 July 2020 unless, prior to that date, more than one third of the Contracting Governments to the Convention or Contracting Governments, the combined merchant fleets of which constitute not less than 50% of the gross tonnage of the world's merchant fleet, have notified their objections to the amendments;

3 INVITES Contracting Governments to note that, in accordance with article VIII(b)(vii)(2) of the Convention, the amendments shall enter into force on 1 January 2021 upon their acceptance in accordance with paragraph 2 above;

4 REQUESTS the Secretary-General, in conformity with article VIII(b)(v) of the Convention, to transmit certified copies of the present resolution and the text of the amendments contained in the annex to all Contracting Governments to the Convention;

5 REQUESTS ALSO the Secretary-General to transmit copies of this resolution and its annex to Members of the Organization which are not Contracting Governments to the Convention.

## ANNEX

### AMENDMENTS TO THE INTERNATIONAL CODE FOR THE CONSTRUCTION AND EQUIPMENT OF SHIPS CARRYING DANGEROUS CHEMICALS IN BULK (IBC CODE)

#### Chapter 1

##### General

- 1 The existing section 1.3 is replaced by the following:

#### "1.3 Definitions

The following definitions apply unless expressly provided otherwise. (Additional definitions are given in individual chapters).

- 1.3.1 *Accommodation spaces* are those spaces used for public spaces, corridors, lavatories, cabins, offices, hospitals, cinemas, games and hobbies rooms, barber shops, pantries containing no cooking appliances and similar spaces. *Public spaces* are those portions of the accommodation spaces which are used for halls, dining rooms, lounges and similar permanently enclosed spaces.
- 1.3.2 *Administration* means the Government of the State whose flag the ship is entitled to fly. For *Administration (Port)* see *Port Administration*.
- 1.3.3 *Anniversary date* means the day and the month of each year which will correspond to the date of expiry of the International Certificate of Fitness for the Carriage of Dangerous Chemicals in Bulk.
- 1.3.4 *Boiling point* is the temperature at which a product exhibits a vapour pressure equal to the atmospheric pressure.
- 1.3.5 *Breadth (B)* means the maximum breadth of the ship, measured amidships to the moulded line of the frame in a ship with a metal shell and to the outer surface of the hull in a ship with a shell of any other material. The breadth (*B*) shall be measured in metres.
- 1.3.6 *Cargo area* is that part of the ship that contains cargo tanks, slop tanks, cargo pump-rooms including pump-rooms, cofferdams, ballast or void spaces adjacent to cargo tanks or slop tanks and also deck areas throughout the entire length and breadth of the part of the ship over the above-mentioned spaces. Where independent tanks are installed in hold spaces, cofferdams, ballast or void spaces at the after end of the aftermost hold space or at the forward end of the forward-most hold space are excluded from the cargo area.
- 1.3.7 *Cargo pump-room* is a space containing pumps and their accessories for the handling of the products covered by the Code.

- 1.3.8 *Cargo service spaces* are spaces within the cargo area used for workshops, lockers and store-rooms of more than 2 m<sup>2</sup> in area, used for cargo-handling equipment.
- 1.3.9 *Cargo tank* is the envelope designed to contain the cargo.
- 1.3.10 *Chemical tanker* is a cargo ship constructed or adapted and used for the carriage in bulk of any liquid product listed in chapter 17.
- 1.3.11 *Cofferdam* is the isolating space between two adjacent steel bulkheads or decks. This space may be a void space or a ballast space.
- 1.3.12 *Control stations* are those spaces in which ship's radio or main navigating equipment or the emergency source of power is located or where the fire-recording or fire-control equipment is centralized. This does not include special fire-control equipment which can be most practically located in the cargo area.
- 1.3.13 *Dangerous chemicals* means any liquid chemicals designated as presenting a safety hazard, based on the safety criteria for assigning products to chapter 17.
- 1.3.14 *Density* is the ratio of the mass to the volume of a product, expressed in terms of kilograms per cubic metre. This applies to liquids, gases and vapours.
- 1.3.15 *Explosive/flammability limits/range* are the conditions defining the state of fuel-oxidant mixture at which application of an adequately strong external ignition source is only just capable of producing flammability in a given test apparatus.
- 1.3.16 *Flashpoint* is the temperature in degrees Celsius at which a product will give off enough flammable vapour to be ignited. Values given in the Code are those for a "closed-cup test" determined by an approved flashpoint apparatus.
- 1.3.17 *Gas-freeing* means the process where a portable or fixed ventilation system is used to introduce fresh air into a tank in order to reduce the concentration of hazardous gases or vapours to a level safe for tank entry.
- 1.3.18 *Hold space* is the space enclosed by the ship's structure in which an independent cargo tank is situated.
- 1.3.19 *Independent* means that a piping or venting system, for example, is in no way connected to another system and that there are no provisions available for the potential connection to other systems.
- 1.3.20 *Length (L)* means 96% of the total length on a waterline at 85% of the least moulded depth measured from the top of the keel, or the length from the foreside of the stem to the axis of the rudder stock on that waterline, if that be greater. In ships designed with a rake of keel, the waterline on which this length is measured shall be parallel to the designed waterline. The length (L) shall be measured in metres.

- 1.3.21 *Machinery spaces of category A* are those spaces and trunks to such spaces which contain:
- .1 internal-combustion machinery used for main propulsion; or
  - .2 internal-combustion machinery used for purposes other than main propulsion where such machinery has in the aggregate a total power output of not less than 375 kW; or
  - .3 any oil-fired boiler or oil fuel unit or any oil-fired equipment other than boilers, such as inert gas generators, incinerators, etc.
- 1.3.22 *Machinery spaces* are all machinery spaces of category A and all other spaces containing propelling machinery, boilers, oil fuel units, steam and internal-combustion engines, generators and major electrical machinery, oil filling station, refrigerating, stabilizing, ventilation and air-conditioning machinery, and similar spaces, and trunks to such spaces.
- 1.3.23 *MARPOL* means the International Convention for the Prevention of Pollution from Ships, 1973, as modified by the Protocol of 1978 relating thereto and by the Protocol of 1997, as amended.
- 1.3.24 *Noxious Liquid Substance* means any substance indicated in the Pollution Category column of chapters 17 or 18 of the International Bulk Chemical Code, or the current MEPC.2/Circular or provisionally assessed under the provisions of regulation 6.3 of MARPOL Annex II as falling into categories X, Y or Z.
- 1.3.25 *Oil fuel unit* is the equipment used for the preparation of oil fuel for delivery to an oil-fired boiler, or equipment used for the preparation for delivery of heated oil to an internal-combustion engine, and includes any oil pressure pumps, filters and heaters dealing with oil at a gauge pressure of more than 0.18 MPa.
- 1.3.26 *Organization* is the International Maritime Organization (IMO).
- 1.3.27 *Permeability* of a space means the ratio of the volume within that space which is assumed to be occupied by water to the total volume of that space.
- 1.3.28 *Port Administration* means the appropriate authority of the country in the port of which the ship is loading or unloading.
- 1.3.29 *Products* is the collective term used to cover both Noxious Liquid Substances and Dangerous Chemicals.
- 1.3.30 *Pump-room* is a space, located in the cargo area, containing pumps and their accessories for the handling of ballast and oil fuel.
- 1.3.31 *Purging* means the introduction of inert gas into a tank which is already in an inert condition with the object of further reducing the oxygen content; and/or reducing the existing hydrocarbon or other flammable vapours content to a level below which combustion cannot be supported if air is subsequently introduced into the tank.

- 1.3.32 *Recognized organization* is an organization authorized by an Administration in accordance with MARPOL Annex II regulation 8.2.2 and SOLAS regulation XI-1/1.
- 1.3.33 *Recognized standards* are applicable international or national standards acceptable to the Administration or standards laid down and maintained by an organization which complies with the standards adopted by the Organization and which is recognized by the Administration.
- 1.3.34 *Reference temperature* is the temperature at which the vapour pressure of the cargo corresponds to the set pressure of the pressure-relief valve.
- 1.3.35 *Separate* means that a cargo piping system or cargo vent system, for example, is not connected to another cargo piping or cargo vent system.
- 1.3.36 *Service spaces* are those spaces used for galleys, pantries containing cooking appliances, lockers, mail and specie rooms, store-rooms, workshops other than those forming part of the machinery spaces and similar spaces and trunks to such spaces.
- 1.3.37 *SOLAS* means the International Convention for the Safety of Life at Sea, 1974, as amended.
- 1.3.38 *Vapour pressure* is the equilibrium pressure of the saturated vapour above a liquid expressed in Pascals (Pa) at a specified temperature.
- 1.3.39 *Void space* is an enclosed space in the cargo area external to a cargo tank, other than a hold space, ballast space, oil fuel tank, cargo pump-room, pump-room, or any space in normal use by personnel."

2 Paragraph 1.5.1.2 is replaced by the following:

"1.5.1.2 The recognized organization referred to in 1.3.32 shall comply with the provisions of SOLAS and MARPOL and with parts 1 and 2 of the Code for Recognized Organizations (RO Code), as adopted by resolutions MSC.349(92) and MEPC.237(65), as may be amended."

## Chapter 15

### Special requirements

3 In paragraph 15.8.25.1, the reference to paragraph "1.3.18" in the second set of brackets is replaced by "1.3.19".

4 Section 15.15 is replaced by the following:

#### **"15.15 Hydrogen sulphide (H<sub>2</sub>S) detection equipment for bulk liquids**

Hydrogen sulphide (H<sub>2</sub>S) detection equipment shall be provided on board ships carrying bulk liquids prone to H<sub>2</sub>S formation. It should be noted that scavengers and biocides, when used, may not be 100% effective in controlling the formation of H<sub>2</sub>S. Toxic vapour detection instruments complying with the requirement in 13.2.1 of the Code for testing for H<sub>2</sub>S may be used to satisfy this requirement."

## Chapter 16

### Operational requirements

5 Paragraph 16.2.7 is replaced by the following:

"16.2.7 Where *column o* in the table of chapter 17 refers to this paragraph, the cargo is subject to the prewash requirements in regulation 13.7.1.4 of Annex II of MARPOL."

6 The complete text of chapters 17, 18 and 19 is replaced by the following:

## "Chapter 17

### Summary of minimum requirements

17.1 Mixtures of noxious liquid substances presenting pollution hazards only, and which are assessed or provisionally assessed under regulation 6.3 of MARPOL Annex II, may be carried under the requirements of the Code applicable to the appropriate position of the entry in this chapter for Noxious Liquid Substances, not otherwise specified (n.o.s.).

#### 17.2 EXPLANATORY NOTES

Product name ( <i>column a</i> )	The product name shall be used in the shipping document for any cargo offered for bulk shipments. Any additional name may be included in brackets after the product name. In some cases, the product names are not identical with the names given in previous issues of the Code.
UN Number ( <i>column b</i> )	Deleted
Pollution Category ( <i>column c</i> )	The letter X, Y, Z means the Pollution Category assigned to each product under MARPOL Annex II.
Hazards ( <i>column d</i> )	"S" means that the product is included in the Code because of its safety hazards; "P" means that the product is included in the Code because of its pollution hazards; and "S/P" means that the product is included in the Code because of both its safety and pollution hazards.
Ship Type ( <i>column e</i> )	1: Ship Type 1 (2.1.2.1) 2: Ship Type 2 (2.1.2.2) 3: Ship Type 3 (2.1.2.3)
Tank type ( <i>column f</i> )	1: independent tank (4.1.1) 2: integral tank (4.1.2) G: gravity tank (4.1.3) P: pressure tank (4.1.4)
Tank vents ( <i>column g</i> )	Cont.: controlled venting Open: open venting
Tank environmental control ( <i>column h</i> )	Inert: inerting (9.1.2.1) Pad: liquid or gas padding (9.1.2.2) Dry: drying (9.1.2.3) Vent: natural or forced ventilation (9.1.2.4) No: no special requirements under this Code (inerting may be required under SOLAS)

Electrical equipment (column i)	Temperature classes (i')	T1 to T6 - indicates no requirements blank no information
	Apparatus group (i'')	IIA, IIB or IIC: - indicates no requirements blank no information
	Flash point (i''')	Yes: flashpoint exceeding 60°C (10.1.6) No: flashpoint not exceeding 60°C (10.1.6) NF: non-flammable product (10.1.6)
Gauging (column j)	O: open gauging (13.1.1.1) R: restricted gauging (13.1.1.2) C: closed gauging (13.1.1.3)	
Vapour detection (column k)	F: flammable vapours T: toxic vapours	
Fire protection (column l)	No: indicates no special requirements under this Code A: alcohol-resistant foam or multi-purpose foam B: regular foam; encompasses all foams that are not of an alcohol-resistant type, including fluoro-protein and aqueous-film-forming foam (AFFF) C: water-spray D: dry chemical No: no special requirements under this Code	
Materials of construction (column m)	Deleted	
Emergency equipment (column n)	Yes: see 14.3.1 No: no special requirements under this Code	
Specific and operational requirements (column o)	When specific reference is made to chapters 15 and/or 16, these requirements shall be additional to the requirements in any other column.	

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Acetic acid	Z	S/P	3	2G	Cont	No	T1	IIA	No	C	F	AC	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.17, 15.19, 16.2.9
Acetic anhydride	Z	S/P	2	2G	Cont	No	T2	IIA	No	R	FT	AC	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12.3, 15.12.4, 15.19.6
Acetochlor	X	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.6, 16.2.9
Acetone cyanohydrin	Y	S/P	1	1G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.13, 15.17, 15.19, 16.6.1, 16.6.2, 16.6.3
Acetonitrile	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Acetonitrile (Low purity grade)	Y	S/P	3	2G	Cont	No	T1	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Acid oil mixture from soya bean, corn (maize) and sunflower oil refining	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Acrylamide solution (50% or less)	Y	S/P	3	2G	Cont	No			NF	C	T	No	No	15.12, 15.13, 15.17, 15.19, 16.2.9, 16.6.1
Acrylic acid	Y	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	AC	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12.3, 15.12.4, 15.13, 15.17, 15.19, 16.2.9, 16.6.1
Acrylic acid/ethenesulphonic acid copolymer with phosphonate groups, sodium salt solution	Z	P	3	2G	Open	No			Yes	O	No	ABC	No	
Acrylonitrile	Y	S/P	2	2G	Cont	No	T1	IIB	No	C	FT	AC	Yes	15.12, 15.13, 15.17, 15.19
Acrylonitrile-Styrene copolymer dispersion in polyether polyol	Y	P	3	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Adiponitrile	Z	S/P	2	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Alachlor technical (90% or more)	X	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6, 16.2.9
Alcohol (C9-C11) poly (2.5-9) ethoxylate	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Alcohol (C6-C17) (secondary) poly(3-6) ethoxylates	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Alcohol (C6-C17) (secondary) poly(7-12) ethoxylates	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Alcohol (C10-C18) poly(7) ethoxylate	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Alcohol (C12-C16) poly(1-6) ethoxylates	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Alcohol (C12-C16) poly(20+) ethoxylates	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Alcohol (C12-C16) poly(7-19) ethoxylates	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Alcohols (C13+)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Alcohols (C12+), primary, linear	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Alcohols (C8-C11), primary, linear and essentially linear	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Alcohols (C12-C13), primary, linear and essentially linear	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Alcohols (C14-C18), primary, linear and essentially linear	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Alkanes (C6-C9)	X	S/P	2	2G	Cont	No	T3	IIA	No	C	FT	AC	No	15.12, 15.17, 15.19.6
Iso- and cyclo-alkanes (C10-C11)	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Iso- and cyclo-alkanes (C12+)	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
n-Alkanes (C9-C11)	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
n-Alkanes (C10 – C20)	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Alkaryl polyethers (C9-C20)	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.6
Alkenoic acid, polyhydroxy ester borated	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Alkenyl (C11+) amide	X	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Alkenyl (C16-C20) succinic anhydride	Z	S/P	3	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Alkyl acrylate/vinylpyridine copolymer in toluene	Y	S/P	2	2G	Cont	No	T1	IIB	No	C	FT	ABC	No	15.12, 15.17, 15.19.6, 16.2.9
Alkylaryl phosphate mixtures (more than 40% Diphenyl tolyl phosphate, less than 0.02% ortho-isomers)	X	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6
Alkylated (C4-C9) hindered phenols	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Alkylbenzene, alkylindane, alkylindene mixture (each C12-C17)	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Alkyl benzene distillation bottoms	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Alkylbenzene mixtures (containing at least 50% of toluene)	Y	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19.6
Alkylbenzenes mixtures (containing naphthalene)	X	S/P	2	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19.6
Alkyl (C3-C4) benzenes	Y	S/P	2	2G	Cont	No	T1	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Alkyl (C5-C8) benzenes	X	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Alkyl (C9+) benzenes	Y	S/P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6
Alkyl (C11-C17) benzene sulphonic acid	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Alkylbenzene sulphonic acid, sodium salt solution	Y	S/P	2	2G	Cont	No	-	-	NF	C	T	No	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Alkyl/cyclo (C4-C5) alcohols	Y	S/P	3	2G	Cont	No	T2	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Alkyl (C10-C15, C12 rich) phenol poly (4-12) ethoxylate	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Alkyl (C12+) dimethylamine	X	S/P	1	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Alkyl dithiocarbamate (C19-C35)	Y	P	3	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Alkyldithiothiadiazole (C6-C24)	Y	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6, 16.2.6
Alkyl ester copolymer (C4-C20)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Alkyl (C7-C9) nitrates	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 15.20, 16.6.1, 16.6.2, 16.6.3
Alkyl (C8-C10)/(C12-C14):(40% or less/60% or more) polyglucoside solution (55% or less)	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Alkyl (C8-C10)/(C12-C14):(60% or more/40% or less) polyglucoside solution(55% or less)	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Alkyl (C7-C11) phenol poly(4-12) ethoxylate	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Alkyl (C8-C40) phenol sulphide	Z	S/P	3	2G	Open	No			Yes	O	No	ABC	No	
Alkyl (C8-C9) phenylamine in aromatic solvents	Y	S/P	2	2G	Cont	No	T1	IIB	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Alkyl (C9-C15) phenyl propoxylate	Z	S/P	3	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Alkyl (C8-C10) polyglucoside solution (65% or less)	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Alkyl (C8-C10)/(C12-C14):(50%/50%) polyglucoside solution (55% or less)	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Alkyl (C12-C14) polyglucoside solution (55% or less)	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Alkyl (C12-C16) propoxyamine ethoxylate	X	S/P	2	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.6
Alkyl (C10-C20, saturated and unsaturated) phosphite	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Alkyl sulphonic acid ester of phenol	Y	P	3	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Alkyl (C18+) toluenes	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.9
Alkyl (C18-C28) toluenesulphonic acid	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12, 15.17, 15.19, 16.2.6, 16.2.9
Alkyl (C18-C28) toluenesulphonic acid, calcium salts, borated	Y	S/P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Alkyl (C18-C28) toluenesulphonic acid, calcium salts, low overbase	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Alkyl (C18-C28) toluenesulphonic acid, calcium salts, high overbase	Y	S/P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Allyl alcohol	Y	S/P	2	2G	Cont	No	T2	IIB	No	C	FT	AC	Yes	15.12, 15.17, 15.19
Allyl chloride	Y	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	AC	No	15.12, 15.17, 15.19
Aluminium chloride/Hydrogen chloride solution	Y	S/P	2	2G	Cont	No	-	-	NF	C	T	No	Yes	15.11, 15.12, 15.17, 15.19
Aluminium hydroxide, sodium hydroxide, sodium carbonate solution (40% or less)	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19
Aluminium sulphate solution	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19
2-(2-Aminoethoxy) ethanol	Z	S/P	3	2G	Cont	No			Yes	C	T	AD	Yes	15.12, 15.17, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Aminoethyldiethanolamine/Aminoethylethanolamine solution	Z	S/P	3	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Aminoethyl ethanolamine	Z	S/P	3	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19
N-Aminoethylpiperazine	Z	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
2-Amino-2-methyl-1-propanol	Z	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Ammonia aqueous (28% or less)	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19
Ammonium chloride solution (less than 25%) (*)	Z	S/P	3	2G	Open	No	-	-	NF	O	No	No	No	
Ammonium hydrogen phosphate solution	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Ammonium lignosulphonate solutions	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	16.2.9
Ammonium nitrate solution (93% or less) (*)	Z	S/P	2	1G	Cont	No			NF	R	T	No	No	15.2, 15.11.4, 15.11.6, 15.12.3, 15.12.4, 15.18, 15.19.6, 16.2.9
Ammonium polyphosphate solution	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	
Ammonium sulphate solution	Z	P	3	2G	Open	No			NF	O	No	No	No	
Ammonium sulphide solution (45% or less) (*)	Y	S/P	2	2G	Cont	Inert	T4	IIB	No	C	FT	AC	No	15.12, 15.17, 15.19, 16.6.1, 16.6.2, 16.6.3
Ammonium thiosulphate solution (60% or less)	Z	S/P	3	2G	Open	No			NF	O	No	No	No	

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Amyl acetate (all isomers)	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.19.6
n-Amyl alcohol	Z	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	ABC	Yes	15.12, 15.17, 15.19
Amyl alcohol, primary	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
sec-Amyl alcohol	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
tert-Amyl alcohol	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
tert-Amyl ethyl ether	Z	P	3	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
tert-Amyl methyl ether	X	S/P	2	2G	Cont	No	T2	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Aniline	Y	S/P	2	2G	Cont	No	T1	IIA	Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Aryl polyolefins (C11-C50)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Aviation alkylates (C8 paraffins and iso-paraffins BPT 95 - 120°C)	X	S/P	2	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
Barium long chain (C11-C50) alkaryl sulphonate	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19, 16.2.6, 16.2.9
Benzene and mixtures having 10% benzene or more (i)	Y	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19.6, 16.2.9
Benzene sulphonyl chloride	Y	S/P	3	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.9
Benzenetricarboxylic acid, trioctyl ester	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Benzyl acetate	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Benzyl alcohol	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Benzyl chloride	Y	S/P	2	2G	Cont	No	T1	IIA	No	C	FT	ABC	Yes	15.12, 15.13, 15.17, 15.19
Bio-fuel blends of Diesel/gas oil and FAME (>25% but <99% by volume)	X	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	No	15.12, 15.17, 15.19.6
Bio-fuel blends of Diesel/gas oil and vegetable oil (>25% but <99% by volume)	X	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	No	15.12, 15.17, 15.19.6
Bio-fuel blends of Gasoline and Ethyl alcohol (>25% but <99% by volume)	X	S/P	2	2G	Cont	No	T3	IIA	No	R	FT	AC	No	15.12, 15.17, 15.19.6
Bis (2-ethylhexyl) terephthalate	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Brake fluid base mix: Poly(2-8)alkylene (C2-C3) glycols/Polyalkylene (C2-C10) glycols monoalkyl (C1-C4) ethers and their borate esters	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	
Bromochloromethane	Z	P	3	2G	Open	No			NF	O	No	No	No	
Butene oligomer	X	P	2	2G	Cont	No	T4	IIB	No	R	F	ABC	No	15.19.6
2-Butoxyethanol (58%)/Hyperbranched polyesteramide (42%) (mixture)	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.12.3, 15.12.4, 15.19
Butyl acetate (all isomers)	Y	P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
Butyl acrylate (all isomers)	Y	S/P	3	2G	Cont	No	T2	IIB	No	R	F	ABC	No	15.13, 15.19.6, 16.6.1, 16.6.2
tert-Butyl alcohol	Z	P	3	2G	Cont	No	T1	IIA	No	R	F	AC	No	15.19.6
Butylamine (all isomers)	Y	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19
Butylbenzene (all isomers)	X	S/P	2	2G	Cont	No	T2	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Butyl benzyl phthalate	X	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Butyl butyrate (all isomers)	Y	S/P	3	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6
Butyl/Decyl/Cetyl/Eicosyl methacrylate mixture	Y	S/P	2	2G	Open	No	T3	IIA	No	R	F	ABC	No	15.13, 15.19.6, 16.6.1, 16.6.2
Butylene glycol	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	
1,2-Butylene oxide	Y	S/P	3	2G	Cont	Inert	T2	IIB	No	C	FT	AC	No	15.8.1 to 15.8.7, 15.8.12, 15.8.13, 15.8.16, 15.8.17, 15.8.18, 15.8.19, 15.8.21, 15.8.25, 15.8.27, 15.8.29, 15.12, 15.17, 15.19.6
n-Butyl ether	Y	S/P	3	2G	Cont	Inert	T4	IIB	No	R	F	AC	No	15.4.6, 15.19
Butyl methacrylate	Z	S/P	3	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.13, 15.19.6, 16.6.1, 16.6.2
n-Butyl propionate	Y	P	3	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.19.6
Butyraldehyde (all isomers)	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Butyric acid	Y	S/P	3	2G	Cont	No			Yes	O	No	AC	No	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.19.6
gamma-Butyrolactone	Y	S/P	3	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19.6
Calcium alkaryl sulphonate (C11-C50)	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	
Calcium alkyl (C10-C28) salicylate	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Calcium hydroxide slurry	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Calcium hypochlorite solution (15% or less)	Y	S/P	2	2G	Cont	No			NF	R	T	No	No	15.12.3, 15.12.4, 15.19.6
Calcium hypochlorite solution (more than 15%)	X	S/P	1	2G	Cont	No			NF	R	T	No	No	15.12.3, 15.12.4, 15.19
Calcium lignosulphonate solutions	Z	P	3	2G	Open	No	-	-	NF	O	No	No	No	16.2.9
Calcium long-chain alkyl (C5-C10) phenate	Y	P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6
Calcium long-chain alkyl (C11-C40) phenate	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Calcium long-chain alkyl phenate sulphide (C8-C40)	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Calcium long-chain alkyl salicylate (C13+)	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Calcium long-chain alkyl (C18-C28) salicylate	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Calcium nitrate/Magnesium nitrate/Potassium chloride solution	Z	S/P	3	2G	Open	No	-	-	NF	O	No	No	No	16.2.9
Calcium nitrate solution (50% or less)	Z	S	3	2G	Open	No	-	-	NF	O	No	No	No	16.2.9
Camelina oil	Y	S/P	2(k)	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7
epsilon-Caprolactam (molten or aqueous solutions)	Z	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Carbolic oil	Y	S/P	2	2G	Cont	No			Yes	C	FT	ABC	Yes	15.12, 15.17, 15.19, 16.2.9
Carbon disulphide	Y	S/P	1	1G	Cont	Pad+inert	T6	IIC	No	C	FT	C	Yes	15.3, 15.12, 15.17, 15.18, 15.19
Carbon tetrachloride	Y	S/P	2	2G	Cont	No			NF	C	T	No	No	15.12, 15.17, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Cashew nut shell oil (untreated)	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.7, 16.2.9
Castor oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Cesium formate solution (*)	Y	S/P	3	2G	Open	No	-	-	NF	O	No	No	No	15.19.6
Cetyl/Eicosyl methacrylate mixture	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.13, 15.19.6, 16.2.9, 16.6.1, 16.6.2
Chlorinated paraffins (C10-C13)	X	S/P	1	2G	Cont	No			NF	C	T	No	No	15.12, 15.17, 15.19, 16.2.6
Chlorinated paraffins (C14-C17) (with 50% chlorine or more, and less than 1% C13 or shorter chains)	X	S/P	1	2G	Cont	No	-	-	Yes	C	T	AC	No	15.12, 15.17, 15.19
Chloroacetic acid (80% or less)	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12, 15.17, 15.18, 15.19, 16.2.9
Chlorobenzene	Y	S/P	2	2G	Cont	No	T1	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Chloroform	Y	S/P	3	2G	Cont	No			NF	C	T	No	No	15.12, 15.17, 15.19.6
Chlorohydrins (crude)	Y	S/P	2	2G	Cont	No	T3	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19
4-Chloro-2-methylphenoxyacetic acid, dimethylamine salt solution	Y	S/P	2	2G	Cont	No			NF	R	T	No	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
o-Chloronitrobenzene	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	No	15.12.3, 15.12.4, 15.19, 16.2.6, 16.2.9
1-(4-Chlorophenyl)-4,4- dimethyl-pentan-3-one	Y	S/P	2	2G	Open	No			Yes	O	No	ABD	No	15.19.6, 16.2.6, 16.2.9
2- or 3-Chloropropionic acid	Z	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12.3, 15.12.4, 15.19, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Chlorosulphonic acid	Y	S/P	1	2G	Cont	No			NF	C	T	No	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.5, 15.11.6, 15.11.7, 15.11.8, 15.12, 15.16.2, 15.17, 15.18, 15.19
m-Chlorotoluene	Y	S/P	2	2G	Cont	No	T4	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19
o-Chlorotoluene	Y	P	2	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6
p-Chlorotoluene	Y	P	2	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6, 16.2.9
Chlorotoluenes (mixed isomers)	Y	P	2	2G	Cont	No	T4	IIA	No	R	F	ABC	No	15.19.6
Choline chloride solutions	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Citric acid (70% or less)	Z	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Coal tar	X	S/P	2	2G	Cont	No	T2	IIA	Yes	C	T	BD	No	15.12, 15.17, 15.19.6, 16.2.6, 16.2.9
Coal tar naphtha solvent	Y	S/P	2	2G	Cont	No	T3	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19.6, 16.2.9
Coal tar pitch (molten) (*)	X	S/P	2	1G	Cont	No	T2	IIA	Yes	C	T	ABCD	No	15.12, 15.17, 15.19.6, 16.2.6, 16.2.9
Cocoa butter	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Coconut oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Coconut oil fatty acid	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Coconut oil fatty acid methyl ester	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6
Copper salt of long chain (C17+) alkanic acid	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Corn Oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Cotton seed oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Creosote (coal tar)	X	S/P	1	2G	Cont	No	T2	IIA	Yes	C	T	AD	No	15.12, 15.17, 15.19.6, 16.2.6, 16.2.9
Cresols (all isomers)	Y	S/P	1	2G	Cont	No	T1	IIA	Yes	C	T	ABC	Yes	15.12, 15.18, 15.19, 16.2.9
Cresol/Phenol/Xylenol mixture	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Cresylic acid, dephenolized	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Cresylic acid, sodium salt solution	Y	S/P	2	2G	Cont	No	T4	IIB	No	C	FT	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Crotonaldehyde	X	S/P	1	1G	Cont	No	T3	IIB	No	C	FT	AC	Yes	15.12, 15.17, 15.18, 15.19
1,5,9-Cyclododecatriene	X	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.13, 15.19.6, 16.6.1, 16.6.2
Cycloheptane	X	S/P	2	2G	Cont	No	T4	IIA	No	R	F	AC	No	15.19.6
Cyclohexane	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6, 16.2.9
Cyclohexane-1,2-dicarboxylic acid, diisononyl ester	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Cyclohexane oxidation products, sodium salts solution	Z	P	3	2G	Open	No			NF	O	No	No	No	
Cyclohexanol	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Cyclohexanone	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
Cyclohexanone, Cyclohexanol mixture	Y	S/P	3	2G	Cont	No			Yes	R	F	AC	No	15.19.6
Cyclohexyl acetate	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Cyclohexylamine	Y	S/P	3	2G	Cont	No	T3	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
1,3-Cyclopentadiene dimer (molten)	Y	S/P	2	2G	Cont	No	T1	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19, 16.2.6, 16.2.9
Cyclopentane	Y	P	2	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
Cyclopentene	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
p-Cymene	Y	S/P	2	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
Decahydronaphthalene	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Decanoic acid	X	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Decene	X	P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Decyl acrylate	X	S/P	1	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.13, 15.19, 16.6.1, 16.6.2
Decyl alcohol (all isomers)	Y	P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9(e)
Decyl/Dodecyl/Tetradecyl alcohol mixture	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Decyloxytetrahydrothiophene dioxide	X	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9
Diacetone alcohol	Z	S/P	3	2G	Cont	No	T1	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Dialkyl (C8-C9) diphenylamines	Z	P	3	2G	Open	No			Yes	O	No	ABC	No	
Dialkyl (C7-C13) phthalates	X	S/P	2	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19.6, 16.2.6
Dialkyl (C9-C10) phthalates	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Dialkyl thiophosphates sodium salts solution	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
2,6-Diaminohexanoic acid phosphonate mixed salts solution	Z	S/P	3	2G	Cont	No			NF	R	No	No	No	15.11, 15.17, 15.19.6
Dibromomethane	Y	S/P	2	2G	Open	No			NF	O	No	No	No	15.19.6
Dibutylamine	Y	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	ABC	Yes	15.12, 15.17, 15.19
Dibutyl hydrogen phosphonate	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
2,6-Di-tert-butylphenol	X	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.9
Dibutyl phthalate	X	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6
Dibutyl terephthalate	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.9
Dichlorobenzene (all isomers)	X	S/P	2	2G	Cont	No	T1	IIA	Yes	C	T	ABD	No	15.12, 15.17, 15.19.6
3,4-Dichloro-1-butene	Y	S/P	2	2G	Cont	No	T1	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
1,1-Dichloroethane	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
Dichloroethyl ether	Y	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.18, 15.19
1,6-Dichlorohexane	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6
2,2'-Dichloroisopropyl ether	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19
Dichloromethane	Y	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19.6
2,4-Dichlorophenol	Y	S/P	2	2G	Cont	Dry			Yes	C	T	AD	Yes	15.12, 15.16.2, 15.17, 15.19, 16.2.6, 16.2.9
2,4-Dichlorophenoxyacetic acid, diethanolamine salt solution	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19, 16.2.9
2,4-Dichlorophenoxyacetic acid, dimethylamine salt solution (70% or less)	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
2,4-Dichlorophenoxyacetic acid, triisopropanolamine salt solution	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
1,1-Dichloropropane	Y	S/P	2	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6
1,2-Dichloropropane	Y	S/P	3	2G	Cont	No	T1	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
1,3-Dichloropropene	X	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	ABC	Yes	15.12, 15.17, 15.19
Dichloropropene/Dichloropropane mixtures	X	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	ABD	No	15.12, 15.17, 15.19
2,2-Dichloropropionic acid	Y	S/P	2	2G	Cont	Dry			Yes	C	T	AD	Yes	15.11.2, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12, 15.16.2, 15.17, 15.19, 16.2.9
Dicyclopentadiene, Resin Grade, 81-89%	Y	S/P	2	2G	Cont	Inert	T2	IIB	No	C	FT	ABC	Yes	15.12, 15.13, 15.17, 15.19
Diethanolamine	Y	S/P	3	2G	Cont	No	T1	IIA	Yes	C	T	AC	No	15.12, 15.17, 15.19.6, 16.2.6, 16.2.9
Diethylamine	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19
Diethylaminoethanol	Y	S/P	2	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
2,6-Diethylaniline	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Diethylbenzene	Y	S/P	2	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Diethylene glycol	Z	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Diethylene glycol dibutyl ether	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	AC	No	
Diethylene glycol diethyl ether	Z	S/P	3	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Diethylene glycol phthalate	Y	S/P	3	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Diethylenetriamine	Y	S/P	3	2G	Cont	No	-	-	Yes	C	T	ABC	No	15.12, 15.17, 15.19
Diethylenetriaminepentaacetic acid, pentasodium salt solution	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	
Diethyl ether (*)	Z	S/P	2	1G	Cont	Inert	T4	IIB	No	R	F	AC	No	15.4, 15.14, 15.19
Di-(2-ethylhexyl) adipate	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19.6
Di-(2-ethylhexyl) phosphoric acid	Y	S/P	2	2G	Cont	No			Yes	R	T	AD	No	15.12.3, 15.12.4, 15.19.6
Diethyl phthalate	Y	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6
Diethyl sulphate	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Diglycidyl ether of bisphenol A	X	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Diglycidyl ether of bisphenol F	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6, 16.2.6
Diheptyl phthalate	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
Di-n-hexyl adipate	X	S/P	1	2G	Open	No			Yes	O	No	AC	No	15.19
Dihexyl phthalate	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19.6
Diisobutylamine	Y	S/P	2	2G	Cont	No	T4	IIB	No	C	FT	ABC	No	15.12.3, 15.12.4, 15.19
Diisobutylene	Y	P	2	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
Diisobutyl ketone	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Diisobutyl phthalate	X	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6
Diisononyl adipate	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6
Diisooctyl phthalate	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Diisopropanolamine	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	16.2.9
Diisopropylamine	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.17, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Diisopropylbenzene (all isomers)	X	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Diisopropyl-naphthalene	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6
N,N-Dimethylacetamide	Z	S/P	3	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
N,N-Dimethylacetamide solution (40% or less)	Z	S/P	3	2G	Cont	No			NF	R	T	No	No	15.12.3, 15.12.4, 15.19.6
Dimethyl adipate	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Dimethylamine solution (45% or less)	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19
Dimethylamine solution (greater than 45% but not greater than 55%)	Y	S/P	3	2G	Cont	No	T2	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19
Dimethylamine solution (greater than 55% but not greater than 65%)	Y	S/P	3	2G	Cont	No	T2	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.14, 15.19
N,N-Dimethylcyclohexylamine	Y	S/P	2	2G	Cont	No	T3	IIB	No	C	FT	AC	Yes	15.12, 15.17, 15.19
Dimethyl disulphide	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
N,N-Dimethyldodecylamine	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Dimethylethanolamine	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Dimethylformamide	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	AC	No	15.12, 15.17, 15.19.6
Dimethyl glutarate	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Dimethyl hydrogen phosphite	Y	S/P	3	2G	Cont	No	T4	IIB	No	R	F	AC	No	15.19.6
Dimethyl octanoic acid	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Dimethyl phthalate	Y	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9
Dimethylpolysiloxane	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
2,2-Dimethylpropane-1,3-diol (molten or solution)	Z	P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	16.2.9
Dimethyl succinate	Y	P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9
Dinitrotoluene (molten)	X	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19, 15.21, 16.2.6, 16.2.9, 16.6.4
Dinonyl phthalate	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6
Diocetyl phthalate	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
1,4-Dioxane	Y	S/P	3	2G	Cont	No	T2	IIB	No	C	FT	AC	No	15.12, 15.17, 15.19.6, 16.2.9
Dipentene	Y	S/P	2	2G	Cont	No	T3	IIA	No	C	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Diphenyl	X	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Diphenylamine (molten)	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Diphenylamine, reaction product with 2,2,4-Trimethylpentene	Y	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.19, 16.2.6
Diphenylamines, alkylated	Y	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.19, 16.2.6, 16.2.9
Diphenyl/Diphenyl ether mixtures	X	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Diphenyl ether	X	P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9
Diphenyl ether/Diphenyl phenyl ether mixture	X	P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Diphenylmethane diisocyanate	Y	S/P	2	2G	Cont	Dry	-	-	Yes(a)	C	T(a)	AB(b)D	Yes	15.12, 15.16.2, 15.17, 15.19, 16.2.6, 16.2.9
Diphenylol propane-epichlorohydrin resins	X	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Di-n-propylamine	Y	S/P	2	2G	Cont	No	T3	IIB	No	C	FT	AC	Yes	15.12.3, 15.12.4, 15.17, 15.19.6
Dipropylene glycol	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Dithiocarbamate ester (C7-C35)	X	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
Ditridecyl adipate	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Ditridecyl phthalate	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6
Diundecyl phthalate	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Dodecane (all isomers)	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
tert-Dodecanethiol	Y	S/P	3	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
1-Dodecene	Y	S/P	3	2G	Open	No			Yes	O	No	ABC	No	15.19.6
Dodecene (all isomers)	X	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Dodecyl alcohol	Y	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9
n-Dodecyl mercaptan	X	S/P	1	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Dodecylamine/Tetradecylamine mixture	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.9
Dodecylbenzene	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Dodecyl diphenyl ether disulphonate solution	X	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19, 16.2.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Dodecyl hydroxypropyl sulphide	X	P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6
Dodecyl methacrylate	Y	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.13, 15.19.6
Dodecyl/Octadecyl methacrylate mixture	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.13, 15.19.6, 16.2.6, 16.6.1, 16.6.2
Dodecyl/Pentadecyl methacrylate mixture	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.13, 15.19.6, 16.6.1, 16.6.2
Dodecyl phenol	X	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.6
Dodecyl Xylene	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Drilling brines (containing zinc chloride)	X	S/P	2	2G	Open	No			NF	O	No	No	Yes	15.19.6
Drilling brines (containing calcium bromide)	Z	S/P	3	2G	Open	No			NF	O	No	No	No	15.19.6
Epichlorohydrin	Y	S/P	2	2G	Cont	No	T2	IIB	No	C	FT	AC	Yes	15.12, 15.17, 15.19
Ethanolamine	Y	S/P	3	2G	Cont	No	T2	IIA	Yes	C	FT	AC	Yes	15.12, 15.17, 15.19, 16.2.9
2-Ethoxyethyl acetate	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	AC	No	15.12, 15.17, 15.19.6
Ethoxylated long chain (C16+) alkyloxyalkylamine	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.9
Ethoxylated tallow amine (>95%)	X	S/P	2	2G	Cont	Inert	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Ethyl acetate	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.19.6
Ethyl acetoacetate	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	
Ethyl acrylate	Y	S/P	2	2G	Cont	No	T2	IIB	No	C	FT	AC	No	15.12, 15.13, 15.17, 15.19, 16.6.1, 16.6.2
Ethylamine (*)	Y	S/P	2	1G	Cont	No	T2	IIA	No	C	F	AC	No	15.12.3.2, 15.14, 15.19
Ethylamine solutions (72% or less)	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	F	AC	No	15.12.3.2, 15.14, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Ethyl amyl ketone	Y	S/P	2	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Ethylbenzene	Y	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	AC	No	15.12, 15.17, 15.19.6
Ethyl tert-butyl ether	Y	S/P	2	2G	Cont	No	T2	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Ethyl butyrate	Y	S/P	2	2G	Cont	No	T2	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Ethylcyclohexane	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
N-Ethylcyclohexylamine	Y	S/P	2	2G	Cont	No	T3	IIB	No	C	FT	AC	No	15.12.3, 15.12.4, 15.19
S-Ethyl dipropylthiocarbamate	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6, 16.2.9
Ethylene carbonate	Z	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Ethylene chlorohydrin	Y	S/P	1	2G	Cont	No	T2	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.18, 15.19
Ethylene cyanohydrin	Y	S/P	2	2G	Cont	No		IIB	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Ethylenediamine	Y	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Ethylenediaminetetraacetic acid, tetrasodium salt solution	Y	S/P	3	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Ethylene dibromide	Y	S/P	2	2G	Cont	No			NF	C	T	No	No	15.12, 15.17, 15.19, 16.2.9
Ethylene dichloride	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19
Ethylene glycol	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6
Ethylene glycol acetate	Y	S/P	3	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Ethylene glycol butyl ether acetate	Y	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6
Ethylene glycol diacetate	Y	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Ethylene glycol methyl ether acetate	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6
Ethylene glycol monoalkyl ethers	Y	S/P	3	2G	Cont	No	T2	IIB	No	C	FT	AC	No	15.12.3, 15.12.4, 15.19, 16.2.9
Ethylene glycol phenyl ether	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	AC	No	16.2.9,
Ethylene glycol phenyl ether/Diethylene glycol phenyl ether mixture	Z	S/P	3	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Ethylene glycol (>75%)/sodium alkyl carboxylates/borax mixture	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6
Ethylene glycol (>85%)/sodium alkyl carboxylates mixture	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6
Ethylene oxide/Propylene oxide mixture with an ethylene oxide content of not more than 30% by mass	Y	S/P	2	1G	Cont	Inert	T2	IIB	No	C	FT	AC	Yes	15.8, 15.12, 15.14, 15.17, 15.19
Ethylene-vinyl acetate copolymer (emulsion)	Y	S/P	3	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Ethyl-3-ethoxypropionate	Y	P	2	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
2-Ethylhexanoic acid	Y	S/P	3	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
2-Ethylhexyl acrylate	Y	S/P	3	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.13, 15.19.6, 16.6.1, 16.6.2
2-Ethylhexylamine	Y	S/P	2	2G	Cont	No	T3	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19.6
2-Ethyl-2-(hydroxymethyl) propane-1,3-diol (C8-C10) ester	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Ethylidene norbornene	Y	S/P	2	2G	Cont	No	T3	IIB	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Ethyl methacrylate	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.13, 15.19.6, 16.6.1, 16.6.2
N-Ethylmethylallylamine	Y	S/P	2	2G	Cont	No	T2	IIB	No	C	FT	AC	No	15.12.3, 15.12.4, 15.19
Ethyl propionate	Y	S/P	3	2G	Cont	No	T1	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
2-Ethyl-3-propylacrolein	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6, 16.2.9
Ethyl toluene	Y	P	2	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6
Fatty acid (saturated C13+)	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Fatty acid methyl esters (m)	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Fatty acids, (C8-C10)	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Fatty acids, (C12+)	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Fatty acids, (C16+)	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Fatty acids, essentially linear (C6-C18) 2-ethylhexyl ester	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
Ferric chloride solutions	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.17, 15.19, 16.2.9
Ferric nitrate/Nitric acid solution	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.17, 15.19
Fish oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Fish silage protein concentrate (containing 4% or less formic acid)	Y	P	2	2G	Open	No			NF	O	No	No	No	15.19.6, 16.2.6
Fish protein concentrate (containing 4% or less formic acid)	Z	P	3	2G	Open	No	-	-	NF	O	No	No	No	
Fluorosilicic acid solution (20-30%)	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.17, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Formaldehyde solutions (45% or less)	Y	S/P	3	2G	Cont	No	T2	IIB	No	C	FT	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Formamide	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6, 16.2.9
Formic acid (85% or less acid)	Y	S/P	3	2G	Cont	No	-	-	Yes	C	T(g)	AC	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12.3, 15.12.4, 15.17, 15.19, 16.2.9
Formic acid (over 85%)	Y	S/P	3	2G	Cont	No	T1	IIA	No	C	FT(g)	AC	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12.3, 15.12.4, 15.17, 15.19, 16.2.9
Formic acid mixture (containing up to 18% propionic acid and up to 25% sodium formate)	Z	S/P	3	2G	Cont	No	-	-	Yes	R	T(g)	AC	No	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12.3, 15.12.4, 15.19.6
Furfural	Y	S/P	3	2G	Cont	No	T2	IIB	No	C	FT	AC	Yes	15.12, 15.17, 15.19
Furfuryl alcohol	Y	S/P	3	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Glucitol/glycerol blend propoxylated (containing less than 10% amines)	Z	S/P	3	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Glucitol/glycerol blend propoxylated (containing 10% or more amines)	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Glutaraldehyde solutions (50% or less)	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19
Glycerine	Z	S	3	2G	Open	No			Yes	O	No	AC	No	16.2.9
Glycerol monooleate	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6, 16.2.6, 16.2.9
Glycerol propoxylated	Z	S/P	3	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Glycerol, propoxylated and ethoxylated	Z	P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Glycerol/sucrose blend propoxylated and ethoxylated	Z	P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	
Glyceryl triacetate	Z	S/P	3	2G	Open	No			Yes	O	No	ABC	No	15.19.6
Glycidyl ester of C10 trialkylacetic acid	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Glycine, sodium salt solution	Z	S/P	3	2G	Open	No			NF	O	No	No	No	
Glycolic acid solution (70% or less)	Z	S/P	3	2G	Cont	No	-	-	NF	C	T	No	Yes	15.12.3, 15.12.4, 15.17, 15.19, 16.2.9
Glyoxal solution (40% or less)	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Glyoxylic acid solution (50% or less)	Y	S/P	3	2G	Cont	No	-	-	Yes	C	T	ACD	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12, 15.17, 15.19, 16.2.9, 16.6.1, 16.6.2, 16.6.3
Glyphosate solution (not containing surfactant)	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Grape Seed Oil	Y	S/P	2(k)	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7
Groundnut oil	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Heptane (all isomers)	X	P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
n-Heptanoic acid	Z	S/P	3	2G	Cont	No			Yes	R	No	ABC	No	15.19.6, 15.17
Heptanol (all isomers) (d)	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Heptene (all isomers)	Y	P	2	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
Heptyl acetate	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
1-Hexadecylnaphthalene / 1,4-bis(hexadecyl)naphthalene mixture	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Hexamethylenediamine (molten)	Y	S/P	3	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Hexamethylenediamine adipate (50% in water)	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Hexamethylenediamine solution	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Hexamethylene diisocyanate	Y	S/P	2	2G	Cont	Dry	T1	IIB	Yes	C	T	AC(b)D	Yes	15.12, 15.16.2, 15.17, 15.18, 15.19
Hexamethylene glycol	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	
Hexamethyleneimine	Y	S/P	2	2G	Cont	No	T2	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19
Hexamethylenetetramine solutions	Z	S	3	2G	Open	No			Yes	O	No	AC	No	15.19.6
Hexane (all isomers)	Y	S/P	2	2G	Cont	No	T3	IIA	No	C	FT	AC	No	15.12, 15.17, 15.19.6
1,6-Hexanediol, distillation overheads	Y	S/P	3	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Hexanoic acid	Y	S/P	3	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Hexanol	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Hexene (all isomers)	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Hexyl acetate	Y	S/P	2	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
Hexylene glycol	Z	S	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Hydrocarbon wax	X	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	No	15.12, 15.17, 15.19.6, 16.2.6, 16.2.9
Hydrochloric acid (*)	Z	S/P	3	1G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.17, 15.19
Hydrogen peroxide solutions (over 60% but not over 70% by mass)	Y	S/P	2	2G	Cont	No			NF	R	T	No	No	15.5.1, 15.12.3, 15.12.4, 15.19.6
Hydrogen peroxide solutions (over 8% but not over 60% by mass)	Y	S/P	3	2G	Cont	No			NF	R	T	No	No	15.5.2, 15.18, 15.12.3, 15.12.4, 15.19.6
2-Hydroxyethyl acrylate	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.13, 15.17, 15.19, 16.6.1, 16.6.2
N-(Hydroxyethyl)ethylenediaminetriacetic acid, trisodium salt solution	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
2-Hydroxy-4-(methylthio)butanoic acid	Z	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Illipe oil	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Isoamyl alcohol	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Isobutyl alcohol	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.19.6
Isobutyl formate	Z	P	3	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.19.6
Isobutyl methacrylate	Z	S/P	3	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.13, 15.19.6, 16.6.1, 16.6.2
Isophorone	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Isophoronediamine	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Isophorone diisocyanate	Y	S/P	2	2G	Cont	Dry			Yes	C	T	ABD	Yes	15.12, 15.16.2, 15.17, 15.19
Isoprene	Y	S/P	2	2G	Cont	No	T3	IIB	No	C	FT	ABC	No	15.12, 15.13, 15.14, 15.17, 15.19.6, 16.6.1, 16.6.2
Isopropanolamine	Y	S/P	3	2G	Cont	No	T2	IIA	Yes	R	No	AC	No	15.19.6, 16.2.6, 16.2.9
Isopropyl acetate	Z	P	3	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6
Isopropylamine	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	AC	No	15.12.3.2, 15.14, 15.19
Isopropylamine (70% or less) solution	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	AC	No	15.12.3.2, 15.19
Isopropylcyclohexane	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6, 16.2.9
Isopropyl ether	Y	S/P	3	2G	Cont	Inert	T2	IIA	No	R	F	AC	No	15.4.6, 15.13, 15.19.6, 16.6.1, 16.6.2
Jatropha oil	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7
Lactic acid	Z	S/P	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Lactonitrile solution (80% or less)	Y	S/P	1	1G	Cont	No			NF	C	T	No	Yes	15.12, 15.13, 15.17, 15.18, 15.19, 16.6.1, 16.6.2, 16.6.3
Lard	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Latex, ammonia (1% or less)- inhibited	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6, 16.2.6, 16.2.9
Latex: Carboxylated styrene-Butadiene copolymer; Styrene-Butadiene rubber	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	AC	No	16.2.9
Lauric acid	X	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Ligninsulphonic acid, magnesium salt solution	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	
Ligninsulphonic acid, sodium salt solution	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	16.2.9
Linseed oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Liquid chemical wastes	X	S/P	2	2G	Cont	No			No	C	FT	AC	No	15.12, 15.17, 15.19, 20.5.1, 20.7
Long-chain alkaryl polyether (C11-C20)	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Long-chain alkaryl sulphonic acid (C16-C60)	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Long-chain alkylphenate/Phenol sulphide mixture	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Long-chain alkylphenol (C14-C18)	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Long-chain alkylphenol (C18-C30)	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
L-Lysine solution (60% or less)	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Magnesium chloride solution	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Magnesium hydroxide slurry	Z	S	3	2G	Open	No	-	-	NF	O	No	No	No	16.2.9
Magnesium long-chain alkaryl sulphonate (C11-C50)	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Magnesium long-chain alkyl salicylate (C11+)	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Maleic anhydride	Y	S/P	3	2G	Cont	No			Yes	C	T	AC(f)	Yes	15.12, 15.17, 15.19, 16.2.9
Maleic anhydride-sodium allylsulphonate copolymer solution	Z	P	3	2G	Open	No			Yes	O	No	ABC	No	
Mango kernel oil	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Mercaptobenzothiazol, sodium salt solution	X	S/P	2	2G	Open	No			NF	O	No	No	No	15.19.6, 16.2.9
Mesityl oxide	Z	S/P	3	2G	Cont	No	T2	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Metam sodium solution	X	S/P	2	2G	Cont	No	-	-	NF	C	T	No	No	15.12.3, 15.12.4, 15.19
Methacrylic acid	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	No	15.13, 15.12.3, 15.12.4, 15.19, 16.2.9, 16.6.1
Methacrylic acid - alkoxypoly (alkylene oxide) methacrylate copolymer, sodium salt aqueous solution (45% or less)	Z	S/P	3	2G	Open	No	-	-	NF	O	No	No	No	16.2.9
Methacrylic resin in ethylene dichloride	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19, 16.2.9
Methacrylonitrile	Y	S/P	2	2G	Cont	No	T1	IIA	No	C	FT	AC	Yes	15.12, 15.13, 15.17, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
3-Methoxy-1-butanol	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6
3-Methoxybutyl acetate	Y	S/P	3	2G	Open	No			Yes	O	No	ABC	No	15.19.6
N-(2-Methoxy-1-methyl ethyl)-2-ethyl-6-methyl chloroacetanilide	X	S/P	1	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19, 16.2.6
Methyl acetate	Z	P	3	2G	Cont	No	T1	IIA	No	R	F	AC	No	15.19.6
Methyl acetoacetate	Z	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Methyl acrylate	Y	S/P	3	2G	Cont	No	T1	IIB	No	C	FT	AC	No	15.12, 15.17, 15.13, 15.19
Methyl alcohol (*)	Y	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	AC	No	15.12.1, 15.12.2, 15.12.3.2, 15.12.3.3, 15.12.4, 15.17, 15.19
Methylamine solutions (42% or less)	Y	S/P	2	2G	Cont	No	T2	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19
Methylamyl acetate	Y	P	2	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.19.6
Methylamyl alcohol	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Methyl amyl ketone	Z	S/P	3	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.19.6
N-Methylaniline	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
alpha-Methylbenzyl alcohol with acetophenone (15% or less)	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Methylbutenol	Y	S/P	3	2G	Cont	No	T4	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Methyl tert-butyl ether	Z	P	3	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6
Methyl butyl ketone	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19.6
Methylbutynol	Z	S/P	3	2G	Cont	No	T4	IIB	No	R	F	AC	No	15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Methyl butyrate	Y	S/P	3	2G	Cont	No	T4	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Methylcyclohexane	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Methylcyclopentadiene dimer	Y	S/P	2	2G	Cont	No	T4	IIB	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Methylcyclopentadienyl manganese tricarbonyl	X	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.18, 15.19, 16.2.9
Methyl diethanolamine	Y	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
2-Methyl-6-ethyl aniline	Y	S/P	3	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Methyl ethyl ketone	Z	S/P	3	2G	Cont	No	T1	IIA	No	R	F	AC	No	15.19.6
2-Methyl-5-ethyl pyridine	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Methyl formate	Z	S/P	2	2G	Cont	No	T1	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.14, 15.19.6
2-Methylglutaronitrile with 2-Ethylsuccinonitrile (12% or less)	Z	S/P	3	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
2-Methyl-2-hydroxy-3-butyne	Z	S/P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6, 16.2.9
Methyl isobutyl ketone	Z	S/P	3	2G	Cont	No	T1	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Methyl methacrylate	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.13, 15.19.6
3-Methyl-3-methoxybutanol	Z	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Methyl naphthalene (molten)	X	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
N-Methylglucamine solution (70% or less)	Z	S	3	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
2-Methyl-1,3-propanediol	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
2-Methylpyridine	Z	S/P	3	2G	Cont	No	T1	IIA	No	C	F	AC	No	15.12.3.2, 15.19
3-Methylpyridine	Z	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	AC	No	15.12.3, 15.12.4, 15.19
4-Methylpyridine	Z	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	AC	No	15.12.3, 15.12.4, 15.19, 16.2.9
N-Methyl-2-pyrrolidone	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6
Methyl propyl ketone	Z	S	3	2G	Cont	No	T1	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Methyl salicylate	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6
alpha-Methylstyrene	Y	S/P	2	2G	Cont	No	T1	IIB	No	C	FT	AD(j)	No	15.12, 15.13, 15.17, 15.19.6, 16.6.1, 16.6.2
3-(methylthio)propionaldehyde	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	FT	ABC	No	15.12, 15.17, 15.19.6
Molybdenum polysulphide long chain alkyl dithiocarbamide complex	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Morpholine	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	AC	No	15.12.3, 15.12.4, 15.19
Motor fuel anti-knock compound (containing lead alkyls)	X	S/P	1	1G	Cont	Inert	T4	IIA	No	C	FT	AC	Yes	15.6, 15.12, 15.17, 15.18, 15.19
Myrcene	X	S/P	2	2G	Cont	No	T3	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Naphthalene (molten)	X	S/P	2	2G	Cont	No	T1	IIA	Yes	C	T	ABC	No	15.12, 15.17, 15.19.6, 16.2.9
Naphthalene crude (molten)	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19.6, 16.2.6, 16.2.9
Naphthalenesulphonic acid-Formaldehyde copolymer, sodium salt solution	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	AC	No	16.2.9
Neodecanoic acid	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Nitrating acid (mixture of sulphuric and nitric acids)	Y	S/P	1	1G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.16.2, 15.17, 15.18, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Nitric acid (70% and over)	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.16.2, 15.17, 15.19
Nitric acid (less than 70%)	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.17, 15.19
Nitrilotriacetic acid, trisodium salt solution	Y	S/P	3	2G	Cont	No			Yes	C	T	AC	No	15.12, 15.17, 15.19.6
Nitrobenzene	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	No	15.12, 15.17, 15.19, 16.2.9
Nitroethane	Y	S/P	3	2G	Cont	No	T2	IIB	No	R	FT	ABC(f)	No	15.12.3, 15.12.4, 15.19.6, 16.6.1, 16.6.2, 16.6.4
Nitroethane (80%)/ Nitropropane(20%)	Y	S/P	3	2G	Cont	No	T2	IIB	No	R	FT	ABC(f)	No	15.12.3, 15.12.4, 15.19.6, 16.6.1, 16.6.2, 16.6.3
Nitroethane, 1-Nitropropane (each 15% or more) mixture	Y	S/P	3	2G	Cont	No	T2	IIB	No	R	FT	ABC(f)	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.6.1, 16.6.2, 16.6.3
o-Nitrophenol (molten)	Y	S/P	2	2G	Cont	No	T4	IIB	No	R	F	ABC	No	15.19.6, 16.2.6, 16.2.9
1- or 2-Nitropropane	Y	S/P	3	2G	Cont	No	T2	IIB	No	C	FT	AC	No	15.12, 15.17, 15.19
Nitropropane (60%)/Nitroethane (40%) mixture	Y	S/P	2	2G	Cont	No	T2	IIB	No	C	FT	ABC(f)	No	15.12, 15.17, 15.19.6
o- or p-Nitrotoluenes	Y	S/P	2	2G	Cont	No		IIB	Yes	C	T	ABC	No	15.12, 15.17, 15.19.6
Nonane (all isomers)	X	S/P	2	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
Nonanoic acid (all isomers)	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.9
Non-edible industrial grade palm oil	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.7, 16.2.9
Nonene (all isomers)	Y	P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Nonyl alcohol (all isomers)	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Nonyl methacrylate monomer	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Nonylphenol	X	S/P	1	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Nonylphenol poly(4+)ethoxylate	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6
Noxious liquid, NF, (1) n.o.s. (trade name ....., contains .....) ST1, Cat. X	X	P	1	2G	Open	No	-	-	Yes	O	No	AC	No	15.19, 16.2.6
Noxious liquid, F, (2) n.o.s. (trade name ....., contains .....) ST1, Cat. X	X	P	1	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19, 16.2.6
Noxious liquid, NF, (3) n.o.s. (trade name ....., contains .....) ST2, Cat. X	X	P	2	2G	Open	No	-		Yes	O	No	AC	No	15.19, 16.2.6
Noxious liquid, F, (4) n.o.s. (trade name ....., contains .....) ST2, Cat. X	X	P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19, 16.2.6
Noxious liquid, NF, (5) n.o.s. (trade name ....., contains .....) ST2, Cat. Y	Y	P	2	2G	Open	No	-		Yes	O	No	AC	No	15.19, 16.2.6, 16.2.9(l)
Noxious liquid, F, (6) n.o.s. (trade name ....., contains .....) ST2, Cat. Y	Y	P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19, 16.2.6, 16.2.9(l)
Noxious liquid, NF, (7) n.o.s. (trade name ....., contains .....) ST3, Cat. Y	Y	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	15.19, 16.2.6, 16.2.9(l)

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Noxious liquid, F, (8) n.o.s. (trade name ....., contains .....) ST3, Cat. Y	Y	P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19, 16.2.6, 16.2.9(l)
Noxious liquid, NF, (9) n.o.s. (trade name ....., contains .....) ST3, Cat. Z	Z	P	3	2G	Open	No	-		Yes	O	No	AC	No	
Noxious liquid, F, (10) n.o.s. (trade name ....., contains .....) ST3, Cat. Z	Z	P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Octamethylcyclotetrasiloxane	Y	P	2	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.19.6, 16.2.9
Octane (all isomers)	X	P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Octanoic acid (all isomers)	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Octanol (all isomers)	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Octene (all isomers)	Y	P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
n-Octyl acetate	Y	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9
Octyl aldehydes	Y	S/P	2	2G	Cont	No	T4	IIB	No	R	F	AC	No	15.19.6, 16.2.9
Octyl decyl adipate	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6, 16.2.9
n-Octyl mercaptan	X	S/P	1	2G	Open	No			Yes	O	No	ABC	No	15.19
Offshore contaminated bulk liquid P (o)	X	P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6
Offshore contaminated bulk liquid S (o)	X	S/P	2	2G	Cont	No	T3	IIA	No	C	FT	AC	Yes	15.12, 15.15, 15.17, 15.19
Olefin-Alkyl ester copolymer (molecular weight 2000+)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Olefin Mixture (C7-C9) C8 rich, stabilized	X	P	2	2G	Cont	No	T3	IIB	No	R	F	ABC	No	15.13, 15.19.6
Olefin mixtures (C5-C7)	Y	S/P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Olefin mixtures (C5-C15)	X	S/P	2	2G	Cont	No	T3	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Olefins (C13+, all isomers)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
alpha-Olefins (C6-C18) mixtures	X	S/P	2	2G	Cont	No	T4	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Oleic acid	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Oleum	Y	S/P	2	2G	Cont	Dry	-	-	NF	C	T	No	Yes	15.11.2 to 15.11.8, 15.12, 15.16.2, 15.17, 15.19, 16.2.6
Oleylamine	X	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Olive oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Oxygenated aliphatic hydrocarbon mixture	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	
Palm acid oil	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm fatty acid distillate	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm kernel acid oil	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm kernel fatty acid distillate	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm kernel oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm kernel olein	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm kernel stearin	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm mid-fraction	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm oil	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Palm oil fatty acid methyl ester	Y	P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6, 16.2.9
Palm olein	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Palm stearin	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Paraffin wax, highly-refined	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Paraffin wax, semi-refined	X	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	No	15.12, 15.17, 15.19.6, 16.2.6, 16.2.9
Paraldehyde	Z	S/P	3	2G	Cont	No	T3	IIB	No	R	F	AC	No	15.19.6, 16.2.9
Paraldehyde-ammonia reaction product	Y	S/P	2	2G	Cont	No	T1	IIB	No	C	FT	ABC	Yes	15.12, 15.17, 15.19
Pentachloroethane	Y	S/P	2	2G	Cont	No			NF	C	T	No	No	15.12, 15.17, 15.19.6
1,3-Pentadiene	Y	P	3	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.13, 15.19.6, 16.6.1, 16.6.2, 16.6.3
1,3-Pentadiene (greater than 50%), cyclopentene and isomers, mixtures	Y	S/P	2	2G	Cont	Inert	T3	IIB	No	C	FT	ABC	Yes	15.12, 15.13, 15.17, 15.19
Pentaethylenehexamine	X	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Pentane (all isomers)	Y	P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	15.14, 15.19.6
Pentanoic acid	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
n-Pentanoic acid (64%)/2-Methyl butyric acid (36%) mixture	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12, 15.17, 15.19
Pentene (all isomers)	Y	P	2	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.14, 15.19.6
n-Pentyl propionate	Y	S/P	3	2G	Cont	No	T2	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Perchloroethylene	Y	S/P	2	2G	Cont	No			NF	C	T	No	No	15.12, 15.17, 15.19.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Phenol	Y	S/P	2	2G	Cont	No	T1	IIA	Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
1-Phenyl-1-xylyl ethane	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
Phosphate esters, alkyl (C12-C14) amine	Y	S/P	2	2G	Cont	No	T4	IIB	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Phosphoric acid	Z	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.11.1, 15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12, 15.17, 15.19, 16.2.9
Phosphorus, yellow or white (*)	X	S/P	1	1G	Cont	Pad+(vent or inert)			No(c)	C	No	ABC	No	15.7, 15.19, 16.2.9
Phthalic anhydride (molten)	Y	S/P	2	2G	Cont	No	T1	IIA	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
alpha-Pinene	X	S/P	2	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
beta-Pinene	X	S/P	2	2G	Cont	No	T1	IIB	No	R	F	ABC	No	15.19.6
Pine oil	X	S/P	2	2G	Open	No			Yes	O		ABC	No	15.19.6, 16.2.6, 16.2.9
Piperazine, 68% solution	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Polyacrylic acid solution (40% or less)	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	AC	No	
Polyalkyl (C18-C22) acrylate in xylene	Y	S/P	2	2G	Cont	No	T1	IIB	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Polyalkylalkenaminesuccinimide, molybdenum oxysulphide	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Poly(2-8)alkylene glycol monoalkyl(C1-C6) ether	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	
Poly(2-8)alkylene glycol monoalkyl (C1-C6) ether acetate	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6
Polyalkyl (C10-C20) methacrylate	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Polyalkyl (C10-C18) methacrylate/ethylene-propylene copolymer mixture	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Polyaluminium chloride solution	Z	S	3	2G	Open	No			NF	O	No	No	No	
Polybutene	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Polybutenyl succinimide	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Poly(2+)cyclic aromatics	X	S/P	1	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Polyether (molecular weight 1350+)	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Polyethylene glycol	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Polyethylene glycol dimethyl ether	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	
Poly(ethylene glycol) methylbutenyl ether (MW>1000)	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	16.2.9
Polyethylene polyamines	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.6, 16.2.9
Polyethylene polyamines (more than 50% C5 -C20 paraffin oil)	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Polyferric sulphate solution	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19
Poly(iminoethylene)-graft-N-poly(ethyleneoxy) solution (90% or less)	Z	S/P	3	2G	Open	No	-	-	NF	O	No	No	No	16.2.9
Polyisobutenamine in aliphatic (C10-C14) solvent	Y	S/P	2	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
(Polyisobutene) amino products in aliphatic hydrocarbons	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Polyisobutenyl anhydride adduct	Z	S/P	3	2G	Open	No			Yes	O	No	ABC	No	
Poly(4+)isobutylene (MW>224)	X	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Polyisobutylene (MW≤224)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Polyglycerin, sodium salt solution (containing less than 3% sodium hydroxide)	Z	S	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Polymethylene polyphenyl isocyanate	Y	S/P	3	2G	Cont	Dry			Yes(a)	C	T(a)	AD	Yes	15.12, 15.16.2, 15.17, 15.19.6, 16.2.9
Polyolefin (molecular weight 300+)	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Polyolefin amide alkeneamine (C17+)	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Polyolefin amide alkeneamine borate (C28-C250)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Polyolefin amide alkeneamine polyol	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Polyolefinamine (C28-C250)	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Polyolefinamine in alkyl (C2-C4) benzenes	Y	S/P	2	2G	Cont	No	T2	IIB	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Polyolefinamine in aromatic solvent	Y	S/P	2	2G	Cont	No	T2	IIB	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Polyolefin aminoester salts (molecular weight 2000+)	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Polyolefin anhydride	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Polyolefin ester (C28-C250)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Polyolefin phenolic amine (C28-C250)	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Polyolefin phosphorusulphide, barium derivative (C28-C250)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Poly(20)oxyethylene sorbitan monooleate	Y	P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.6, 16.2.9
Poly(5+)propylene	Y	P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.9
Polypropylene glycol	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6
Polysiloxane	Y	P	2	2G	Cont	No	T2	IIB	No	R	F	ABC	No	15.19.6, 16.2.9
Potassium chloride solution	Z	P	3	2G	Open	No	-	-	NF	O	No	No	No	16.2.9
Potassium hydroxide solution (*)	Y	S/P	3	2G	Open	No			NF	C	No	No	No	15.12.3.2, 15.19
Potassium formate solutions (*)	Z	S	3	2G	Open	No			NF	R	No	No	No	15.19.6
Potassium oleate	Y	S/P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.6, 16.2.9
Potassium thiosulphate (50% or less)	Y	S/P	3	2G	Cont	No			NF	R	T	No	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
n-Propanolamine	Y	S/P	3	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.9
2-Propene-1-aminium, N,N-dimethyl-N-2-propenyl-, chloride, homopolymer solution	Y	P	3	2G	Open	No	-	-	NF	O	No	No	No	15.19.6
beta-Propiolactone	Y	S/P	1	2G	Cont	No		IIA	Yes	C	T	AC	Yes	15.12, 15.17, 15.18, 15.19
Propionaldehyde	Y	S/P	3	2G	Cont	Inert	T4	IIB	No	R	F	AC	No	15.19.6
Propionic acid	Y	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	AC	Yes	15.11.2, 15.11.3, 15.11.4, 15.11.6, 15.11.7, 15.11.8, 15.12, 15.17, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Propionic anhydride	Y	S/P	2	2G	Cont	No	T2	IIA	Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Propionitrile	Y	S/P	1	1G	Cont	No	T1	IIB	No	C	FT	AC	Yes	15.12, 15.17, 15.18, 15.19
n-Propyl acetate	Y	P	3	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6
n-Propyl alcohol	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	AC	No	15.12, 15.17, 15.19.6
n-Propylamine	Z	S/P	2	2G	Cont	Inert	T2	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19
Propylbenzene (all isomers)	Y	P	3	2G	Cont	No	T2	IIA	No	R	F	ABC	No	15.19.6
Propylene carbonate	Z	S	3	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19
Propylene glycol methyl ether acetate	Z	P	3	2G	Cont	No	T2	IIA	No	R	F	AC	No	
Propylene glycol monoalkyl ether	Z	S/P	3	2G	Cont	No	T3	IIA	No	R	F	AC	No	15.19.6
Propylene glycol phenyl ether	Z	S/P	3	2G	Open	No			Yes	O	No	ABC	No	
Propylene oxide	Y	S/P	2	2G	Cont	Inert	T2	IIB	No	C	FT	AC	No	15.8, 15.12, 15.14, 15.17, 15.19
Propylene tetramer	X	S/P	2	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
Propylene trimer	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	F	ABC	No	15.19.6
Pyridine	Y	S/P	3	2G	Cont	No	T1	IIA	No	R	FT	AC	No	15.12.3, 15.12.4, 15.19.6
Pyrolysis gasoline (containing benzene)	Y	S/P	2	2G	Cont	No	T3	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19.6
Rapeseed oil	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Rapeseed oil (low erucic acid containing less than 4% free fatty acids)	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Rape seed oil fatty acid methyl esters	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6
Resin oil, distilled	Y	S/P	2	2G	Cont	No	T1	IIA	No	C	FT	ABC	No	15.12, 15.17, 15.19.6
Rice bran oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Rosin	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Safflower oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Shea butter	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Sodium alkyl (C14-C17) sulphonates (60-65% solution)	Y	S/P	2	2G	Cont	No			NF	R	T	No	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Sodium aluminosilicate slurry	Z	P	3	2G	Open	No			NF	O	No	No	No	16.2.9
Sodium benzoate	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	16.2.9
Sodium borohydride (15% or less)/Sodium hydroxide solution (*)	Y	S/P	3	2G	Open	No			NF	C	No	No	No	15.19, 16.2.6, 16.2.9
Sodium bromide solution (less than 50%) (*)	Y	S/P	3	2G	Open	No	-	-	NF	R	No	No	No	15.19.6
Sodium carbonate solution (*)	Z	S/P	3	2G	Open	No			NF	R	No	No	No	15.19.6
Sodium chlorate solution (50% or less) (*)	Z	S/P	3	2G	Open	No			NF	R	No	No	No	15.9, 15.12, 15.19, 16.2.9
Sodium dichromate solution (70% or less)	Y	S/P	1	1G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.18, 15.19
Sodium hydrogen sulphide (6% or less)/Sodium carbonate (3% or less) solution	Z	S/P	3	2G	Open	No			NF	O	No	No	No	15.19.6, 16.2.9
Sodium hydrogen sulphite solution (45% or less)	Z	P	3	2G	Open	No			NF	O	No	No	No	16.2.9
Sodium hydrosulphide/Ammonium sulphide solution (*)	Y	S/P	2	2G	Cont	No	T4	IIB	No	C	FT	AC	Yes	15.12, 15.15, 15.17, 15.19, 16.6.1, 16.6.2, 16.6.3
Sodium hydrosulphide solution (45% or less) (*)	Z	S/P	3	2G	Cont	Vent or pad (gas)			NF	R	T	No	Yes	15.12, 15.15, 15.19.6, 16.2.9
Sodium hydroxide solution (*)	Y	S/P	3	2G	Open	No			NF	C	No	No	No	15.19, 16.2.6, 16.2.9

MSC 101/24/Add.1  
Annex 5, page 52

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Sodium hypochlorite solution (15% or less)	Y	S/P	2	2G	Cont	No	-	-	NF	R	No	No	No	15.17, 15.19.6
Sodium methylate 21-30% in methyl alcohol	Y	S/P	2	2G	Cont	No	T1	IIA	No	C	FT	AC	Yes	15.12, 15.17, 15.19, 16.2.6 (only if >28%), 16.2.9
Sodium nitrite solution	Y	S/P	3	2G	Cont	No			NF	C	T	No	No	15.12.3, 15.12.4, 15.19, 16.2.6, 16.2.9
Sodium petroleum sulphonate	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	Yes	15.12.3, 15.12.4, 15.19.6, 16.2.6
Sodium poly(4+)acrylate solutions	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	AC	No	16.2.9
Sodium silicate solution	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19, 16.2.9
Sodium sulphate solutions	Z	S	3	2G	Open	No			NF	O	No	No	No	16.2.9,
Sodium sulphide solution (15% or less)	Y	S/P	3	2G	Cont	No			NF	C	T	No	Yes	15.12, 15.17, 15.19, 16.2.9
Sodium sulphite solution (25% or less)	Y	S/P	3	2G	Open	No			NF	O	No	No	No	15.19.6, 16.2.9
Sodium thiocyanate solution (56% or less)	Y	S/P	3	2G	Open	No			NF	O	No	No	No	15.19.6, 16.2.9
Soyabean oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Soybean Oil Fatty Acid Methyl Ester	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Styrene monomer	Y	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	ABC	No	15.12, 15.13, 15.17, 15.19.6, 16.6.1, 16.6.2
Sulphohydrocarbon (C3-C88)	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Sulpholane	Y	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9
Sulphur (molten) (*)	Z	S	3	1G	Open	Vent or pad (gas)	T3		Yes	O	FT	No	No	15.10, 16.2.9

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Sulphuric acid	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.16.2, 15.17, 15.19, 16.2.9
Sulphuric acid, spent	Y	S/P	2	2G	Cont	No			NF	C	T	No	Yes	15.11, 15.12, 15.16.2, 15.17, 15.19
Sulphurized fat (C14-C20)	Z	S/P	3	2G	Open	No			Yes	O	No	ABC	No	
Sulphurized polyolefinamide alkene (C28-C250) amine	Z	P	3	2G	Open	No	-	-	Yes	O	No	AC	No	
Sunflower seed oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Tall oil, crude	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Tall oil, distilled	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6
Tall oil fatty acid (resin acids less than 20%)	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6
Tall oil pitch	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Tall oil soap, crude	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.6
Tallow	Y	P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Tallow fatty acid	Y	P	2	2G	Open	No	-	-	Yes	O	No	AC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Tetrachloroethane	Y	S/P	2	2G	Cont	No			NF	R	T	No	No	15.12.3, 15.12.4, 15.19
Tetraethylene glycol	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Tetraethylene pentamine	Y	S/P	2	2G	Cont	No			Yes	C	T	AC	Yes	15.12, 15.17, 15.19
Tetrahydrofuran	Z	S	3	2G	Cont	No	T3	IIB	No	R	F	AC	No	15.19.6
Tetrahydronaphthalene	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Tetramethylbenzene (all isomers)	X	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.9
Titanium dioxide slurry	Z	P	3	2G	Open	No			NF	O	No	No	No	

MSC 101/24/Add.1  
Annex 5, page 54

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Toluene	Y	S/P	3	2G	Cont	No	T1	IIA	No	C	FT	AC	No	15.12, 15.17, 15.19.6
Toluenediamine	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.17, 15.18, 15.19, 16.2.6, 16.2.9
Toluene diisocyanate	Y	S/P	2	2G	Cont	Dry	-	-	Yes	C	T	ABC(b)D	Yes	15.12, 15.16.2, 15.17, 15.18, 15.19, 16.2.9
o-Toluidine	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19
Tributyl phosphate	Y	S/P	3	2G	Cont	No			Yes	C	T	ABC	No	15.12.3, 15.12.4, 15.19.6
1,2,3-Trichlorobenzene (molten)	X	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
1,2,4-Trichlorobenzene	X	S/P	1	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19, 16.2.9
1,1,1-Trichloroethane	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
1,1,2-Trichloroethane	Y	S/P	3	2G	Open	No			NF	O	No	No	No	15.19.6
Trichloroethylene	Y	S/P	2	2G	Cont	No	-	-	NF	C	T	No	No	15.12, 15.17, 15.19.6
1,2,3-Trichloropropane	Y	S/P	3	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19
1,1,2-Trichloro-1,2,2-Trifluoroethane	Y	P	2	2G	Open	No			NF	O	No	No	No	15.19.6
Tricresyl phosphate (containing 1% or more ortho-isomer)	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	ABC	No	15.12, 15.17, 15.19, 16.2.6
Tricresyl phosphate (containing less than 1% ortho-isomer)	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19.6, 16.2.6
Tridecane	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
Tridecanoic acid	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Tridecyl acetate	Y	S/P	3	2G	Cont	No	-	-	Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Triethanolamine	Z	S/P	3	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Triethylamine	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	ABC	No	15.12.3, 15.12.4, 15.19

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Triethylbenzene	X	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6
Triethylenetetramine	Y	S/P	2	2G	Cont	No	-	-	Yes	C	T	AC	Yes	15.12, 15.17, 15.19, 16.2.9
Triethyl phosphate	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6
Triethyl phosphite	Z	S/P	3	2G	Cont	No	T3	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Trisopropanolamine	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.9
Trisopropylated phenyl phosphates	X	P	2	2G	Open	No			Yes	O	No	AC	No	15.19.6, 16.2.6
Trimethylacetic acid	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.11, 15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
Trimethylamine solution (30% or less)	Z	S/P	2	2G	Cont	No	T3	IIB	No	R	FT	AC	No	15.12.3, 15.12.4, 15.14, 15.19.6
Trimethylbenzene (all isomers)	X	S/P	2	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6
Trimethylol propane propoxylated	Z	S/P	3	2G	Open	No	-	-	Yes	O	No	ABC	No	
2,2,4-Trimethyl-1,3-pentanediol diisobutyrate	Y	S/P	3	2G	Open	No			Yes	O	No	ABC	No	15.19.6
2,2,4-Trimethyl-1,3-pentanediol-1-isobutyrate	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
1,3,5-Trioxane	Y	S/P	3	2G	Cont	No	T2	IIB	No	C	FT	AC	No	15.12, 15.17, 15.19.6, 16.2.9
Tripropylene glycol	Z	P	3	2G	Open	No			Yes	O	No	AC	No	
Trixylyl phosphate	X	S/P	1	2G	Cont	No			Yes	C	T	ABC	No	15.12, 15.17, 15.19.6, 16.2.6

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Tung oil	Y	S/P	2(k)	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Turpentine	X	S/P	2	2G	Cont	No	T3	IIA	No	R	FT	AC	No	15.19.6
Undecanoic acid	Y	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.6, 16.2.9
1-Undecene	X	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6
Undecyl alcohol	X	S/P	2	2G	Cont	No			Yes	R	T	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Urea/Ammonium nitrate solution	Y	S/P	3	2G	Open	No	-	-	NF	O	No	No	No	15.19.6
Urea/Ammonium phosphate solution	Y	S/P	2	2G	Cont	No			Yes	R	T	AC	No	15.12.3, 15.12.4, 15.19.6
Urea solution	Z	S/P	3	2G	Open	No			Yes	O	No	AC	No	16.2.9,
Used cooking oil (m)	X	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Used cooking oil (Triglycerides, C16-C18 and C18 unsaturated) (m) (n)	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Valeraldehyde (all isomers)	Y	S/P	3	2G	Cont	Inert	T3	IIB	No	R	F	ABC	No	15.4.6, 15.13, 15.19.6, 16.6.1, 16.6.2
Vegetable acid oils (m)	Y	S/P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Vegetable fatty acid distillates (m)	Y	P	2	2G	Open	No	-	-	Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Vegetable oil mixtures, containing less than 15% free fatty acid (m)	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.7, 16.2.9
Vinyl acetate	Y	S/P	3	2G	Cont	No	T2	IIA	No	C	FT	ABC	No	15.12, 15.13, 15.17, 15.19.6, 16.6.1, 16.6.2
Vinyl ethyl ether	Z	S/P	2	2G	Cont	Inert	T3	IIB	No	R	F	ABC	No	15.4, 15.13, 15.14, 15.19.6, 16.6.1, 16.6.2

a	c	d	e	f	g	h	i'	i''	i'''	j	k	l	n	o
Vinylidene chloride	Y	S/P	2	2G	Cont	Inert	T2	IIA	No	C	FT	ABC	No	15.12, 15.13, 15.14, 15.17, 15.19, 16.6.1, 16.6.2
Vinyl neodecanoate	Y	S/P	2	2G	Cont	No			Yes	C	T	ABC	Yes	15.12, 15.13, 15.17, 15.19, 16.6.1, 16.6.2
Vinyltoluene	Y	S/P	2	2G	Cont	No	T1	IIA	No	C	FT	ABC	No	15.12, 15.13, 15.17, 15.19.6, 16.6.1, 16.6.2
White spirit, low (15-20%) aromatic	Y	S/P	2	2G	Cont	No	T3	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6, 16.2.9
Wood lignin with sodium acetate/oxalate	Z	S/P	3	2G	Open	No	-	-	NF	O	No	No	No	
Xylenes	Y	P	2	2G	Cont	No	T1	IIA	No	R	F	ABC	No	15.19.6, 16.2.9 (h)
Xylenes/ethylbenzene (10% or more) mixture	Y	S/P	2	2G	Cont	No	T2	IIA	No	R	FT	ABC	No	15.12.3, 15.12.4, 15.19.6
Xylenol	Y	S/P	2	2G	Cont	No	-	IIA	Yes	C	T	ABC	Yes	15.12, 15.17, 15.19, 16.2.9
Zinc alkaryl dithiophosphate (C7-C16)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6, 16.2.9
Zinc alkenyl carboxamide	Y	S/P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6
Zinc alkyl dithiophosphate (C3-C14)	Y	P	2	2G	Open	No			Yes	O	No	ABC	No	15.19.6, 16.2.6

### Footnotes to products in chapter 17

Some entries in chapter 17 contain footnotes, as either letters or symbols in parentheses following the name of the product, in *column a* of the tables. These provide additional information about the carriage requirements for the product. The definitions of these footnotes are included below.

- a If the product to be carried contains flammable solvents such that the flashpoint does not exceed 60°C, then special electrical systems and a flammable-vapour detector shall be provided.
- b Although water is suitable for extinguishing open-air fires involving chemicals to which this footnote applies, water shall not be allowed to contaminate closed tanks containing these chemicals because of the risk of hazardous gas generation.
- c Phosphorus, yellow or white, is carried above its autoignition temperature and therefore flashpoint is not appropriate. Electrical equipment requirements may be similar to those for substances with a flashpoint above 60°C.
- d Requirements are based on those isomers having a flashpoint of 60°C or less; some isomers have a flashpoint greater than 60°C and therefore the requirements based on flammability would not apply to such isomers.
- e Applies to n-decyl alcohol only.
- f Dry chemical shall not be used as fire-extinguishing media.
- g Confined spaces shall be tested for both formic acid vapours and carbon monoxide gas, a decomposition product.
- h Applies to p-xylene only.
- i For mixtures containing no other components with safety hazards and where the pollution category is Y or less.
- j Only certain alcohol-resistant foams are effective.
- k Requirements for Ship Type identified in *column e* might be subject to regulation 4.1.3 of Annex II of MARPOL.
- l Applicable when the melting point is equal to or greater than 0°C.
- m From vegetable oils, animal fats and fish oils specified in the IBC Code.
- n Confirmation that the product is composed of Triglycerides, C16-C18 and C18 unsaturated shall be required in order for the entry to be used. Otherwise, the more generic entry "Used cooking oil (m)" must be used.
- o Indicates that the entries are to be used solely for backloading of contaminated bulk liquids from offshore installations used in the search and exploitation of seabed mineral resources.
- \* Indicates that with reference to chapter 21 of the IBC Code (paragraph 21.1.3), deviations from the normal assignment criteria used for some carriage requirements have been implemented.

## Chapter 18

### List of products to which the Code does not apply

18.1 The following are products which have been reviewed for their safety and pollution hazards and determined not to present hazards to such an extent as to warrant application of the Code.

18.2 Although the products listed in this chapter fall outside the scope of the Code, the attention of Administrations is drawn to the fact that some safety precautions may be needed for their safe transportation. Accordingly, Administrations shall prescribe appropriate safety requirements.

18.3 Some liquid substances are identified as falling into Pollution Category Z and, therefore, subject to certain requirements of MARPOL Annex II.

18.4 Liquid mixtures which are assessed or provisionally assessed under regulation 6.3 of MARPOL Annex II as falling into Pollution Category Z or OS, and which do not present safety hazards, may be carried under the appropriate entry in this chapter for "Noxious or Non-Noxious Liquid Substances, not otherwise specified (n.o.s.)".

#### EXPLANATORY NOTES

Product name	The product name shall be used in the shipping document for any cargo offered for bulk shipments. Any additional name may be included in brackets after the product name. In some cases, the product names are not identical with the names given in previous issues of the Code.
Pollution Category	The letter Z means the Pollution Category assigned to each product under Annex II of MARPOL. OS means the product was evaluated and found to fall outside Categories X, Y, or Z.

<b>Product Name</b>	<b>Pollution Category</b>
Acetone	Z
Alcoholic beverages, n.o.s.	Z
Apple juice	OS
n-Butyl alcohol	Z
sec-Butyl alcohol	Z
Calcium carbonate slurry	OS
Clay slurry	OS
Coal slurry	OS
Ethyl alcohol	Z
Glucose solution	OS
Glycerol ethoxylated	OS
Hydrogenated starch hydrolysate	OS
Isopropyl alcohol	Z
Kaolin slurry	OS
Lecithin	OS
Maltitol solution	OS

<b>Product Name</b>	<b>Pollution Category</b>
Microsilica slurry	OS
Molasses	OS
Noxious liquid, (11) n.o.s. (trade name ....., contains .....) Cat. Z	Z
Non noxious liquid, (12) n.o.s. (trade name ....., contains .....) Cat. OS	OS
Orange juice (concentrated)	OS
Orange juice (not concentrated)	OS
Potassium chloride solution (less than 26%)	OS
Propylene glycol	OS
Sodium acetate solutions	Z
Sodium bicarbonate solution (less than 10%)	OS
Sorbitol solution	OS
Sulphonated polyacrylate solution	Z
Tetraethyl silicate monomer/oligomer (20% in ethanol)	Z
Triethylene glycol	OS
Vegetable protein solution (hydrolysed)	OS
Water	OS

## Chapter 19

### Index of Products Carried in Bulk

19.1 The first column of the Index of Products Carried in Bulk (hereafter referred to as "the Index") provides the so-called Index Name. Where the Index Name is in capitals and in bold, the Index Name is identical to the Product Name in either chapter 17 or chapter 18. The second column listing the relevant Product Name is therefore empty. Where the Index Name is non-bold lower case it reflects a synonym for which the Product Name in either chapter 17 or chapter 18 is given in the second column. The relevant chapter of the IBC Code is reflected in the third column.

19.2 Following a review of chapter 19, a column listing UN numbers which was previously included had been removed from the Index. Since UN numbers are only available for a limited number of Index Names and there are inconsistencies between some of the names used in chapter 19 and those linked to UN numbers, it was decided to remove UN number references in order to avoid any confusion.

19.3 The Index has been developed for information purposes only. None of the Index Names indicated in non-bold lower case in the first column shall be used as the Product Name on the shipping document.

19.4 Prefixes forming an integral part of the name are shown in ordinary (roman) type and are taken into account in determining the alphabetical order of entries. These include such prefixes as:

Mono Di Tri Tetra Penta Iso Bis Neo Ortho Cyclo

19.5 Prefixes that are disregarded for purposes of alphabetical order are the following:

n-	(normal-)
sec-	(secondary-)
tert-	(tertiary-)
o-	(ortho-)
m-	(meta-)
p-	(para-)
N-	
O-	
S-	
sym-	(symmetrical)
uns-	(unsymmetrical)
dl-	
D-	
L-	
cis-	
trans-	
(E)-	
(Z)-	
alpha-	( $\alpha$ -)
beta-	( $\beta$ -)
gamma-	( $\gamma$ -)
epsilon-	( $\epsilon$ -)
omega-	( $\omega$ -)

19.6 The Index utilizes a note after the index name for some entries (shown as (a) or (b)) which indicates that the following qualifications apply:

- (a) This Index Name represents a subset of the corresponding Product Name.
- (b) The Product Name corresponding to this Index Name contains a carbon chain length qualification. Since the Index Name should always represent a subset or be an exact synonym of the corresponding Product Name, the carbon chain length characteristics should be checked for any product identified by this Index Name.

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Abietic anhydride	ROSIN	17
acedimethylamide	N,N-DIMETHYLACETAMIDE	17
Acetaldehyde cyanohydrin solution (80% or less)	LACTONITRILE SOLUTION (80% OR LESS)	17
Acetaldehyde trimer	PARALDEHYDE	17
<b>ACETIC ACID</b>		17
Acetic acid anhydride	ACETIC ANHYDRIDE	17
Acetic acid, ethenyl ester	VINYL ACETATE	17
Acetic acid, methyl ester	METHYL ACETATE	17
Acetic acid, vinyl ester	VINYL ACETATE	17
<b>ACETIC ANHYDRIDE</b>		17
Acetic ester	ETHYL ACETATE	17
Acetic ether	ETHYL ACETATE	17
Acetic oxide	ACETIC ANHYDRIDE	17
Acetoacetic acid, methyl ester	METHYL ACETOACETATE	17
Acetoacetic ester	ETHYL ACETOACETATE	17
<b>ACETOCHLOR</b>		17
<b>ACETONE</b>		18
<b>ACETONE CYANOHYDRIN</b>		17
<b>ACETONITRILE</b>		17
<b>ACETONITRILE (LOW PURITY GRADE)</b>		17
Acetyl anhydride	ACETIC ANHYDRIDE	17
Acetylene tetrachloride	TETRACHLOROETHANE	17
Acetyl ether	ACETIC ANHYDRIDE	17
Acetyl oxide	ACETIC ANHYDRIDE	17
<b>ACID OIL MIXTURE FROM SOYABEAN, CORN (MAIZE) AND SUNFLOWER OIL REFINING</b>		17
Acroleic acid	ACRYLIC ACID	17
<b>ACRYLAMIDE SOLUTION (50% OR LESS)</b>		17
<b>ACRYLIC ACID</b>		17
<b>ACRYLIC ACID/ETHENESULPHONIC ACID COPOLYMER WITH PHOSPHONATE GROUPS, SODIUM SALT SOLUTION</b>		17
Acrylic acid, 2-hydroxyethyl ester	2-HYDROXYETHYL ACRYLATE	17
Acrylic amide solution, 50% or less	ACRYLAMIDE SOLUTION (50% OR LESS)	17
Acrylic resin monomer	METHYL METHACRYLATE	17
<b>ACRYLONITRILE</b>		17
<b>ACRYLONITRILE-STYRENE COPOLYMER DISPERSION IN POLYETHER POLYOL</b>		17
Adipic acid, bis(2-ethylhexyl) ester	DI-(2-ETHYLHEXYL) ADIPATE	17
<b>ADIPONITRILE</b>		17
<b>ALACHLOR TECHNICAL (90% OR MORE)</b>		17
Alcohol	ETHYL ALCOHOL	18
Alcohol, C10	DECYL ALCOHOL (ALL ISOMERS)	17
Alcohol, C11	UNDECYL ALCOHOL	17
Alcohol, C12	DODECYL ALCOHOL	17
Alcohol, C7 (a)	HEPTANOL (ALL ISOMERS) (D)	17
Alcohol, C8	OCTANOL (ALL ISOMERS)	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Alcohol, C9	<b>NONYL ALCOHOL (ALL ISOMERS)</b>	17
<b>ALCOHOLIC BEVERAGES, N.O.S.</b>		18
<b>ALCOHOL (C9-C11) POLY(2.5-9)ETHOXYLATE</b>		17
<b>ALCOHOL (C10-C18) POLY (7) ETHOXYLATE</b>		17
<b>ALCOHOL (C6-C17) (SECONDARY) POLY(3-6)ETHOXYLATES</b>		17
<b>ALCOHOL (C6-C17) (SECONDARY) POLY(7-12)ETHOXYLATES</b>		17
<b>ALCOHOL (C12-C16) POLY(1-6) ETHOXYLATES</b>		17
<b>ALCOHOL (C12-C16) POLY(20+)ETHOXYLATES</b>		17
<b>ALCOHOL (C12-C16) POLY(7-19)ETHOXYLATES</b>		17
<b>ALCOHOLS (C13+)</b>		17
Alcohols, C13 - C15	<b>ALCOHOLS (C13+)</b>	17
<b>ALCOHOLS (C12+), PRIMARY, LINEAR</b>		17
<b>ALCOHOLS (C8-C11), PRIMARY, LINEAR AND ESSENTIALLY LINEAR</b>		17
<b>ALCOHOLS (C12-C13), PRIMARY, LINEAR AND ESSENTIALLY LINEAR</b>		17
<b>ALCOHOLS (C14-C18), PRIMARY, LINEAR AND ESSENTIALLY LINEAR</b>		17
Aldehyde collidine	<b>2-METHYL-5-ETHYL PYRIDINE</b>	17
Aldehydine	<b>2-METHYL-5-ETHYL PYRIDINE</b>	17
<b>ALKANES (C6-C9)</b>		17
<b>ISO- AND CYCLO-ALKANES (C10-C11)</b>		17
<b>ISO- AND CYCLO-ALKANES (C12+)</b>		17
<b>N-ALKANES (C9-C11)</b>		17
<b>N-ALKANES (C10-C20)</b>		17
Alkane(C10-C18)sulfonic acid, phenyl ester (a)	<b>ALKYL SULPHONIC ACID ESTER OF PHENOL</b>	17
<b>ALKARYL POLYETHERS (C9-C20)</b>		17
<b>ALKENOIC ACID, POLYHYDROXY ESTER BORATED</b>		17
<b>ALKENYL (C11+) AMIDE</b>		17
<b>ALKENYL (C16-C20) SUCCINIC ANHYDRIDE</b>		17
<b>ALKYL ACRYLATE/VINYLPYRIDINE COPOLYMER IN TOLUENE</b>		17
<b>ALKYL/CYCLO (C4-C5) ALCOHOLS</b>		17
<b>ALKYLARYL PHOSPHATE MIXTURES (MORE THAN 40% DIPHENYL TOLYL PHOSPHATE, LESS THAN 0.02% ORTHO-ISOMERS)</b>		17
<b>ALKYLATED (C4-C9) HINDERED PHENOLS</b>		17
<b>ALKYLBENZENE, ALKYLINDANE, ALKYLINDENE MIXTURE (EACH C12-C17)</b>		17
<b>ALKYLBENZENE DISTILLATION BOTTOMS</b>		17
<b>ALKYLBENZENE MIXTURES (CONTAINING AT LEAST 50% OF TOLUENE)</b>		17
<b>ALKYL (C3-C4) BENZENES</b>		17
<b>ALKYL (C5-C8) BENZENES</b>		17
<b>ALKYL(C9+)BENZENES</b>		17

Index Name	Product Name	Chapter
ALKYLBENZENES MIXTURES (CONTAINING NAPHTHALENE)		17
ALKYL (C11-C17) BENZENE SULPHONIC ACID		17
ALKYLBENZENE SULPHONIC ACID, SODIUM SALT SOLUTION		17
ALKYL (C12+) DIMETHYLAMINE		17
ALKYL DITHIOCARBAMATE (C19-C35)		17
ALKYL DITHIOTHIAZOLE (C6-C24)		17
ALKYL ESTER COPOLYMER (C4-C20)		17
ALKYL (C8-C10)/(C12-C14):(40% OR LESS/60% OR MORE) POLYGLUCOSIDE SOLUTION (55% OR LESS)		17
ALKYL (C8-C10)/(C12-C14):(60% OR MORE/40% OR LESS) POLYGLUCOSIDE SOLUTION(55% OR LESS)		17
ALKYL (C7-C9) NITRATES		17
2,2'- [3-(Alkyl(C16-C18)oxy)propylimino]diethanol (a)	ETHOXYLATED LONG CHAIN (C16+) ALKYOXYALKYLAMINE	17
Alkylphenol, long-chain (C14-C18)	LONG-CHAIN ALKYLPHENOL (C14-C18)	17
Alkylphenol, long-chain (C18-C30)	LONG-CHAIN ALKYLPHENOL (C18-C30)	17
ALKYL(C7-C11)PHENOL POLY(4-12) ETHOXYLATE		17
ALKYL (C8-C40) PHENOL SULPHIDE		17
ALKYL (C8-C9) PHENYLAMINE IN AROMATIC SOLVENTS		17
ALKYL (C9-C15) PHENYL PROPOXYLATE		17
ALKYL (C8-C10) POLYGLUCOSIDE SOLUTION (65% OR LESS)		17
ALKYL (C8-C10)/(C12-C14):(50%/50%) POLYGLUCOSIDE SOLUTION (55% OR LESS)		17
ALKYL (C12-C14) POLYGLUCOSIDE SOLUTION (55% OR LESS)		17
ALKYL(C12-C16) PROPOXYAMINE ETHOXYLATE		17
ALKYL (C10-C15, C12 RICH) PHENOL POLY(4-12)ETHOXYLATE		17
ALKYL (C10-C20, SATURATED AND UNSATURATED) PHOSPHITE		17
ALKYL SULPHONIC ACID ESTER OF PHENOL		17
ALKYL (C18+) TOLUENES		17
Alkyltoluenesulfonic acid, calcium salts, high overbase (up to 70% in mineral oil)	ALKYL (C18-C28) TOLUENESULPHONIC ACID, CALCIUM SALTS, HIGH OVERBASE	17
Alkyl(C18-C28)toluenesulfonic acid,calcium salts, low overbase (up to 60% in mineral oil)	ALKYL (C18-C28) TOLUENESULPHONIC ACID, CALCIUM SALTS, LOW OVERBASE	17
ALKYL(C18-C28)TOLUENESULPHONIC ACID		17
ALKYL(C18-C28)TOLUENESULPHONIC ACID, CALCIUM SALTS, BORATED		17
ALKYL (C18-C28) TOLUENESULPHONIC ACID, CALCIUM SALTS, HIGH OVERBASE		17
ALKYL (C18-C28) TOLUENESULPHONIC ACID, CALCIUM SALTS, LOW OVERBASE		17
3-Alkyl(C16-C18)oxy-N,N'-bis(2-hydroxyethyl)propan-1-amine (a)	ETHOXYLATED LONG CHAIN (C16+) ALKYOXYALKYLAMINE	17
ALLYL ALCOHOL		17
ALLYL CHLORIDE		17
ALUMINIUM CHLORIDE/HYDROGEN CHLORIDE SOLUTION		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>ALUMINIUM HYDROXIDE, SODIUM HYDROXIDE, SODIUM CARBONATE SOLUTION (40% OR LESS)</b>		17
Aluminium silicate hydroxide	<b>KAOLIN SLURRY</b>	18
<b>ALUMINIUM SULPHATE SOLUTION</b>		17
Aminoacetic acid, sodium salt solution	<b>GLYCINE, SODIUM SALT SOLUTION</b>	17
1-Amino-3-aminomethyl-3,5,5-trimethylcyclohexane	<b>ISOPHORONEDIAMINE</b>	17
Aminobenzene	<b>ANILINE</b>	17
1-Aminobutane (a)	<b>BUTYLAMINE (ALL ISOMERS)</b>	17
2-Aminobutane	<b>BUTYLAMINE (ALL ISOMERS)</b>	17
Aminocyclohexane	<b>CYCLOHEXYLAMINE</b>	17
Aminoethane	<b>ETHYLAMINE</b>	17
Aminoethane solutions, 72% or less	<b>ETHYLAMINE SOLUTIONS (72% OR LESS)</b>	17
2-Aminoethanol	<b>ETHANOLAMINE</b>	17
<b>2-(2-AMINOETHOXY) ETHANOL</b>		17
2-(2-Aminoethylamino)ethanol	<b>AMINOETHYL ETHANOLAMINE</b>	17
<b>AMINOETHYLDIETHANOLAMINE/AMINOETHYLETHANOLA MINE SOLUTION</b>		17
<b>AMINOETHYL ETHANOLAMINE</b>		17
N-(2-aminoethyl)ethylenediamine	<b>DIETHYLENETRIAMINE</b>	17
1-(2-Aminoethyl)piperazine	<b>N-AMINOETHYLPIPERAZINE</b>	17
<b>N-AMINOETHYLPIPERAZINE</b>		17
2-Aminoisobutane (a)	<b>BUTYLAMINE (ALL ISOMERS)</b>	17
Aminomethane solutions, 42% or less	<b>METHYLAMINE SOLUTIONS (42% OR LESS)</b>	17
1-Amino-2-methylbenzene	<b>O-TOLUIDINE</b>	17
2-Amino-1-methylbenzene	<b>O-TOLUIDINE</b>	17
<b>2-AMINO-2-METHYL-1-PROPANOL</b>		17
3-Aminomethyl-3,5,5-trimethylcyclohexylamine	<b>ISOPHORONEDIAMINE</b>	17
Aminophen	<b>ANILINE</b>	17
1-Aminopropane	<b>N-PROPYLAMINE</b>	17
2-Aminopropane	<b>ISOPROPYLAMINE</b>	17
2-Aminopropane (70% or less) solution	<b>ISOPROPYLAMINE (70% OR LESS) SOLUTION</b>	17
1-Amino-2-propanol	<b>ISOPROPANOLAMINE</b>	17
1-Aminopropan-2-ol	<b>ISOPROPANOLAMINE</b>	17
3-Aminopropan-1-ol	<b>N-PROPANOLAMINE</b>	17
2-Aminotoluene	<b>O-TOLUIDINE</b>	17
o-Aminotoluene	<b>O-TOLUIDINE</b>	17
5-Amino-1,3,3-trimethylcyclohexylmethylamine	<b>ISOPHORONEDIAMINE</b>	17
<b>AMMONIA AQUEOUS (28% OR LESS)</b>		17
Ammonia water, 28% or less	<b>AMMONIA AQUEOUS (28% OR LESS)</b>	17
<b>AMMONIUM CHLORIDE SOLUTION (LESS THAN 25%) (*)</b>		17
<b>AMMONIUM HYDROGEN PHOSPHATE SOLUTION</b>		17
Ammonium hydroxide, 28% or less	<b>AMMONIA AQUEOUS (28% OR LESS)</b>	17
<b>AMMONIUM LIGNOSULPHONATE SOLUTIONS</b>		17
<b>AMMONIUM NITRATE SOLUTION (93% OR LESS) (*)</b>		17
<b>AMMONIUM POLYPHOSPHATE SOLUTION</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>AMMONIUM SULPHATE SOLUTION</b>		17
<b>AMMONIUM SULPHIDE SOLUTION (45% OR LESS) (*)</b>		17
<b>AMMONIUM THIOSULPHATE SOLUTION (60% OR LESS)</b>		17
<b>AMYL ACETATE (ALL ISOMERS)</b>		17
Amyl acetate, commercial (a)	<b>AMYL ACETATE (ALL ISOMERS)</b>	17
n-Amyl acetate (a)	<b>AMYL ACETATE (ALL ISOMERS)</b>	17
sec-Amyl acetate (a)	<b>AMYL ACETATE (ALL ISOMERS)</b>	17
Amylacetic ester (a)	<b>AMYL ACETATE (ALL ISOMERS)</b>	17
Amyl alcohol	<b>N-AMYL ALCOHOL</b>	17
<b>N-AMYL ALCOHOL</b>		17
<b>AMYL ALCOHOL, PRIMARY</b>		17
<b>SEC-AMYL ALCOHOL</b>		17
<b>TERT-AMYL ALCOHOL</b>		17
Amyl aldehyde	<b>VALERALDEHYDE (ALL ISOMERS)</b>	17
Amylcarbinol	<b>HEXANOL</b>	17
Amylene hydrate	<b>TERT-AMYL ALCOHOL</b>	17
<b>TERT-AMYL ETHYL ETHER</b>		17
Amyl ethyl ketone	<b>ETHYL AMYL KETONE</b>	17
<b>TERT-AMYL METHYL ETHER</b>		17
n-Amyl methyl ketone	<b>METHYL AMYL KETONE</b>	17
n-Amyl propionate	<b>N-PENTYL PROPIONATE</b>	17
Anaesthetic ether	<b>DIETHYL ETHER (*)</b>	17
<b>ANILINE</b>		17
Aniline oil	<b>ANILINE</b>	17
Anilinobenzene	<b>DIPHENYLAMINE (MOLTEN)</b>	17
Anthracene oil (coal tar fraction) (a)	<b>COAL TAR</b>	17
Ant oil, artificial	<b>FURFURAL</b>	17
<b>APPLE JUICE</b>		18
Aqua fortis	<b>NITRIC ACID (70% AND OVER)</b>	17
Argilla	<b>KAOLIN SLURRY</b>	18
<b>ARYL POLYOLEFINS (C11-C50)</b>		17
<b>AVIATION ALKYLATES (C8 PARAFFINS AND ISO-PARAFFINS BPT 95 - 120°C)</b>		17
Azacycloheptane	<b>HEXAMETHYLENEIMINE</b>	17
3-Azapentane-1,5-diamine	<b>DIETHYLENTRIAMINE</b>	17
Azepane	<b>HEXAMETHYLENEIMINE</b>	17
Azotic acid	<b>NITRIC ACID (70% AND OVER)</b>	17
<b>BARIUM LONG CHAIN (C11-C50) ALKARYL SULPHONATE</b>		17
Basic calcium alkyl salicylate in approximately 30% mineral oil (b)	<b>CALCIUM LONG-CHAIN ALKYL SALICYLATE (C13+)</b>	17
Battery acid	<b>SULPHURIC ACID</b>	17
Behenyl alcohol (a)	<b>ALCOHOLS (C13+)</b>	17
Benzenamine	<b>ANILINE</b>	17
1,4-Benzenedicarboxylic acid, bis(2-ethylhexyl) ester	<b>BIS(2-ETHYLHEXYL) TEREPHTHALATE</b>	17
1,4-Benzenedicarboxylic acid, butyl ester	<b>DIBUTYL TEREPHTHALATE</b>	17
1,2-Benzenedicarboxylic acid, diethyl ester	<b>DIETHYL PHTHALATE</b>	17

Index Name	Product Name	Chapter
1,2-Benzenedicarboxylic acid, diundecyl ester	DIUNDECYL PHTHALATE	17
<b>BENZENE AND MIXTURES HAVING 10% BENZENE OR MORE (I)</b>		17
<b>BENZENE SULPHONYL CHLORIDE</b>		17
BENZENESULPHONYL CHLORIDE	BENZENE SULPHONYL CHLORIDE	17
<b>BENZENETRICARBOXYLIC ACID, TRIOCTYL ESTER</b>		17
Benzenol	PHENOL	17
Benzol	BENZENE AND MIXTURES HAVING 10% BENZENE OR MORE (I)	17
Benzole	BENZENE AND MIXTURES HAVING 10% BENZENE OR MORE (I)	17
Benzophenol	PHENOL	17
2-Benzothiazolethiol, sodium salt solution	MERCAPTOBENZOTHIAZOL, SODIUM SALT SOLUTION	17
Benzothiazole-2-thiol, sodium salt solution	MERCAPTOBENZOTHIAZOL, SODIUM SALT SOLUTION	17
(2-Benzothiazolylthio) sodium solution	MERCAPTOBENZOTHIAZOL, SODIUM SALT SOLUTION	17
<b>BENZYL ACETATE</b>		17
<b>BENZYL ALCOHOL</b>		17
Benzyl butyl phthalate	BUTYL BENZYL PHTHALATE	17
<b>BENZYL CHLORIDE</b>		17
Betaprone	BETA-PROPIOLACTONE	17
Betula oil	METHYL SALICYLATE	17
Biformyl	GLYOXAL SOLUTION (40% OR LESS)	17
<b>BIO-FUEL BLENDS OF DIESEL/GAS OIL AND FAME (&gt;25% BUT &lt;99% BY VOLUME)</b>		17
<b>BIO-FUEL BLENDS OF DIESEL/GAS OIL AND VEGETABLE OIL (&gt;25% BUT &lt;99% BY VOLUME)</b>		17
<b>BIO-FUEL BLENDS OF GASOLINE AND ETHYL ALCOHOL (&gt;25% BUT &lt;99% BY VOLUME)</b>		17
Biphenyl	DIPHENYL	17
Bis(methylcyclopentadiene)	METHYLCYCLOPENTADIENE DIMER	17
2,5-Bis(alkyl(C7+)thio)-1,3,4-thiadiazole	ALKYL DITHIOTHIAZADIAZOLE (C6-C24)	17
Bis(2-aminoethyl)amine	DIETHYLENETRIAMINE	17
N,N'-Bis(2-aminoethyl)ethane-1,2-diamine	TRIETHYLENETETRAMINE	17
N,N'-Bis(2-aminoethyl)ethylenediamine	TRIETHYLENETETRAMINE	17
N,N-Bis(2-(bis(carboxymethyl)amino)ethyl)glycine, pentasodium salt solution	DIETHYLENETRIAMINEPENTAACETIC ACID, PENTASODIUM SALT SOLUTION	17
Bis(2-butoxyethyl) ether	DIETHYLENE GLYCOL DIBUTYL ETHER	17
N,N- Bis(carboxymethyl)glycine trisodium salt solution	NITRILOTRIACETIC ACID, TRISODIUM SALT SOLUTION	17
Bis(chloroethyl) ether	DICHLOROETHYL ETHER	17
Bis(2-chloroethyl) ether	DICHLOROETHYL ETHER	17
Bis (2-chloroisopropyl) ether	2,2'-DICHLOROISOPROPYL ETHER	17
Bis(2-chloro-1-methylethyl) ether	2,2'-DICHLOROISOPROPYL ETHER	17
Bis[2-(2,3-epoxypropoxy)phenyl]methane	DIGLYCIDYL ETHER OF BISPHENOL F	17
2,2-Bis[4-(2,3-epoxypropoxy)phenyl]propane	DIGLYCIDYL ETHER OF BISPHENOL A	17
Bis(2-ethoxyethyl) ether	DIETHYLENE GLYCOL DIETHYL ETHER	17
Bis(2-ethylhexyl) adipate	DI-(2-ETHYLHEXYL) ADIPATE	17
Bis (2-ethylhexyl)-1-4-benzenedicarboxylate	BIS(2-ETHYLHEXYL) TEREPHTHALATE	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Bis(2-ethylhexyl) hydrogen phosphate	DI-(2-ETHYLHEXYL) PHOSPHORIC ACID	17
Bis(2-ethylhexyl) phthalate	DIOCTYL PHTHALATE	17
<b>BIS(2-ETHYLHEXYL) TEREPHTHALATE</b>		17
Bis(2-hydroxyethyl)amine	DIETHANOLAMINE	17
Bis(2-hydroxyethyl)ammonium 2,4-dichlorophenoxyacetate solution	2,4-DICHLOROPHENOXYACETIC ACID, DIETHANOLAMINE SALT SOLUTION	17
Bis(2-hydroxyethyl) ether	DIETHYLENE GLYCOL	17
Bis(2-hydroxypropyl)amine	DIISOPROPANOLAMINE	17
Bis(6-methylheptyl) phthalate	DIOCTYL PHTHALATE	17
Blackstrap molasses (a)	MOLASSES	18
Blend of propoxylated polyether polyols with >10% additives	GLUCITOL/GLYCEROL BLEND PROPOXYLATED (CONTAINING 10% OR MORE AMINES)	17
Bolus alba	KAOLIN SLURRY	18
<b>BRAKE FLUID BASE MIX: POLY(2-8)ALKYLENE (C2-C3) GLYCOLS/POLYALKYLENE (C2-C10) GLYCOLS MONOALKYL (C1-C4) ETHERS AND THEIR BORATE ESTERS</b>		17
Bran oil	FURFURAL	17
<b>BROMOCHLOROMETHANE</b>		17
Butaldehyde (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
Butanal (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
n-Butanal (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
1,3-Butanediol (a)	BUTYLENE GLYCOL	17
Butane-1,3-diol (a)	BUTYLENE GLYCOL	17
1,4-Butanediol (a)	BUTYLENE GLYCOL	17
Butane -1,4-diol (a)	BUTYLENE GLYCOL	17
2,3-Butanediol (a)	BUTYLENE GLYCOL	17
Butane-2,3-diol (a)	BUTYLENE GLYCOL	17
Butane, 2-ethoxy-2-methyl-ether	TERT-AMYL ETHYL ETHER	17
Butanoic acid	BUTYRIC ACID	17
Butanol	N-BUTYL ALCOHOL	18
1-Butanol	N-BUTYL ALCOHOL	18
Butanol-1	N-BUTYL ALCOHOL	18
Butan-1-ol	N-BUTYL ALCOHOL	18
2-Butanol	SEC-BUTYL ALCOHOL	18
Butan-2-ol	SEC-BUTYL ALCOHOL	18
Butanol acetate (a)	BUTYL ACETATE (ALL ISOMERS)	17
2-Butanol acetate (a)	BUTYL ACETATE (ALL ISOMERS)	17
1,4-Butanolide	GAMMA-BUTYROLACTONE	17
Butan-4-olide	GAMMA-BUTYROLACTONE	17
n-Butanol	N-BUTYL ALCOHOL	18
sec-Butanol	SEC-BUTYL ALCOHOL	18
tert-Butanol	TERT-BUTYL ALCOHOL	17
2-Butanone	METHYL ETHYL KETONE	17
Butan-2-one	METHYL ETHYL KETONE	17
2-Butenal	CROTONALDEHYDE	17
Butene dimer	OCTENE (ALL ISOMERS)	17
<b>BUTENE OLIGOMER</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
1-Butoxybutane	N-BUTYL ETHER	17
2-Butoxyethanol (a)	ETHYLENE GLYCOL MONOALKYL ETHERS	17
2-tert-butoxyethanol (a)	ETHYLENE GLYCOL MONOALKYL ETHERS	17
<b>2-BUTOXYETHANOL (58%)/HYPERBRANCHED POLYESTERAMIDE (42%) (MIXTURE)</b>		17
2-(2-Butoxyethoxy)ethanol (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
2-(2-Butoxyethoxy)ethyl acetate (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE	17
2-Butoxyethyl acetate	ETHYLENE GLYCOL BUTYL ETHER ACETATE	17
1-Butoxypropan-2-ol (a)	PROPYLENE GLYCOL MONOALKYL ETHER	17
Butyl acetate (a)	BUTYL ACETATE (ALL ISOMERS)	17
<b>BUTYL ACETATE (ALL ISOMERS)</b>		17
n-Butyl acetate (a)	BUTYL ACETATE (ALL ISOMERS)	17
sec-Butyl acetate (a)	BUTYL ACETATE (ALL ISOMERS)	17
tert-Butyl acetate (a)	BUTYL ACETATE (ALL ISOMERS)	17
<b>BUTYL ACRYLATE (ALL ISOMERS)</b>		17
n-Butyl acrylate (a)	BUTYL ACRYLATE (ALL ISOMERS)	17
Butyl alcohol	N-BUTYL ALCOHOL	18
<b>N-BUTYL ALCOHOL</b>		18
<b>SEC-BUTYL ALCOHOL</b>		18
<b>TERT-BUTYL ALCOHOL</b>		17
n-Butyl aldehyde (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
<b>BUTYLAMINE (ALL ISOMERS)</b>		17
n-Butylamine (a)	BUTYLAMINE (ALL ISOMERS)	17
sec-Butylamine (a)	BUTYLAMINE (ALL ISOMERS)	17
tert-Butylamine (a)	BUTYLAMINE (ALL ISOMERS)	17
<b>BUTYLBENZENE (ALL ISOMERS)</b>		17
tert-Butylbenzene (a)	BUTYLBENZENE (ALL ISOMERS)	17
<b>BUTYL BENZYL PHTHALATE</b>		17
Butyl butanoate (a)	BUTYL BUTYRATE (ALL ISOMERS)	17
<b>BUTYL BUTYRATE (ALL ISOMERS)</b>		17
n-Butyl butyrate (a)	BUTYL BUTYRATE (ALL ISOMERS)	17
n-Butylcarbinol	N-AMYL ALCOHOL	17
Butyl carbitol (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
Butyl carbitol acetate (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE	17
Butyl cellosolve acetate	ETHYLENE GLYCOL BUTYL ETHER ACETATE	17
<b>BUTYL/DECYL/CETYL/EICOSYL METHACRYLATE MIXTURE</b>		17
Butyl/decyl/hexadecyl/icosyl methacrylate mixture (a)	BUTYL/DECYL/CETYL/EICOSYL METHACRYLATE MIXTURE	17
Butyl diglycol acetate (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE	17
<b>BUTYLENE GLYCOL</b>		17
alpha-Butylene glycol (a)	BUTYLENE GLYCOL	17
beta-Butylene glycol (a)	BUTYLENE GLYCOL	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
1,3-Butylene glycol, 3-methyl ether	<b>3-METHOXY-1-BUTANOL</b>	17
1,3-Butylene glycol, 3-methyl ether, 1-acetate	<b>3-METHOXYBUTYL ACETATE</b>	17
Butylene oxide	<b>TETRAHYDROFURAN</b>	17
<b>1,2-BUTYLENE OXIDE</b>		17
Butyl ethanoate	<b>BUTYL ACETATE (ALL ISOMERS)</b>	17
Butyl ether	<b>N-BUTYL ETHER</b>	17
<b>N-BUTYL ETHER</b>		17
Butylethylacetic acid (a)	<b>OCTANOIC ACID (ALL ISOMERS)</b>	17
Butylethylene	<b>HEXENE (ALL ISOMERS)</b>	17
tert-Butyl ethyl ether	<b>ETHYL TERT-BUTYL ETHER</b>	17
iso-Butyl ketone	<b>DIISOBUTYL KETONE</b>	17
<b>BUTYL METHACRYLATE</b>		17
tert-Butyl methyl ether	<b>METHYL TERT-BUTYL ETHER</b>	17
Butyl methyl ketone	<b>METHYL BUTYL KETONE</b>	17
Butyl phthalate	<b>DIBUTYL PHTHALATE</b>	17
<b>N-BUTYL PROPIONATE</b>		17
<b>BUTYRALDEHYDE (ALL ISOMERS)</b>		17
n-Butyraldehyde	<b>BUTYRALDEHYDE (ALL ISOMERS)</b>	17
<b>BUTYRIC ACID</b>		17
n-Butyric acid	<b>BUTYRIC ACID</b>	17
Butyric alcohol	<b>N-BUTYL ALCOHOL</b>	18
Butyric aldehyde (a)	<b>BUTYRALDEHYDE (ALL ISOMERS)</b>	17
<b>GAMMA-BUTYROLACTONE</b>		17
Cajeputene	<b>DIPENTENE</b>	17
<b>CALCIUM ALKARYL SULPHONATE (C11-C50)</b>		17
Calcium alkyl(longchain) salicylate (overbased) in mineral oil (LOA) (b)	<b>CALCIUM LONG-CHAIN ALKYL SALICYLATE (C13+)</b>	17
<b>CALCIUM ALKYL (C10-C28) SALICYLATE</b>		17
Calcium bis(O-alkylsalicylate) (b)	<b>CALCIUM LONG-CHAIN ALKYL SALICYLATE (C13+)</b>	17
Calcium bromide / zinc bromide solution	<b>DRILLING BRINES (CONTAINING ZINC CHLORIDE)</b>	17
<b>CALCIUM CARBONATE SLURRY</b>		18
<b>CALCIUM HYDROXIDE SLURRY</b>		17
<b>CALCIUM HYPOCHLORITE SOLUTION (15% OR LESS)</b>		17
<b>CALCIUM HYPOCHLORITE SOLUTION (MORE THAN 15%)</b>		17
<b>CALCIUM LIGNOSULPHONATE SOLUTIONS</b>		17
<b>CALCIUM LONG-CHAIN ALKYL (C5-C10) PHENATE</b>		17
<b>CALCIUM LONG-CHAIN ALKYL (C11-C40) PHENATE</b>		17
<b>CALCIUM LONG-CHAIN ALKYL PHENATE SULPHIDE (C8-C40)</b>		17
<b>CALCIUM LONG-CHAIN ALKYL SALICYLATE (C13+)</b>		17
<b>CALCIUM LONG-CHAIN ALKYL (C18-C28) SALICYLATE</b>		17
<b>CALCIUM NITRATE/MAGNESIUM NITRATE/POTASSIUM CHLORIDE SOLUTION</b>		17
<b>CALCIUM NITRATE SOLUTIONS (50% OR LESS)</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>CAMELINA OIL</b>		17
Camelina Sativa Oil	<b>CAMELINA OIL</b>	17
Camelina Sativa Seed Oil	<b>CAMELINA OIL</b>	17
Cane molasses (a)	<b>MOLASSES</b>	18
Canola oil	<b>RAPESEED OIL (LOW ERUCIC ACID CONTAINING LESS THAN 4% FREE FATTY ACIDS)</b>	17
Capric acid	<b>DECANOIC ACID</b>	17
Caproic acid	<b>HEXANOIC ACID</b>	17
Caprolactam	<b>EPSILON-CAPROLACTAM (MOLTEN OR AQUEOUS SOLUTIONS)</b>	17
<b>EPSILON-CAPROLACTAM (MOLTEN OR AQUEOUS SOLUTIONS)</b>		17
Caproyl alcohol	<b>HEXANOL</b>	17
Capryl alcohol (a)	<b>OCTANOL (ALL ISOMERS)</b>	17
Caprylic acid (a)	<b>OCTANOIC ACID (ALL ISOMERS)</b>	17
Caprylyl acetate	<b>N-OCTYL ACETATE</b>	17
Carbamide solution	<b>UREA SOLUTION</b>	17
Carbinol	<b>METHYL ALCOHOL (*)</b>	17
Carbitol acetate (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE</b>	17
Carbitol solvent (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Carbolic acid	<b>PHENOL</b>	17
<b>CARBOLIC OIL</b>		17
Carbon bisulphide	<b>CARBON DISULPHIDE</b>	17
<b>CARBON DISULPHIDE</b>		17
<b>CARBON TETRACHLORIDE</b>		17
Carbonyldiamide solution	<b>UREA SOLUTION</b>	17
Carbonyldiamine solution	<b>UREA SOLUTION</b>	17
Carboxyethyliminobis(ethylenenitrilo)tetraacetic acid, pentasodium salt solution	<b>DIETHYLENETRIAMINEPENTAACETIC ACID, PENTASODIUM SALT SOLUTION</b>	17
<b>CASHEW NUT SHELL OIL (UNTREATED)</b>		17
<b>CASTOR OIL</b>		17
Caustic potash solution	<b>POTASSIUM HYDROXIDE SOLUTION (*)</b>	17
Caustic soda	<b>SODIUM HYDROXIDE SOLUTION (*)</b>	17
Caustic soda solution	<b>SODIUM HYDROXIDE SOLUTION (*)</b>	17
Cellosolve acetate	<b>2-ETHOXYETHYL ACETATE</b>	17
Cesium formate solution	<b>CESIUM FORMATE SOLUTION (*)</b>	17
<b>CESIUM FORMATE SOLUTION (*)</b>		17
<b>CETYL/EICOSYL METHACRYLATE MIXTURE</b>		17
Cetyl / stearyl alcohol (a)	<b>ALCOHOLS (C13+)</b>	17
China clay	<b>KAOLIN SLURRY</b>	18
<b>CHLORINATED PARAFFINS (C10-C13)</b>		17
<b>CHLORINATED PARAFFINS (C14-C17) (WITH 50% CHLORINE OR MORE, AND LESS THAN 1% C13 OR SHORTER CHAINS)</b>		17
<b>CHLOROACETIC ACID (80% OR LESS)</b>		17
alpha-Chloroallyl chloride	<b>1,3-DICHLOROPROPENE</b>	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Chloroallylene	ALLYL CHLORIDE	17
<b>CHLOROBENZENE</b>		17
Chlorobenzol	CHLOROBENZENE	17
Chlorobromomethane	BROMOCHLOROMETHANE	17
1-Chloro-2-(beta-chloroethoxy)ethane	DICHLOROETHYL ETHER	17
1-Chloro-2,3-epoxypropane	EPICHLOROHYDRIN	17
2-Chloroethanol	ETHYLENE CHLOROXYDRIN	17
2-Chloro-N-ethoxymethyl-6'-ethylacet-o-toluidide	ACETOCHLOR	17
2-Chloro-N-(ethoxymethyl)-N-(2-ethyl-6-methylphenyl)acetamide	ACETOCHLOR	17
2-Chloroethyl alcohol	ETHYLENE CHLOROXYDRIN	17
beta-Chloroethyl alcohol	ETHYLENE CHLOROXYDRIN	17
Chloroethyl ether	DICHLOROETHYL ETHER	17
2-Chloro-6'-ethyl-N-(2-methoxy-1-methylethyl)acet-o-toluidide	N-(2-METHOXY-1-METHYL ETHYL)-2-ETHYL-6-METHYL CHLOROACETANILIDE	17
2-Chloro-N-(2-ethyl-6-methylphenyl)-N-(2-methoxy-1-methylethyl)acetamide	N-(2-METHOXY-1-METHYL ETHYL)-2-ETHYL-6-METHYL CHLOROACETANILIDE	17
<b>CHLOROFORM</b>		17
<b>CHLOROXYDRINS (CRUDE)</b>		17
m-Chloromethylbenzene	M-CHLOROTOLUENE	17
o-Chloromethylbenzene	O-CHLOROTOLUENE	17
p-Chloromethylbenzene	P-CHLOROTOLUENE	17
(Chloromethyl)ethylene oxide	EPICHLOROXYDRIN	17
(2-Chloro-1-methylethyl) ether	2,2'-DICHLOROISOPROPYL ETHER	17
2-Chloro-1-methylethyl ether	2,2'-DICHLOROISOPROPYL ETHER	17
Chloromethyloxirane	EPICHLOROXYDRIN	17
<b>4-CHLORO-2-METHYLPHENOXYACETIC ACID, DIMETHYLAMINE SALT SOLUTION</b>		17
1-Chloro-2-nitrobenzene	O-CHLORONITROBENZENE	17
<b>O-CHLORONITROBENZENE</b>		17
<b>1-(4-CHLOROPHENYL)-4,4- DIMETHYL-PENTAN-3-ONE</b>		17
2- or 3- Chloropropanoic acid	2- OR 3-CHLOROPROPIONIC ACID	17
3-Chloropropene	ALLYL CHLORIDE	17
<b>2- OR 3-CHLOROPROPIONIC ACID</b>		17
alpha- or beta- Chloropropionic acid	2- OR 3-CHLOROPROPIONIC ACID	17
3-Chloropropylene	ALLYL CHLORIDE	17
alpha-Chloropropylene	ALLYL CHLORIDE	17
Chloropropylene oxide	EPICHLOROXYDRIN	17
<b>CHLOROSULPHONIC ACID</b>		17
Chlorosulphuric acid	CHLOROSULPHONIC ACID	17
3-Chlorotoluene	M-CHLOROTOLUENE	17
4-Chlorotoluene	P-CHLOROTOLUENE	17
alpha-Chlorotoluene	BENZYL CHLORIDE	17
<b>M-CHLOROTOLUENE</b>		17
<b>O-CHLOROTOLUENE</b>		17
<b>P-CHLOROTOLUENE</b>		17
<b>CHLOROTOLUENES (MIXED ISOMERS)</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>CHOLINE CHLORIDE SOLUTIONS</b>		17
Cinene	DIPENTENE	17
Cinnamene	STYRENE MONOMER	17
Cinnamol	STYRENE MONOMER	17
cis-Butenedioic anhydride	MALEIC ANHYDRIDE	17
cis-9-Octadecenoic acid	OLEIC ACID	17
<b>CITRIC ACID (70% OR LESS)</b>		17
<b>CLAY SLURRY</b>		18
<b>COAL SLURRY</b>		18
<b>COAL TAR</b>		17
Coal tar distillate	COAL TAR NAPHTHA SOLVENT	17
<b>COAL TAR NAPHTHA SOLVENT</b>		17
<b>COAL TAR PITCH (MOLTEN) (*)</b>		17
<b>COCOA BUTTER</b>		17
<b>COCONUT OIL</b>		17
<b>COCONUT OIL FATTY ACID</b>		17
<b>COCONUT OIL FATTY ACID METHYL ESTER</b>		17
Colamine	ETHANOLAMINE	17
Cold pressed grape seed oil	GRAPE SEED OIL	17
Cologne spirits	ETHYL ALCOHOL	18
Colonial spirit	METHYL ALCOHOL (*)	17
Colophony	ROSIN	17
Columbian spirit	METHYL ALCOHOL (*)	17
Columbian spirits	METHYL ALCOHOL (*)	17
<b>COPPER SALT OF LONG CHAIN (C17+) ALKANOIC ACID</b>		17
<b>CORN OIL</b>		17
<b>COTTON SEED OIL</b>		17
<b>CREOSOTE (COAL TAR)</b>		17
<b>CRESOL/PHENOL/XYLENOL MIXTURE</b>		17
<b>CRESOLS (ALL ISOMERS)</b>		17
<b>CRESYLIC ACID, DEPHENOLIZED</b>		17
Cresylic acids	CRESOLS (ALL ISOMERS)	17
<b>CRESYLIC ACID, SODIUM SALT SOLUTION</b>		17
Cresylols	CRESOLS (ALL ISOMERS)	17
<b>CROTONALDEHYDE</b>		17
Crotonic aldehyde	CROTONALDEHYDE	17
Crude grape seed oil	GRAPE SEED OIL	17
CTMP (Chemi Thermo Mechanical Pulp) concentrate	WOOD LIGNIN WITH SODIUM ACETATE/OXALATE	17
Cumene (a)	PROPYLBENZENE (ALL ISOMERS)	17
Cumol (a)	PROPYLBENZENE (ALL ISOMERS)	17
Cyanoethylene	ACRYLONITRILE	17
2-Cyanopropan-2-ol	ACETONE CYANOHYDRIN	17
2-Cyano-2-propanol	ACETONE CYANOHYDRIN	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
2-cyanopropene-1	METHACRYLONITRILE	17
Cyclic propylene carbonate	PROPYLENE CARBONATE	17
<b>1,5,9-CYCLODODECATRIENE</b>		17
<b>CYCLOHEPTANE</b>		17
Cyclohexamethylenimine	HEXAMETHYLENEIMINE	17
<b>CYCLOHEXANE</b>		17
<b>CYCLOHEXANE-1,2-DICARBOXYLIC ACID, DIISONONYL ESTER</b>		17
Cyclohexane 1,2-Di-Isononyldicarboxylate	CYCLOHEXANE-1,2-DICARBOXYLIC ACID, DIISONONYL ESTER	17
<b>CYCLOHEXANE OXIDATION PRODUCTS, SODIUM SALTS SOLUTION</b>		17
Cyclohexane, oxidized, aqueous extraction, sodium salt	CYCLOHEXANE OXIDATION PRODUCTS, SODIUM SALTS SOLUTION	17
<b>CYCLOHEXANOL</b>		17
<b>CYCLOHEXANONE</b>		17
<b>CYCLOHEXANONE, CYCLOHEXANOL MIXTURE</b>		17
Cyclohexatriene	BENZENE AND MIXTURES HAVING 10% BENZENE OR MORE (I)	17
<b>CYCLOHEXYL ACETATE</b>		17
<b>CYCLOHEXYLAMINE</b>		17
Cyclohexyldimethylamine	N,N-DIMETHYLCYCLOHEXYLAMINE	17
Cyclohexyl(ethyl)amine	N-ETHYLCYCLOHEXYLAMINE	17
Cyclohexyl(ethyl)amine	N-ETHYLCYCLOHEXYLAMINE	17
Cyclohexyl ketone	CYCLOHEXANONE	17
Cyclohexylmethane	METHYLCYCLOHEXANE	17
<b>1,3-CYCLOPENTADIENE DIMER (MOLTEN)</b>		17
<b>CYCLOPENTANE</b>		17
<b>CYCLOPENTENE</b>		17
Cyclotetramethylene oxide	TETRAHYDROFURAN	17
<b>P-CYMENE</b>		17
Cymol	P-CYMENE	17
Dalapon (ISO)	2,2-DICHLOROPROPIONIC ACID	17
DCCP	DICYCLOPENTADIENE, RESIN GRADE, 81-89%	17
Deanol	DIMETHYLETHANOLAMINE	17
<b>DECAHYDRONAPHTHALENE</b>		17
<b>DECANOIC ACID</b>		17
Decan-1-ol	DECYL ALCOHOL (ALL ISOMERS)	17
n-Decanol	DECYL ALCOHOL (ALL ISOMERS)	17
Decatoic acid	DECANOIC ACID	17
<b>DECENE</b>		17
Decoic acid	DECANOIC ACID	17
<b>DECYL ACRYLATE</b>		17
Decyl alcohol	DECYL ALCOHOL (ALL ISOMERS)	17
<b>DECYL ALCOHOL (ALL ISOMERS)</b>		17
Decylbenzene (a)	ALKYL(C9+)BENZENES	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>DECYL/DODECYL/TETRADECYL ALCOHOL MIXTURE</b>		17
Decylic acid	<b>DECANOIC ACID</b>	17
Decyl octyl adipate	<b>OCTYL DECYL ADIPATE</b>	17
<b>DECYLOXYTETRAHYDROTHIOPHENE DIOXIDE</b>		17
Degummed grape seed oil	<b>GRAPE SEED OIL</b>	17
1-Deoxy-1-methylamino-D-glucitol solution (70% or less)	<b>N-METHYLGLUCAMINE SOLUTION (70% OR LESS)</b>	17
Detergent alkylate	<b>ALKYL(C9+)BENZENES</b>	17
Diacetic ester	<b>ETHYL ACETOACETATE</b>	17
Diacetone	<b>DIACETONE ALCOHOL</b>	17
<b>DIACETONE ALCOHOL</b>		17
Di[alkyl/alkenyl(C10-C20)] hydrogen phosphite (a)	<b>ALKYL (C10-C20, SATURATED AND UNSATURATED) PHOSPHITE</b>	17
<b>DIALKYL (C8-C9) DIPHENYLAMINES</b>		17
<b>DIALKYL (C7-C13) PHTHALATES</b>		17
<b>DIALKYL (C9 - C10) PHTHALATES</b>		17
<b>DIALKYL THIOPHOSPHATES SODIUM SALTS SOLUTION</b>		17
1,2-Diaminoethane	<b>ETHYLENEDIAMINE</b>	17
1,6-Diaminohexane	<b>HEXAMETHYLENEDIAMINE (MOLTEN)</b>	17
1,6-Diaminohexane solutions	<b>HEXAMETHYLENEDIAMINE SOLUTION</b>	17
2,6-Diaminohexanoic acid	<b>L-LYSINE SOLUTION (60% OR LESS)</b>	17
<b>2,6-DIAMINOHEXANOIC ACID PHOSPHONATE MIXED SALTS SOLUTION</b>		17
Diaminotoluene (a)	<b>TOLUENEDIAMINE</b>	17
2,4-Diaminotoluene (a)	<b>TOLUENEDIAMINE</b>	17
2,6-Diaminotoluene (a)	<b>TOLUENEDIAMINE</b>	17
3,6-Diazaoctane-1,8-diamine	<b>TRIETHYLENETETRAMINE</b>	17
1,2-Dibromoethane	<b>ETHYLENE DIBROMIDE</b>	17
<b>DIBROMOMETHANE</b>		17
2,2'-Dibutoxyethyl ether	<b>DIETHYLENE GLYCOL DIBUTYL ETHER</b>	17
<b>DIBUTYLAMINE</b>		17
Dibutylbenzene-1,2-dicarboxylate	<b>DIBUTYL PHTHALATE</b>	17
Dibutyl carbinol (a)	<b>NONYL ALCOHOL (ALL ISOMERS)</b>	17
Dibutyl ether	<b>N-BUTYL ETHER</b>	17
n-Dibutyl ether	<b>N-BUTYL ETHER</b>	17
Dibutyl hydrogen phosphite	<b>DIBUTYL HYDROGEN PHOSPHONATE</b>	17
<b>DIBUTYL HYDROGEN PHOSPHONATE</b>		17
<b>2,6-DI-TERT-BUTYLPHENOL</b>		17
Dibutyl phosphonate	<b>DIBUTYL HYDROGEN PHOSPHONATE</b>	17
<b>DIBUTYL PHTHALATE</b>		17
Dibutyl ortho-phthalate	<b>DIBUTYL PHTHALATE</b>	17
<b>DIBUTYL TEREPHTHALATE</b>		17
<b>DICHLOROBENZENE (ALL ISOMERS)</b>		17
1,2-Dichlorobenzene (a)	<b>DICHLOROBENZENE (ALL ISOMERS)</b>	17
m-Dichlorobenzene (a)	<b>DICHLOROBENZENE (ALL ISOMERS)</b>	17
o-Dichlorobenzene (a)	<b>DICHLOROBENZENE (ALL ISOMERS)</b>	17

Index Name	Product Name	Chapter
3,4-Dichlorobut-1-ene	3,4-DICHLORO-1-BUTENE	17
<b>3,4-DICHLORO-1-BUTENE</b>		17
2,2'-Dichlorodiethyl ether	DICHLOROETHYL ETHER	17
Dichlorodiisopropyl ether	2,2'-DICHLOROISOPROPYL ETHER	17
<b>1,1-DICHLOROETHANE</b>		17
1,2-Dichloroethane	ETHYLENE DICHLORIDE	17
1,1-Dichloroethene	VINYLDENE CHLORIDE	17
Dichloroether	DICHLOROETHYL ETHER	17
1,1-Dichloroethylene	VINYLDENE CHLORIDE	17
<b>DICHLOROETHYL ETHER</b>		17
2,2'-Dichloroethyl ether	DICHLOROETHYL ETHER	17
Dichloroethyl oxide	DICHLOROETHYL ETHER	17
<b>1,6-DICHLOROHEXANE</b>		17
<b>2,2'-DICHLOROISOPROPYL ETHER</b>		17
<b>DICHLOROMETHANE</b>		17
<b>2,4-DICHLOROPHENOL</b>		17
<b>2,4-DICHLOROPHENOXYACETIC ACID, DIETHANOLAMINE SALT SOLUTION</b>		17
<b>2,4-DICHLOROPHENOXYACETIC ACID, DIMETHYLAMINE SALT SOLUTION (70% OR LESS)</b>		17
<b>2,4-DICHLOROPHENOXYACETIC ACID, TRIISOPROPANOLAMINE SALT SOLUTION</b>		17
<b>1,1-DICHLOROPROPANE</b>		17
<b>1,2-DICHLOROPROPANE</b>		17
Dichloropropane / dichloropropene mixtures	DICHLOROPROPENE/DICHLOROPROPANE MIXTURES	17
2,2-Dichloropropanoic acid	2,2-DICHLOROPROPIONIC ACID	17
<b>1,3-DICHLOROPROPENE</b>		17
<b>DICHLOROPROPENE/DICHLOROPROPANE MIXTURES</b>		17
<b>2,2-DICHLOROPROPIONIC ACID</b>		17
Dichloropropylene	1,3-DICHLOROPROPENE	17
1,4-Dicyanobutane	ADIPONITRILE	17
Dicyclopentadiene	1,3-CYCLOPENTADIENE DIMER (MOLTEN)	17
<b>DICYCLOPENTADIENE, RESIN GRADE, 81-89%</b>		17
Didecyl phthalate (a)	DIALKYL (C7-C13) PHTHALATES	17
Didodecyl phthalate (a)	DIALKYL (C7-C13) PHTHALATES	17
<b>DIETHANOLAMINE</b>		17
<b>DIETHYLAMINE</b>		17
<b>DIETHYLAMINOETHANOL</b>		17
2-Diethylaminoethanol	DIETHYLAMINOETHANOL	17
<b>2,6-DIETHYLANILINE</b>		17
<b>DIETHYLBENZENE</b>		17
Diethyl 'carbitol'	DIETHYLENE GLYCOL DIETHYL ETHER	17
Diethylene dioxide	1,4-DIOXANE	17
1,4-Diethylene dioxide	1,4-DIOXANE	17
Diethylene ether	1,4-DIOXANE	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>DIETHYLENE GLYCOL</b>		17
Diethylene glycol butyl ether (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Diethylene glycol butyl ether acetate (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE</b>	17
<b>DIETHYLENE GLYCOL DIBUTYL ETHER</b>		17
<b>DIETHYLENE GLYCOL DIETHYL ETHER</b>		17
Diethylene glycol ethyl ether (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Diethylene glycol ethyl ether acetate (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE</b>	17
Diethylene glycol methyl ether (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Diethylene glycol methyl ether acetate (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE</b>	17
Diethylene glycol monobutyl ether (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Diethylene glycol monobutyl ether acetate (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE</b>	17
Diethylene glycol monoethyl ether (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Diethylene glycol monoethyl ether acetate (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE</b>	17
Diethylene glycol monomethyl ether (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Diethylene glycol monomethyl ether acetate (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE</b>	17
<b>DIETHYLENE GLYCOL PHTHALATE</b>		17
<b>DIETHYLENTRIAMINE</b>		17
<b>DIETHYLENTRIAMINEPENTAACETIC ACID, PENTASODIUM SALT SOLUTION</b>		17
N,N-Diethylethanamine	<b>TRIETHYLAMINE</b>	17
N,N-Diethylethanolamine	<b>DIETHYLAMINOETHANOL</b>	17
<b>DIETHYL ETHER (*)</b>		17
<b>DI-(2-ETHYLHEXYL) ADIPATE</b>		17
<b>DI-(2-ETHYLHEXYL) PHOSPHORIC ACID</b>		17
Di (2-ethylhexyl) Terephthalate	<b>BIS(2-ETHYLHEXYL) TEREPHTHALATE</b>	17
Diethyl oxide	<b>DIETHYL ETHER (*)</b>	17
<b>DIETHYL PHTHALATE</b>		17
<b>DIETHYL SULPHATE</b>		17
Diformyl	<b>GLYOXAL SOLUTION (40% OR LESS)</b>	17
<b>DIGLYCIDYL ETHER OF BISPHENOL A</b>		17
<b>DIGLYCIDYL ETHER OF BISPHENOL F</b>		17
Diglycol	<b>DIETHYLENE GLYCOL</b>	17
Diglycolamine	<b>2-(2-AMINOETHOXY) ETHANOL</b>	17
Diglycol phthalate	<b>DIETHYLENE GLYCOL PHTHALATE</b>	17
<b>DIHEPTYL PHTHALATE</b>		17
<b>DI-N-HEXYL ADIPATE</b>		17
<b>DIHEXYL PHTHALATE</b>		17
1,3-Dihydroisobenzofuran-1,3-dione (molten)	<b>PHTHALIC ANHYDRIDE (MOLTEN)</b>	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
2,3-Dihydroxybutane (a)	BUTYLENE GLYCOL	17
2,2'-Dihydroxydiethylamine	DIETHANOLAMINE	17
Di-(2-hydroxyethyl)amine	DIETHANOLAMINE	17
Dihydroxyethyl ether	DIETHYLENE GLYCOL	17
1,6-Dihydroxyhexane	HEXAMETHYLENE GLYCOL	17
1,2-Dihydroxypropane	PROPYLENE GLYCOL	18
Diisobutene	DIISOBUTYLENE	17
<b>DIISOBUTYLAMINE</b>		17
Diisobutylcarbinol (a)	NONYL ALCOHOL (ALL ISOMERS)	17
<b>DIISOBUTYLENE</b>		17
alpha-Diisobutylene (a)	DIISOBUTYLENE	17
beta-Diisobutylene (a)	DIISOBUTYLENE	17
<b>DIISOBUTYL KETONE</b>		17
<b>DIISOBUTYL PHTHALATE</b>		17
2,4-diisocyanato-1-methylbenzene	TOLUENE DIISOCYANATE	17
2,4-Diisocyanatotoluene	TOLUENE DIISOCYANATE	17
Diisodecyl phthalate (a)	DIALKYL (C7-C13) PHTHALATES	17
<b>DIISONONYL ADIPATE</b>		17
Diisononyl phthalate (a)	DIALKYL (C7-C13) PHTHALATES	17
<b>DIISOCTYL PHTHALATE</b>		17
<b>DIISOPROPANOLAMINE</b>		17
<b>DIISOPROPYLAMINE</b>		17
<b>DIISOPROPYLBENZENE (ALL ISOMERS)</b>		17
Diisopropyl ether	ISOPROPYL ETHER	17
<b>DIISOPROPYLNAPHTHALENE</b>		17
Diisopropyl oxide	ISOPROPYL ETHER	17
<b>N,N-DIMETHYLACETAMIDE</b>		17
<b>N,N-DIMETHYLACETAMIDE SOLUTION (40% OR LESS)</b>		17
Dimethylacetylene carbinol	2-METHYL-2-HYDROXY-3-BUTYNE	17
<b>DIMETHYL ADIPATE</b>		17
<b>DIMETHYLAMINE SOLUTION (45% OR LESS)</b>		17
<b>DIMETHYLAMINE SOLUTION (GREATER THAN 45% BUT NOT GREATER THAN 55%)</b>		17
<b>DIMETHYLAMINE SOLUTION (GREATER THAN 55% BUT NOT GREATER THAN 65%)</b>		17
Dimethylaminoethanol	DIMETHYLETHANOLAMINE	17
2-(Dimethylamino)ethanol	DIMETHYLETHANOLAMINE	17
Dimethylbenzenes	XYLENES	17
1,3-Dimethylbutanol	METHYLAMYL ALCOHOL	17
1,3-Dimethylbutan-1-ol	METHYLAMYL ALCOHOL	17
1,3-Dimethylbutyl acetate (a)	METHYLAMYL ACETATE	17
Dimethylcarbinol	ISOPROPYL ALCOHOL	18
<b>N,N-DIMETHYLCYCLOHEXYLAMINE</b>		17
<b>DIMETHYL DISULPHIDE</b>		17
N,N-Dimethyldodecanamine	N,N-DIMETHYLDODECYLAMINE	17

Index Name	Product Name	Chapter
N,N-Dimethyldodecan-1-amine	N,N-DIMETHYLDODECYLAMINE	17
<b>N,N-DIMETHYLDODECYLAMINE</b>		17
1,1-Dimethylethanol	TERT-BUTYL ALCOHOL	17
<b>DIMETHYLETHANOLAMINE</b>		17
1,1-Dimethylethyl alcohol	TERT-BUTYL ALCOHOL	17
Dimethyl ethyl carbinol	TERT-AMYL ALCOHOL	17
1,1-dimethylethyl methyl ether	METHYL TERT-BUTYL ETHER	17
Dimethylformaldehyde	ACETONE	18
<b>DIMETHYLFORMAMIDE</b>		17
<b>DIMETHYL GLUTARATE</b>		17
2,6-Dimethyl-4-heptanone	DIISOBUTYL KETONE	17
2,6-Dimethylheptan-4-one	DIISOBUTYL KETONE	17
N,N-Dimethylhexanamine (a)	ALKYL (C12+) DIMETHYLAMINE	17
<b>DIMETHYL HYDROGEN PHOSPHITE</b>		17
Dimethylhydroxybenzenes (all isomers)	XYLENOL	17
1,1'-Dimethyl-2,2'-iminodiethanol	DIISOPROPANOLAMINE	17
Dimethyl ketal	ACETONE	18
Dimethyl ketone	ACETONE	18
N,N-dimethylaurylamine	N,N-DIMETHYLDODECYLAMINE	17
N,N-Dimethylmethanamine solution (30% or less)	TRIMETHYLAMINE SOLUTION (30% OR LESS)	17
6,6-Dimethyl-2-methylenebicyclo[3.1.1]heptane	BETA-PINENE	17
<b>DIMETHYL OCTANOIC ACID</b>		17
2,2-Dimethyloctanoic acid (a)	NEODECANOIC ACID	17
2,3-Dimethylphenol (a)	XYLENOL	17
2,4-Dimethylphenol (a)	XYLENOL	17
2,5-Dimethylphenol (a)	XYLENOL	17
2,6-Dimethylphenol (a)	XYLENOL	17
3,4-Dimethylphenol (a)	XYLENOL	17
3,5-Dimethylphenol (a)	XYLENOL	17
Dimethylphenols	XYLENOL	17
Dimethylphenyl phosphate (3:1) (all isomers)	TRIXYLYL PHOSPHATE	17
<b>DIMETHYL PHTHALATE</b>		17
<b>DIMETHYLPOLYSILOXANE</b>		17
2,2-Dimethylpropane (a)	PENTANE (ALL ISOMERS)	17
<b>2,2-DIMETHYLPROPANE-1,3-DIOL (MOLTEN OR SOLUTION)</b>		17
2,2-Dimethylpropanoic acid	TRIMETHYLACETIC ACID	17
1,1-Dimethylpropargyl alcohol	2-METHYL-2-HYDROXY-3-BUTYNE	17
2,2-Dimethylpropionic acid	TRIMETHYLACETIC ACID	17
1,1-Dimethylpropyl ethyl ether	TERT-AMYL ETHYL ETHER	17
1,1-Dimethylpropynol	2-METHYL-2-HYDROXY-3-BUTYNE	17
<b>DIMETHYL SUCCINATE</b>		17
N,N-Dimethyltetradecanamine (a)	ALKYL (C12+) DIMETHYLAMINE	17
Dimethyl(tetradecyl)amine (a)	ALKYL (C12+) DIMETHYLAMINE	17
3,9-Dimethyltricyclo[5.2.1.0 <sup>2,6</sup> ]deca-3,9-diene	METHYLCYCLOPENTADIENE DIMER	17
Dimethyltrimethylene glycol	2,2-DIMETHYLPROPANE-1,3-DIOL (MOLTEN OR SOLUTION)	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>DINITROTOLUENE (MOLTEN)</b>		17
<b>DINONYL PHTHALATE</b>		17
Dinonyl phthalate (a)	<b>DIALKYL (C7-C13) PHTHALATES</b>	17
3,6-Dioxaoctane-1,8-diol	<b>TRIETHYLENE GLYCOL</b>	18
Diocetyl adipate	<b>DI-(2-ETHYLHEXYL) ADIPATE</b>	17
Diocetyl hydrogen phosphate	<b>DI-(2-ETHYLHEXYL) PHOSPHORIC ACID</b>	17
Diocetyl phosphoric acid	<b>DI-(2-ETHYLHEXYL) PHOSPHORIC ACID</b>	17
<b>DIOCTYL PHTHALATE</b>		17
Diocetyl terephthalate	<b>BIS(2-ETHYLHEXYL) TEREPHTHALATE</b>	17
2,4-D-diolamine	<b>2,4-DICHLOROPHENOXYACETIC ACID, DIETHANOLAMINE SALT SOLUTION</b>	17
1,4-Dioxan	<b>1,4-DIOXANE</b>	17
<b>1,4-DIOXANE</b>		17
1,3-Dioxolan-2-one	<b>ETHYLENE CARBONATE</b>	17
Dioxolone-2	<b>ETHYLENE CARBONATE</b>	17
1,1-Dioxothiolan	<b>SULPHOLANE</b>	17
Dioxyethylene ether	<b>1,4-DIOXANE</b>	17
<b>DIPENTENE</b>		17
<b>DIPHENYL</b>		17
<b>DIPHENYLAMINE (MOLTEN)</b>		17
<b>DIPHENYLAMINE, REACTION PRODUCT WITH 2,2,4-TRIMETHYLPENTENE</b>		17
<b>DIPHENYLAMINES, ALKYLATED</b>		17
<b>DIPHENYL/DIPHENYL ETHER MIXTURES</b>		17
Diphenyl/diphenyl oxide mixtures	<b>DIPHENYL/DIPHENYL ETHER MIXTURES</b>	17
Diphenyl dodecyl ether disulphonate solution	<b>DODECYL DIPHENYL ETHER DISULPHONATE SOLUTION</b>	17
Diphenyl dodecyl oxide disulphonate solution	<b>DODECYL DIPHENYL ETHER DISULPHONATE SOLUTION</b>	17
<b>DIPHENYL ETHER</b>		17
<b>DIPHENYL ETHER/DIPHENYL PHENYL ETHER MIXTURE</b>		17
<b>DIPHENYLMETHANE DIISOCYANATE</b>		17
<b>DIPHENYLOL PROPANE-EPICHLOROHYDRIN RESINS</b>		17
Diphenyl oxide	<b>DIPHENYL ETHER</b>	17
Diphenyl oxide / diphenyl phenyl ether mixture	<b>DIPHENYL ETHER/DIPHENYL PHENYL ETHER MIXTURE</b>	17
Dipropylamine	<b>DI-N-PROPYLAMINE</b>	17
n-Dipropylamine	<b>DI-N-PROPYLAMINE</b>	17
<b>DI-N-PROPYLAMINE</b>		17
<b>DIPROPYLENE GLYCOL</b>		17
Dipropylene glycol methyl ether (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Dipropylene glycol monomethyl ether (a)	<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>	17
Disodium carbonate solution	<b>SODIUM CARBONATE SOLUTION (*)</b>	17
Distillates (Petroleum), Steam Cracked, C8 - C12 Fraction (a)	<b>RESIN OIL, DISTILLED</b>	17
<b>DITHIOCARBAMATE ESTER (C7-C35)</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>DITRIDECYL ADIPATE</b>		17
<b>DITRIDECYL PHTHALATE</b>		17
<b>DIUNDECYL PHTHALATE</b>		17
dl-Lactic acid	<b>LACTIC ACID</b>	17
dl-p-Mentha-1,8-diene	<b>DIPENTENE</b>	17
1-Docosanol (a)	<b>ALCOHOLS (C13+)</b>	17
Docosan-1-ol (a)	<b>ALCOHOLS (C13+)</b>	17
<b>DODECANE (ALL ISOMERS)</b>		17
1-Dodecanethiol	<b>N-DODECYL MERCAPTAN</b>	17
<b>TERT-DODECANETHIOL</b>		17
Dodecanoic acid	<b>LAURIC ACID</b>	17
1-Dodecanol	<b>DODECYL ALCOHOL</b>	17
Dodecan-1-ol	<b>DODECYL ALCOHOL</b>	17
n-Dodecanol	<b>DODECYL ALCOHOL</b>	17
<b>DODECENE (ALL ISOMERS)</b>		17
<b>1-DODECENE</b>		17
Dodec-1-ene	<b>1-DODECENE</b>	17
<b>DODECYL ALCOHOL</b>		17
n-Dodecyl alcohol	<b>DODECYL ALCOHOL</b>	17
<b>DODECYLAMINE/TETRADECYLAMINE MIXTURE</b>		17
<b>DODECYLBENZENE</b>		17
Dodecylbenzenesulphonic acid (contains 1.5% sulphuric acid)	<b>ALKYL (C11-C17) BENZENE SULPHONIC ACID</b>	17
Dodecyldimethylamine	<b>N,N-DIMETHYLDODECYLAMINE</b>	17
<b>DODECYL DIPHENYL ETHER DISULPHONATE SOLUTION</b>		17
Dodecyl diphenyl oxide disulphonate solution	<b>DODECYL DIPHENYL ETHER DISULPHONATE SOLUTION</b>	17
Dodecylene	<b>DODECENE (ALL ISOMERS)</b>	17
<b>DODECYL HYDROXYPROPYL SULPHIDE</b>		17
Dodecylic acid	<b>LAURIC ACID</b>	17
<b>N-DODECYL MERCAPTAN</b>		17
tert-Dodecyl mercaptan	<b>TERT-DODECANETHIOL</b>	17
<b>DODECYL METHACRYLATE</b>		17
Dodecyl 2-methylprop-2-enoate	<b>DODECYL METHACRYLATE</b>	17
Dodecyl-2-methyl-2-propenoate	<b>DODECYL METHACRYLATE</b>	17
<b>DODECYL/OCTADECYL METHACRYLATE MIXTURE</b>		17
<b>DODECYL/PENTADECYL METHACRYLATE MIXTURE</b>		17
<b>DODECYL PHENOL</b>		17
Dodecyl, Tetradecyl, hexadecyl-dimethylamine mixture	<b>ALKYL (C12+) DIMETHYLAMINE</b>	17
2-Dodecylthio-1-methylethanol	<b>DODECYL HYDROXYPROPYL SULPHIDE</b>	17
1-(Dodecylthio)propan-2-ol	<b>DODECYL HYDROXYPROPYL SULPHIDE</b>	17
<b>DODECYL XYLENE</b>		17
Drilling brine: potassium chloride solution	<b>POTASSIUM CHLORIDE SOLUTION</b>	17
<b>DRILLING BRINES (CONTAINING CALCIUM BROMIDE)</b>		17
<b>DRILLING BRINES (CONTAINING ZINC CHLORIDE)</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
(E)-But-2-enal	CROTONALDEHYDE	17
Enanthic acid	N-HEPTANOIC ACID	17
Enanthylic acid	N-HEPTANOIC ACID	17
Engravers' acid	NITRIC ACID (70% AND OVER)	17
<b>EPICHLOROHYDRIN</b>		17
1,2-Epoxybutane	1,2-BUTYLENE OXIDE	17
1,4-epoxybutane	TETRAHYDROFURAN	17
1,2-Epoxypropane	PROPYLENE OXIDE	17
2,3-Epoxypropyl ester of mixed C10 trialkylacetic acids	GLYCIDYL ESTER OF C10 TRIALKYLACETIC ACID	17
2,3-Epoxypropyl neodecanoate	GLYCIDYL ESTER OF C10 TRIALKYLACETIC ACID	17
EPTC	S-ETHYL DIPROPYLTHIOCARBAMATE	17
Essence of Mirbane	NITROBENZENE	17
Essence of Myrbane	NITROBENZENE	17
Ethanamine solutions, 72% or less	ETHYLAMINE SOLUTIONS (72% OR LESS)	17
Ethancarbonitrile	PROPIONITRILE	17
Ethanedial	GLYOXAL SOLUTION (40% OR LESS)	17
1,2-Ethanediol	ETHYLENE GLYCOL	17
Ethanoic acid	ACETIC ACID	17
Ethanoic anhydride	ACETIC ANHYDRIDE	17
Ethanol	ETHYL ALCOHOL	18
<b>ETHANOLAMINE</b>		17
ethenyl acetate	VINYL ACETATE	17
ethenyl ethanoate	VINYL ACETATE	17
Ether	DIETHYL ETHER (*)	17
Ethinyl trichloride	TRICHLOROETHYLENE	17
2-Ethoxyethanol (a)	ETHYLENE GLYCOL MONOALKYL ETHERS	17
2-(2-Ethoxyethoxy)ethanol (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
2-(2-Ethoxyethoxy)ethyl acetate (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER ACETATE	17
<b>2-ETHOXYETHYL ACETATE</b>		17
<b>ETHOXYLATED LONG CHAIN (C16+) ALKYOXYALKYLAMINE</b>		17
<b>ETHOXYLATED TALLOW AMINE (&gt; 95%)</b>		17
2-Ethoxy-2-methylpropane	ETHYL TERT-BUTYL ETHER	17
1-Ethoxypropan-2-ol (a)	PROPYLENE GLYCOL MONOALKYL ETHER	17
<b>ETHYL ACETATE</b>		17
<b>ETHYL ACETOACETATE</b>		17
Ethyl acetone	METHYL PROPYL KETONE	17
<b>ETHYL ACRYLATE</b>		17
<b>ETHYL ALCOHOL</b>		18
<b>ETHYLAMINE (*)</b>		17
<b>ETHYLAMINE SOLUTIONS (72% OR LESS)</b>		17
Ethylaminocyclohexane	N-ETHYLCYCLOHEXYLAMINE	17
<b>ETHYL AMYL KETONE</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>ETHYLBENZENE</b>		17
Ethyl benzol	<b>ETHYLBENZENE</b>	17
Ethyl butanoate	<b>ETHYL BUTYRATE</b>	17
<b>ETHYL TERT-BUTYL ETHER</b>		17
<b>ETHYL BUTYRATE</b>		17
2-Ethylcaproic acid	<b>2-ETHYLHEXANOIC ACID</b>	17
Ethyl carbinol	<b>N-PROPYL ALCOHOL</b>	17
Ethyl cyanide	<b>PROPIONITRILE</b>	17
<b>ETHYLCYCLOHEXANE</b>		17
<b>N-ETHYLCYCLOHEXYLAMINE</b>		17
Ethyldimethylmethane (a)	<b>PENTANE (ALL ISOMERS)</b>	17
S-Ethyl dipropylcarbamoithioate	<b>S-ETHYL DIPROPYLTHIOCARBAMATE</b>	17
<b>S-ETHYL DIPROPYLTHIOCARBAMATE</b>		17
Ethylene alcohol	<b>ETHYLENE GLYCOL</b>	17
Ethylene bis(iminodiacetic acid) tetrasodium salt solution	<b>ETHYLENEDIAMINETETRAACETIC ACID, TETRASODIUM SALT SOLUTION</b>	17
Ethylene bromide	<b>ETHYLENE DIBROMIDE</b>	17
<b>ETHYLENE CARBONATE</b>		17
Ethylenecarboxylic acid	<b>ACRYLIC ACID</b>	17
Ethylene chloride	<b>ETHYLENE DICHLORIDE</b>	17
<b>ETHYLENE CHLOROHYDRIN</b>		17
<b>ETHYLENE CYANOHYDRIN</b>		17
Ethylene diacetate	<b>ETHYLENE GLYCOL DIACETATE</b>	17
<b>ETHYLENEDIAMINE</b>		17
<b>ETHYLENEDIAMINETETRAACETIC ACID, TETRASODIUM SALT SOLUTION</b>		17
<b>ETHYLENE DIBROMIDE</b>		17
<b>ETHYLENE DICHLORIDE</b>		17
Ethylenedinitrotetraacetic acid tetrasodium salt solution	<b>ETHYLENEDIAMINETETRAACETIC ACID, TETRASODIUM SALT SOLUTION</b>	17
2,2'-Ethylenedioxydiethanol	<b>TRIETHYLENE GLYCOL</b>	18
<b>ETHYLENE GLYCOL</b>		17
<b>ETHYLENE GLYCOL ACETATE</b>		17
Ethylene glycol acrylate	<b>2-HYDROXYETHYL ACRYLATE</b>	17
Ethylene glycol butyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
<b>ETHYLENE GLYCOL BUTYL ETHER ACETATE</b>		17
Ethylene glycol n-butyl ether (58%)/ Hyperbranched polyesteramide (42%)	<b>2-BUTOXYETHANOL (58%)/HYPERBRANCHED POLYESTERAMIDE (42%) (MIXTURE)</b>	17
Ethylene glycol tert-butyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
<b>ETHYLENE GLYCOL DIACETATE</b>		17
Ethylene glycol ethyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
Ethylene glycol ethyl ether acetate	<b>2-ETHOXYETHYL ACETATE</b>	17
Ethylene glycol isopropyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
Ethylene glycol methyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
<b>ETHYLENE GLYCOL METHYL ETHER ACETATE</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>		17
Ethylene glycol monoalkyl ethers (58%)/ Hyperbranched polyesteramide (42%)	<b>2-BUTOXYETHANOL (58%)/HYPERBRANCHED POLYESTERAMIDE (42%) (MIXTURE)</b>	17
Ethylene glycol monobutyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
Ethylene glycol monobutyl ether (58%)/ Hyperbranched polyesteramide (42%)	<b>2-BUTOXYETHANOL (58%)/HYPERBRANCHED POLYESTERAMIDE (42%) (MIXTURE)</b>	17
Ethylene glycol mono-tert-butyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
Ethylene glycol monoethyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
Ethylene glycol monoethyl ether acetate	<b>2-ETHOXYETHYL ACETATE</b>	17
Ethylene glycol monomethyl ether (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
Ethylene glycol monomethyl ether acetate	<b>ETHYLENE GLYCOL METHYL ETHER ACETATE</b>	17
Ethylene glycol monophenyl ether	<b>ETHYLENE GLYCOL PHENYL ETHER</b>	17
<b>ETHYLENE GLYCOL PHENYL ETHER</b>		17
<b>ETHYLENE GLYCOL PHENYL ETHER/DIETHYLENE GLYCOL PHENYL ETHER MIXTURE</b>		17
<b>ETHYLENE GLYCOL (&gt;75%)/SODIUM ALKYL CARBOXYLATES/BORAX MIXTURE</b>		17
<b>ETHYLENE GLYCOL (&gt;85%)/SODIUM ALKYL CARBOXYLATES MIXTURE</b>		17
<b>ETHYLENE OXIDE/PROPYLENE OXIDE MIXTURE WITH AN ETHYLENE OXIDE CONTENT OF NOT MORE THAN 30% BY MASS</b>		17
Ethylene tetrachloride	<b>PERCHLOROETHYLENE</b>	17
Ethylene trichloride	<b>TRICHLOROETHYLENE</b>	17
<b>ETHYLENE-VINYL ACETATE COPOLYMER (EMULSION)</b>		17
Ethyl ethanoate	<b>ETHYL ACETATE</b>	17
Ethyl ether	<b>DIETHYL ETHER (*)</b>	17
<b>ETHYL-3-ETHOXYPROPIONATE</b>		17
Ethyl fluid (a)	<b>MOTOR FUEL ANTI-KNOCK COMPOUND (CONTAINING LEAD ALKYL)</b>	17
Ethylformic acid	<b>PROPIONIC ACID</b>	17
Ethyl glycol (a)	<b>ETHYLENE GLYCOL MONOALKYL ETHERS</b>	17
2-Ethylhexaldehyde (a)	<b>OCTYL ALDEHYDES</b>	17
2-Ethylhexanal (a)	<b>OCTYL ALDEHYDES</b>	17
<b>2-ETHYLHEXANOIC ACID</b>		17
2-Ethylhexanol (a)	<b>OCTANOL (ALL ISOMERS)</b>	17
2-Ethylhexenal	<b>2-ETHYL-3-PROPYLACROLEIN</b>	17
2-Ethylhex-2-enal	<b>2-ETHYL-3-PROPYLACROLEIN</b>	17
2-Ethylhexoic acid (a)	<b>OCTANOIC ACID (ALL ISOMERS)</b>	17
<b>2-ETHYLHEXYL ACRYLATE</b>		17
2-Ethylhexyl alcohol (a)	<b>OCTANOL (ALL ISOMERS)</b>	17
<b>2-ETHYLHEXYLAMINE</b>		17
<b>2-ETHYL-2-(HYDROXYMETHYL) PROPANE-1,3-DIOL (C8-C10) ESTER</b>		17
Ethyllic acid	<b>ACETIC ACID</b>	17
5-Ethylidenebicyclo(2.2.1)hept-2-ene	<b>ETHYLIDENE NORBORNENE</b>	17
Ethylidene chloride	<b>1,1-DICHLOROETHANE</b>	17
<b>ETHYLIDENE NORBORNENE</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>ETHYL METHACRYLATE</b>		17
<b>N-ETHYLMETHYLALLYLAMINE</b>		17
N-Ethyl-2-methylallylamine	<b>N-ETHYLMETHYLALLYLAMINE</b>	17
2-Ethyl-6-methylaniline	<b>2-METHYL-6-ETHYL ANILINE</b>	17
2-Ethyl-6-methylbenzenamine	<b>2-METHYL-6-ETHYL ANILINE</b>	17
1-ethyl-4-methylbenzene	<b>ETHYL TOLUENE</b>	17
Ethyl methyl ketone	<b>METHYL ETHYL KETONE</b>	17
5-Ethyl-2-methylpyridine	<b>2-METHYL-5-ETHYL PYRIDINE</b>	17
Ethyl oxide	<b>DIETHYL ETHER (*)</b>	17
Ethyl phosphate	<b>TRIETHYL PHOSPHATE</b>	17
Ethyl phthalate	<b>DIETHYL PHTHALATE</b>	17
5-Ethyl-2-picoline	<b>2-METHYL-5-ETHYL PYRIDINE</b>	17
Ethyl propenoate	<b>ETHYL ACRYLATE</b>	17
<b>ETHYL PROPIONATE</b>		17
<b>2-ETHYL-3-PROPYLACROLEIN</b>		17
Ethyl sulphate	<b>DIETHYL SULPHATE</b>	17
<b>ETHYL TOLUENE</b>		17
6-Ethyl-2-toluidine	<b>2-METHYL-6-ETHYL ANILINE</b>	17
6-Ethyl-o-toluidine	<b>2-METHYL-6-ETHYL ANILINE</b>	17
Ethyl vinyl ether	<b>VINYL ETHYL ETHER</b>	17
Extra virgin grape seed oil	<b>GRAPE SEED OIL</b>	17
<b>FATTY ACID (SATURATED C13+)</b>		17
<b>FATTY ACID METHYL ESTERS (M)</b>		17
<b>FATTY ACIDS, (C8-C10)</b>		17
<b>FATTY ACIDS, (C12+)</b>		17
<b>FATTY ACIDS, (C16+)</b>		17
<b>FATTY ACIDS, ESSENTIALLY LINEAR (C6-C18) 2-ETHYLHEXYL ESTER</b>		17
Feeding corn molasses (a)	<b>MOLASSES</b>	18
Fermentation alcohol	<b>ETHYL ALCOHOL</b>	18
<b>FERRIC CHLORIDE SOLUTIONS</b>		17
<b>FERRIC NITRATE/NITRIC ACID SOLUTION</b>		17
<b>FISH OIL</b>		17
<b>FISH PROTEIN CONCENTRATE (CONTAINING 4% OR LESS FORMIC ACID)</b>		17
<b>FISH SILAGE PROTEIN CONCENTRATE (CONTAINING 4% OR LESS FORMIC ACID)</b>		17
<b>FLUOROSILICIC ACID SOLUTION (20-30%)</b>		17
<b>FORMALDEHYDE SOLUTIONS (45% OR LESS)</b>		17
Formaldehyde trimer	<b>1,3,5-TRIOXANE</b>	17
Formalin	<b>FORMALDEHYDE SOLUTIONS (45% OR LESS)</b>	17
<b>FORMAMIDE</b>		17
Formdimethylamide	<b>DIMETHYLFORMAMIDE</b>	17
<b>FORMIC ACID (85% OR LESS ACID)</b>		17
<b>FORMIC ACID (OVER 85%)</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>FORMIC ACID MIXTURE (CONTAINING UP TO 18% PROPIONIC ACID AND UP TO 25% SODIUM FORMATE)</b>		17
Formic aldehyde	<b>FORMALDEHYDE SOLUTIONS (45% OR LESS)</b>	17
Formylformic acid	<b>GLYOXYLIC ACID SOLUTION (50 % OR LESS)</b>	17
Fural	<b>FURFURAL</b>	17
2-Furaldehyde	<b>FURFURAL</b>	17
2,5-Furandione	<b>MALEIC ANHYDRIDE</b>	17
Furan-2,5-dione	<b>MALEIC ANHYDRIDE</b>	17
<b>FURFURAL</b>		17
2-Furfuraldehyde	<b>FURFURAL</b>	17
<b>FURFURYL ALCOHOL</b>		17
Furylcarbinol	<b>FURFURYL ALCOHOL</b>	17
Fused poly(2+)cyclic aromatic hydrocarbons (b)	<b>POLY(2+)CYCLIC AROMATICS</b>	17
Gaultheria oil	<b>METHYL SALICYLATE</b>	17
Glacial acetic acid	<b>ACETIC ACID</b>	17
<b>GLUCITOL/GLYCEROL BLEND PROPOXYLATED (CONTAINING 10% OR MORE AMINES)</b>		17
<b>GLUCITOL/GLYCEROL BLEND PROPOXYLATED (CONTAINING LESS THAN 10% AMINES)</b>		17
Glucitol solution	<b>SORBITOL SOLUTION</b>	18
D-Glucitol solution	<b>SORBITOL SOLUTION</b>	18
<b>GLUCOSE SOLUTION</b>		18
<b>GLUTARALDEHYDE SOLUTIONS (50% OR LESS)</b>		17
Glycerin	<b>GLYCERINE</b>	17
<b>GLYCERINE</b>		17
Glycerin triacetate	<b>GLYCERYL TRIACETATE</b>	17
Glyceritol	<b>GLYCERINE</b>	17
Glycerol	<b>GLYCERINE</b>	17
<b>GLYCEROL ETHOXYLATED</b>		18
<b>GLYCEROL MONOOLEATE</b>		17
Glycerol oleate	<b>GLYCEROL MONOOLEATE</b>	17
Glycerol 1-oleate	<b>GLYCEROL MONOOLEATE</b>	17
<b>GLYCEROL PROPOXYLATED</b>		17
<b>GLYCEROL, PROPOXYLATED AND ETHOXYLATED</b>		17
<b>GLYCEROL/SUCROSE BLEND PROPOXYLATED AND ETHOXYLATED</b>		17
Glycerol triacetate	<b>GLYCERYL TRIACETATE</b>	17
<b>GLYCERYL TRIACETATE</b>		17
<b>GLYCIDYL ESTER OF C10 TRIALKYLACETIC ACID</b>		17
Glycidyl neodecanoate	<b>GLYCIDYL ESTER OF C10 TRIALKYLACETIC ACID</b>	17
<b>GLYCINE, SODIUM SALT SOLUTION</b>		17
Glycol	<b>ETHYLENE GLYCOL</b>	17
Glycol carbonate	<b>ETHYLENE CARBONATE</b>	17
Glycol chlorohydrin	<b>ETHYLENE CHLOROHYDRIN</b>	17
Glycol dichloride	<b>ETHYLENE DICHLORIDE</b>	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>GLYCOLIC ACID SOLUTION (70% OR LESS)</b>		17
Glycol monobutyl ether (a)	ETHYLENE GLYCOL MONOALKYL ETHERS	17
Glycols, polyethylene mono(p-nonylphenyl) ether (b)	ALKARYL POLYETHERS (C9-C20)	17
Glycyl alcohol	GLYCERINE	17
Glyoxaldehyde	GLYOXAL SOLUTION (40% OR LESS)	17
Glyoxalic acid	GLYOXYLIC ACID SOLUTION (50 % OR LESS)	17
<b>GLYOXAL SOLUTION (40% OR LESS)</b>		17
<b>GLYOXYLIC ACID SOLUTION (50 % OR LESS)</b>		17
Glyphosate	GLYPHOSATE SOLUTION (NOT CONTAINING SURFACTANT)	17
Glyphosate-mono(isopropylammonium)	GLYPHOSATE SOLUTION (NOT CONTAINING SURFACTANT)	17
<b>GLYPHOSATE SOLUTION (NOT CONTAINING SURFACTANT)</b>		17
Grain alcohol	ETHYL ALCOHOL	18
<b>GRAPE SEED OIL</b>		17
<b>GROUNDNUT OIL</b>		17
Hemimellitene (a)	TRIMETHYLBENZENE (ALL ISOMERS)	17
Hendecanoic acid	UNDECANOIC ACID	17
1-Hendecanol	UNDECYL ALCOHOL	17
cyclo-Heptamethylene	CYCLOHEPTANE	17
<b>HEPTANE (ALL ISOMERS)</b>		17
1-Heptanecarboxylic acid (a)	OCTANOIC ACID (ALL ISOMERS)	17
3-Heptanecarboxylic acid (a)	OCTANOIC ACID (ALL ISOMERS)	17
Heptanoic acid	N-HEPTANOIC ACID	17
<b>N-HEPTANOIC ACID</b>		17
<b>HEPTANOL (ALL ISOMERS) (D)</b>		17
2-Heptanone	METHYL AMYL KETONE	17
Heptan-2-one	METHYL AMYL KETONE	17
<b>HEPTENE (ALL ISOMERS)</b>		17
Heptoic acid	N-HEPTANOIC ACID	17
<b>HEPTYL ACETATE</b>		17
Heptyl alcohol, all isomers (a)	HEPTANOL (ALL ISOMERS) (D)	17
Heptylcarbinol (a)	OCTANOL (ALL ISOMERS)	17
Heptylene, mixed isomers	HEPTENE (ALL ISOMERS)	17
Heptylic acid	N-HEPTANOIC ACID	17
n-Heptylic acid	N-HEPTANOIC ACID	17
1-Hexadecene	OLEFINS (C13+, ALL ISOMERS)	17
Hexadecyl and icosyl methacrylate mixture (a)	CETYL/EICOSYL METHACRYLATE MIXTURE	17
<b>1-HEXADECYLNAPHTHALENE / 1,4-BIS(HEXADECYL)NAPHTHALENE MIXTURE</b>		17
Hexadecylnaphthalene/dihexadecylnaphthalene mixture	1-HEXADECYLNAPHTHALENE / 1,4-BIS(HEXADECYL)NAPHTHALENE MIXTURE	17
Hexadecyl / octadecyl alcohol (a)	ALCOHOLS (C13+)	17
Hexaethylene glycol (a)	POLYETHYLENE GLYCOL	17
Hexafluorosilicate solution (20-30%)	FLUOROSILICIC ACID SOLUTION (20-30%)	17
Hexahydroaniline	CYCLOHEXYLAMINE	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Hexahydro-1H-azepine	HEXAMETHYLENEIMINE	17
Hexahydrobenzene	CYCLOHEXANE	17
Hexahydro-l-H-azepine	HEXAMETHYLENEIMINE	17
Hexahydrophenol	CYCLOHEXANOL	17
Hexahydrotoluene	METHYLCYCLOHEXANE	17
Hexamethylene	CYCLOHEXANE	17
<b>HEXAMETHYLENEDIAMINE (MOLTEN)</b>		17
<b>HEXAMETHYLENEDIAMINE ADIPATE (50% IN WATER)</b>		17
<b>HEXAMETHYLENEDIAMINE SOLUTION</b>		17
1,6-Hexamethylenediamine solution	HEXAMETHYLENEDIAMINE SOLUTION	17
Hexamethylenediammonium adipate solution (50% solution)	HEXAMETHYLENEDIAMINE ADIPATE (50% IN WATER)	17
<b>HEXAMETHYLENE DIISOCYANATE</b>		17
Hexamethylene-1,6-diisocyanate	HEXAMETHYLENE DIISOCYANATE	17
<b>HEXAMETHYLENE GLYCOL</b>		17
<b>HEXAMETHYLENEIMINE</b>		17
<b>HEXAMETHYLENETETRAMINE SOLUTIONS</b>		17
Hexamine	HEXAMETHYLENETETRAMINE SOLUTIONS	17
Hexanaphthene	CYCLOHEXANE	17
1,6-Hexandiamine hexanedioate (1:1)	HEXAMETHYLENEDIAMINE ADIPATE (50% IN WATER)	17
<b>HEXANE (ALL ISOMERS)</b>		17
1,6-Hexanediamine	HEXAMETHYLENEDIAMINE (MOLTEN)	17
1,6-Hexanediamine solutions	HEXAMETHYLENEDIAMINE SOLUTION	17
Hexane-1,6-diamine solutions	HEXAMETHYLENEDIAMINE SOLUTION	17
Hexanedioic acid, bis(2-ethylhexyl) ester	DI-(2-ETHYLHEXYL) ADIPATE	17
1,6-Hexanediol	HEXAMETHYLENE GLYCOL	17
Hexane-1,6-diol	HEXAMETHYLENE GLYCOL	17
<b>1,6-HEXANEDIOL, DISTILLATION OVERHEADS</b>		17
n-Hexane	HEXANE (ALL ISOMERS)	17
<b>HEXANOIC ACID</b>		17
<b>HEXANOL</b>		17
Hexan-1-ol	HEXANOL	17
2-Hexanone	METHYL BUTYL KETONE	17
Hexan-2-one	METHYL BUTYL KETONE	17
<b>HEXENE (ALL ISOMERS)</b>		17
1-Hexene (a)	HEXENE (ALL ISOMERS)	17
Hex-1-ene (a)	HEXENE (ALL ISOMERS)	17
2-Hexene (a)	HEXENE (ALL ISOMERS)	17
Hexone	METHYL ISOBUTYL KETONE	17
<b>HEXYL ACETATE</b>		17
sec-Hexyl acetate	METHYLAMYL ACETATE	17
Hexyl alcohol	HEXANOL	17
Hexylene (a)	HEXENE (ALL ISOMERS)	17
<b>HEXYLENE GLYCOL</b>		17
Hexyl ethanoate	HEXYL ACETATE	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Highly-Reactive Polyisobutylene	POLY(4+)ISOBUTYLENE (MW>224)	17
Homopiperidine	HEXAMETHYLENEIMINE	17
<b>HYDROCARBON WAX</b>		17
<b>HYDROCHLORIC ACID (*)</b>		17
Hydrofluorosilic acid solution (20-30%)	FLUOROSILICIC ACID SOLUTION (20-30%)	17
Hydrofuran	TETRAHYDROFURAN	17
Hydrogenated maltose syrup	MALTITOL SOLUTION	18
Hydrogenated oligosaccharide	HYDROGENATED STARCH HYDROLYSATE	18
<b>HYDROGENATED STARCH HYDROLYSATE</b>		18
Hydrogencarboxylic acid	FORMIC ACID (85% OR LESS ACID)	17
Hydrogen chloride, aqueous	HYDROCHLORIC ACID (*)	17
<b>HYDROGEN PEROXIDE SOLUTIONS (OVER 60% BUT NOT OVER 70% BY MASS)</b>		17
<b>HYDROGEN PEROXIDE SOLUTIONS (OVER 8% BUT NOT OVER 60% BY MASS)</b>		17
Hydrogen sulphate	SULPHURIC ACID	17
alpha-Hydro-omega-hydroxypoly[oxy(methyl-1,2-ethanediy)]	POLYPROPYLENE GLYCOL	17
Hydroxyacetic acid	GLYCOLIC ACID SOLUTION (70% OR LESS)	17
Hydroxybenzene	PHENOL	17
4-Hydroxybutanoic acid lactone	GAMMA-BUTYROLACTONE	17
4-Hydroxybutyric acid lactone	GAMMA-BUTYROLACTONE	17
gamma-Hydroxybutyric acid lactone	GAMMA-BUTYROLACTONE	17
Hydroxydimethylbenzenes	XYLENOL	17
Hydroxyethanoic acid	GLYCOLIC ACID SOLUTION (70% OR LESS)	17
2-Hydroxyethyl acetate	ETHYLENE GLYCOL ACETATE	17
<b>2-HYDROXYETHYL ACRYLATE</b>		17
beta-Hydroxyethyl acrylate	2-HYDROXYETHYL ACRYLATE	17
2-Hydroxyethylamine	ETHANOLAMINE	17
N-beta-Hydroxyethylethylenediamine	AMINOETHYL ETHANOLAMINE	17
<b>N-(HYDROXYETHYL)ETHYLENEDIAMINETRIACETIC ACID, TRISODIUM SALT SOLUTION</b>		17
beta-Hydroxyethyl phenyl ether	ETHYLENE GLYCOL PHENYL ETHER	17
2-Hydroxyethyl propenoate	2-HYDROXYETHYL ACRYLATE	17
2-Hydroxyethyl 2-propenoate	2-HYDROXYETHYL ACRYLATE	17
alpha-Hydroxyisobutyronitrile	ACETONE CYANOHYDRIN	17
4-Hydroxy-2-keto-4-methylpentane	DIACETONE ALCOHOL	17
4-Hydroxy-4-methylpentanone-2	DIACETONE ALCOHOL	17
4-Hydroxy-4-methylpentan-2-one	DIACETONE ALCOHOL	17
2-Hydroxy-2-methylpropionitrile	ACETONE CYANOHYDRIN	17
<b>2-HYDROXY-4-(METHYLTHIO)BUTANOIC ACID</b>		17
2-Hydroxy-4-(methylthio)butyric acid	2-HYDROXY-4-(METHYLTHIO)BUTANOIC ACID	17
2-Hydroxynitrobenzene (molten)	O-NITROPHENOL (MOLTEN)	17
1-Hydroxy-2-phenoxyethane	ETHYLENE GLYCOL PHENYL ETHER	17
2-Hydroxypropanoic acid	LACTIC ACID	17
2-Hydroxypropionic acid	LACTIC ACID	17
alpha-Hydroxypropionic acid	LACTIC ACID	17
3-Hydroxypropionic acid, lactone.	BETA-PROPIOLACTONE	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
beta-Hydroxypropionitrile	ETHYLENE CYANOHYDRIN	17
2-Hydroxypropionitrile solution (80% or less)	LACTONITRILE SOLUTION (80% OR LESS)	17
alpha-Hydroxypropionitrile solution (80% or less)	LACTONITRILE SOLUTION (80% OR LESS)	17
3-Hydroxypropionitrile	ETHYLENE CYANOHYDRIN	17
2-Hydroxypropionitrile solution (80% or less)	LACTONITRILE SOLUTION (80% OR LESS)	17
2-[2-(2-hydroxypropoxy)propoxy]propan-1-ol	TRIPROPYLENE GLYCOL	17
2-Hydroxypropylamine	ISOPROPANOLAMINE	17
3-Hydroxypropylamine	N-PROPANOLAMINE	17
alpha-Hydroxytoluene	BENZYL ALCOHOL	17
3-Hydroxy-2,2,4-trimethylpentyl isobutyrate	2,2,4-TRIMETHYL-1,3-PENTANEDIOL-1-ISOBUTYRATE	17
<b>ILLIPE OIL</b>		17
2,2'-Iminodi(ethylamine)	DIETHYLENETRIAMINE	17
2,2'-Iminodiethanol	DIETHANOLAMINE	17
1,1'-Iminodipropan-2-ol	DIISOPROPANOLAMINE	17
Iron (III) chloride solutions	FERRIC CHLORIDE SOLUTIONS	17
Iron (III) nitrate / nitric acid solution	FERRIC NITRATE/NITRIC ACID SOLUTION	17
Isoacetophenone	ISOPHORONE	17
Isoamyl acetate (a)	AMYL ACETATE (ALL ISOMERS)	17
<b>ISOAMYL ALCOHOL</b>		17
Isobutaldehyde (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
Isobutanal (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
Isobutanol	ISOBUTYL ALCOHOL	17
Isobutanolamine	2-AMINO-2-METHYL-1-PROPANOL	17
Isobutyl acetate	BUTYL ACETATE (ALL ISOMERS)	17
Isobutyl acrylate (a)	BUTYL ACRYLATE (ALL ISOMERS)	17
<b>ISOBUTYL ALCOHOL</b>		17
Isobutyl aldehyde (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
Isobutylamine (a)	BUTYLAMINE (ALL ISOMERS)	17
Isobutylcarbinol	ISOAMYL ALCOHOL	17
<b>ISOBUTYL FORMATE</b>		17
Isobutyl ketone	DIISOBUTYL KETONE	17
<b>ISOBUTYL METHACRYLATE</b>		17
Isobutylmethylcarbinol	METHYLAMYL ALCOHOL	17
Isobutyl methyl ketone	METHYL ISOBUTYL KETONE	17
Isobutylmethylmethanol	METHYLAMYL ALCOHOL	17
Isobutyraldehyde (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
Isobutyric aldehyde (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
alpha-Isocyanatobenzyl-omega-isocyanatophenylpoly[(phenyl isocyanate)-alt-formaldehyde]	POLYMETHYLENE POLYPHENYL ISOCYANATE	17
3-Isocyanatomethyl-3,5,5-trimethylcyclohexyl isocyanate	ISOPHORONE DIISOCYANATE	17
Isodecanol	DECYL ALCOHOL (ALL ISOMERS)	17
Isodecyl alcohol	DECYL ALCOHOL (ALL ISOMERS)	17
Isododecane (a)	DODECANE (ALL ISOMERS)	17
Isodurene (a)	TETRAMETHYLBENZENE (ALL ISOMERS)	17
Isononanoic acid	NONANOIC ACID (ALL ISOMERS)	17
Isononanol	NONYL ALCOHOL (ALL ISOMERS)	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Isooctane (a)	OCTANE (ALL ISOMERS)	17
Isooctanol	OCTANOL (ALL ISOMERS)	17
Isopentane (a)	PENTANE (ALL ISOMERS)	17
Isopentanol	AMYL ALCOHOL, PRIMARY	17
Isopentanol	ISOAMYL ALCOHOL	17
Isopentyl acetate (a)	AMYL ACETATE (ALL ISOMERS)	17
Isopentyl alcohol	ISOAMYL ALCOHOL	17
<b>ISOPHORONE</b>		17
<b>ISOPHORONEDIAMINE</b>		17
<b>ISOPHORONE DIISOCYANATE</b>		17
<b>ISOPRENE</b>		17
Isopropanol	ISOPROPYL ALCOHOL	18
<b>ISOPROPANOLAMINE</b>		17
Isopropenylbenzene	ALPHA-METHYLSTYRENE	17
2-Isopropoxyethanol (a)	ETHYLENE GLYCOL MONOALKYL ETHERS	17
2-Isopropoxypropane	ISOPROPYL ETHER	17
<b>ISOPROPYL ACETATE</b>		17
Isopropylacetone	METHYL ISOBUTYL KETONE	17
<b>ISOPROPYL ALCOHOL</b>		18
<b>ISOPROPYLAMINE</b>		17
<b>ISOPROPYLAMINE (70% OR LESS) SOLUTION</b>		17
Isopropylammonium N-(phosphonomethyl)glycine	GLYPHOSATE SOLUTION (NOT CONTAINING SURFACTANT)	17
Isopropylcarbinol	ISOBUTYL ALCOHOL	17
Isopropyl carbinol	ISOBUTYL ALCOHOL	17
<b>ISOPROPYLCYCLOHEXANE</b>		17
1-Isopropyl-2,2-dimethyltrimethylene diisobutyrate	2,2,4-TRIMETHYL-1,3-PENTANEDIOL DIISOBUTYRATE	17
<b>ISOPROPYL ETHER</b>		17
Isopropylideneacetone	MESITYL OXIDE	17
Isopropyl oxide	ISOPROPYL ETHER	17
4-Isopropyltoluene	P-CYMENE	17
p-Isopropyltoluene	P-CYMENE	17
4-Isopropyltoluol	P-CYMENE	17
Isovaleral	VALERALDEHYDE (ALL ISOMERS)	17
Isovaleraldehyde	VALERALDEHYDE (ALL ISOMERS)	17
Isovaleric aldehyde	VALERALDEHYDE (ALL ISOMERS)	17
Isovalerone	DIISOBUTYL KETONE	17
<b>JATROPHA OIL</b>		17
Kaolin clay slurry	KAOLIN SLURRY	18
Kaolinite slurry	KAOLIN SLURRY	18
<b>KAOLIN SLURRY</b>		18
Ketohexamethylene	CYCLOHEXANONE	17
Ketone propane	ACETONE	18
Ketopropane	ACETONE	18
<b>LACTIC ACID</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>LACTONITRILE SOLUTION (80% OR LESS)</b>		17
<b>LARD</b>		17
<b>LATEX, AMMONIA (1% OR LESS)- INHIBITED</b>		17
<b>LATEX: CARBOXYLATED STYRENE-BUTADIENE COPOLYMER; STYRENE-BUTADIENE RUBBER</b>		17
<b>LAURIC ACID</b>		17
Lauryl alcohol	<b>DODECYL ALCOHOL</b>	17
Lead alkyls, n.o.s. (a)	<b>MOTOR FUEL ANTI-KNOCK COMPOUND (CONTAINING LEAD ALKYLs)</b>	17
Lead tetraethyl (a)	<b>MOTOR FUEL ANTI-KNOCK COMPOUND (CONTAINING LEAD ALKYLs)</b>	17
Lead tetramethyl (a)	<b>MOTOR FUEL ANTI-KNOCK COMPOUND (CONTAINING LEAD ALKYLs)</b>	17
<b>LECITHIN</b>		18
<b>LIGNINSULPHONIC ACID, MAGNESIUM SALT SOLUTION</b>		17
<b>LIGNINSULPHONIC ACID, SODIUM SALT SOLUTION</b>		17
Limonene	<b>DIPENTENE</b>	17
Linear alkylbenzene (LAB) bottoms (a)	<b>ALKYLBENZENE DISTILLATION BOTTOMS</b>	17
Linear alkyl(C12-C16) propoxyamine ethoxylate	<b>ALKYL(C12-C16) PROPOXYAMINE ETHOXYLATE</b>	17
<b>LINSEED OIL</b>		17
<b>LIQUID CHEMICAL WASTES</b>		17
Liquid paraffin	<b>N-ALKANES (C10-C20)</b>	17
<b>LONG-CHAIN ALKARYL POLYETHER (C11-C20)</b>		17
<b>LONG-CHAIN ALKARYL SULPHONIC ACID (C16-C60)</b>		17
<b>LONG-CHAIN ALKYLPHENATE/PHENOL SULPHIDE MIXTURE</b>		17
<b>LONG-CHAIN ALKYLPHENOL (C14-C18)</b>		17
<b>LONG-CHAIN ALKYLPHENOL (C18-C30)</b>		17
Lye, soda solution	<b>SODIUM HYDROXIDE SOLUTION (*)</b>	17
<b>L-LYSINE SOLUTION (60% OR LESS)</b>		17
Magnesia hydrate	<b>MAGNESIUM HYDROXIDE SLURRY</b>	17
<b>MAGNESIUM CHLORIDE SOLUTION</b>		17
<b>MAGNESIUM HYDROXIDE SLURRY</b>		17
Magnesium Lignasulphonate solution	<b>LIGNINSULPHONIC ACID, MAGNESIUM SALT SOLUTION</b>	17
<b>MAGNESIUM LONG-CHAIN ALKARYL SULPHONATE (C11-C50)</b>		17
<b>MAGNESIUM LONG-CHAIN ALKYL SALICYLATE (C11+)</b>		17
<b>MALEIC ANHYDRIDE</b>		17
<b>MALEIC ANHYDRIDE-SODIUM ALLYLSULPHONATE COPOLYMER SOLUTION</b>		17
Maltitol	<b>MALTITOL SOLUTION</b>	18
<b>MALTITOL SOLUTION</b>		18
Maltitol syrup	<b>MALTITOL SOLUTION</b>	18
<b>MANGO KERNEL OIL</b>		17
Meglumine solution (70% or less)	<b>N-METHYLGLUCAMINE SOLUTION (70% OR LESS)</b>	17

Index Name	Product Name	Chapter
<b>MERCAPTOBENZOTHAZOL, SODIUM SALT SOLUTION</b>		17
Mesitylene	TRIMETHYLBENZENE (ALL ISOMERS)	17
<b>MESITYL OXIDE</b>		17
Metaformaldehyde	1,3,5-TRIOXANE	17
Metam-sodium	METAM SODIUM SOLUTION	17
<b>METAM SODIUM SOLUTION</b>		17
<b>METHACRYLIC ACID</b>		17
<b>METHACRYLIC ACID - ALKOXPOLY (ALKYLENE OXIDE) METHACRYLATE COPOLYMER, SODIUM SALT AQUEOUS SOLUTION (45% OR LESS)</b>		17
alpha-Methacrylic acid	METHACRYLIC ACID	17
Methacrylic acid, dodecyl ester	DODECYL METHACRYLATE	17
Methacrylic acid, lauryl ester	DODECYL METHACRYLATE	17
<b>METHACRYLIC RESIN IN ETHYLENE DICHLORIDE</b>		17
<b>METHACRYLONITRILE</b>		17
Methanal	FORMALDEHYDE SOLUTIONS (45% OR LESS)	17
Methanamide	FORMAMIDE	17
Methanamine	METHYLAMINE SOLUTIONS (42% OR LESS)	17
Methanecarboxylic acid	ACETIC ACID	17
Methanoic acid	FORMIC ACID (85% OR LESS ACID)	17
Methanol	METHYL ALCOHOL (*)	17
Methenamine	HEXAMETHYLENETETRAMINE SOLUTIONS	17
<b>3-METHOXY-1-BUTANOL</b>		17
3-Methoxybutan-1-ol	3-METHOXY-1-BUTANOL	17
<b>3-METHOXYBUTYL ACETATE</b>		17
2-Methoxyethanol (a)	ETHYLENE GLYCOL MONOALKYL ETHERS	17
2-(2-Methoxyethoxy)ethanol (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
2-[2-(2-Methoxyethoxy)ethoxy]ethanol (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
2-(2-Methoxyethoxy)ethyl acetate (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE	17
2-Methoxyethyl acetate	ETHYLENE GLYCOL METHYL ETHER ACETATE	17
2-Methoxy-2-methylbutane	TERT-AMYL METHYL ETHER	17
3-Methoxy-3-methylbutan-1-ol	3-METHYL-3-METHOXYBUTANOL	17
2-Methoxy-1-methylethyl acetate	PROPYLENE GLYCOL METHYL ETHER ACETATE	17
<b>N-(2-METHOXY-1-METHYL ETHYL)-2-ETHYL-6-METHYL CHLOROACETANILIDE</b>		17
2-methoxy-2-methylpropane	METHYL TERT-BUTYL ETHER	17
1-Methoxypropan-2-ol (a)	PROPYLENE GLYCOL MONOALKYL ETHER	17
1-Methoxy-2-propanol acetate	PROPYLENE GLYCOL METHYL ETHER ACETATE	17
1-(2-Methoxypropoxy)propan-2-ol (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
3-[3-(3-Methoxypropoxy)propoxy]propan-1-ol (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
Methoxytriglycol (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Methylacetaldehyde	PROPIONALDEHYDE	17
<b>METHYL ACETATE</b>		17
Methylacetic acid	PROPIONIC ACID	17
<b>METHYL ACETOACETATE</b>		17
Methyl acetylacetate	METHYL ACETOACETATE	17
beta-Methylacrolein	CROTONALDEHYDE	17
<b>METHYL ACRYLATE</b>		17
2-Methylacrylic acid	METHACRYLIC ACID	17
2-Methylacrylic acid, dodecyl ester	DODECYL METHACRYLATE	17
2-Methylacrylic acid, lauryl ester	DODECYL METHACRYLATE	17
<b>METHYL ALCOHOL (*)</b>		17
<b>METHYLAMINE SOLUTIONS (42% OR LESS)</b>		17
1-Methyl-2-aminobenzene	O-TOLUIDINE	17
2-Methyl-1-aminobenzene	O-TOLUIDINE	17
<b>METHYLAMYL ACETATE</b>		17
<b>METHYLAMYL ALCOHOL</b>		17
<b>METHYL AMYL KETONE</b>		17
Methyl n-amyl ketone	METHYL AMYL KETONE	17
2-Methylaniline	O-TOLUIDINE	17
<b>N-METHYLANILINE</b>		17
o-Methylaniline	O-TOLUIDINE	17
2-Methylbenzenamine	O-TOLUIDINE	17
o-Methylbenzenamine	O-TOLUIDINE	17
Methylbenzene	TOLUENE	17
Methylbenzol	TOLUENE	17
<b>ALPHA-METHYLBENZYL ALCOHOL WITH ACETOPHENONE (15% OR LESS)</b>		17
2-Methyl-1,3-butadiene	ISOPRENE	17
3-Methyl-1,3-butadiene	ISOPRENE	17
2-Methylbutanal	VALERALDEHYDE (ALL ISOMERS)	17
3-Methylbutanal	VALERALDEHYDE (ALL ISOMERS)	17
2-Methylbutane (a)	PENTANE (ALL ISOMERS)	17
Methyl butanoate	METHYL BUTYRATE	17
2-Methyl-2-butanol	TERT-AMYL ALCOHOL	17
2-Methylbutan-2-ol	TERT-AMYL ALCOHOL	17
2-Methyl-4-butanol	ISOAMYL ALCOHOL	17
3-Methyl-1-butanol	AMYL ALCOHOL, PRIMARY	17
3-Methylbutan-1-ol	AMYL ALCOHOL, PRIMARY	17
3-Methyl-1-butanol	ISOAMYL ALCOHOL	17
3-Methylbutan-1-ol	ISOAMYL ALCOHOL	17
3-Methylbutan-3-ol	TERT-AMYL ALCOHOL	17
3-Methylbut-1-ene (a)	PENTENE (ALL ISOMERS)	17
Methylbutenes (a)	PENTENE (ALL ISOMERS)	17
<b>METHYLBUTENOL</b>		17
1-Methylbutyl acetate (a)	AMYL ACETATE (ALL ISOMERS)	17
2-Methyl-2-butyl alcohol	TERT-AMYL ALCOHOL	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
3-Methyl-1-butyl alcohol	ISOAMYL ALCOHOL	17
3-Methyl-3-butyl alcohol	TERT-AMYL ALCOHOL	17
<b>METHYL TERT-BUTYL ETHER</b>		17
<b>METHYL BUTYL KETONE</b>		17
<b>METHYLBUTYNOL</b>		17
2-Methyl-3-butyn-2-ol	2-METHYL-2-HYDROXY-3-BUTYNE	17
2-Methylbut-3-yn-2-ol	2-METHYL-2-HYDROXY-3-BUTYNE	17
2-Methylbut-3-yn-2-ol	METHYLBUTYNOL	17
2-Methyl-3-butyn-2-ol	METHYLBUTYNOL	17
2-Methylbutyraldehyde	VALERALDEHYDE (ALL ISOMERS)	17
3-Methylbutyraldehyde	VALERALDEHYDE (ALL ISOMERS)	17
<b>METHYL BUTYRATE</b>		17
Methyl 'carbitol' acetate (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE	17
Methyl 'cellosolve' acetate	ETHYLENE GLYCOL METHYL ETHER ACETATE	17
Methylchloroform	1,1,1-TRICHLOROETHANE	17
Methyl cyanide	ACETONITRILE	17
<b>METHYLCYCLOHEXANE</b>		17
1-Methyl-1,3-cyclopentadiene	METHYLCYCLOPENTADIENE DIMER	17
<b>METHYLCYCLOPENTADIENE DIMER</b>		17
<b>METHYLCYCLOPENTADIENYL MANGANESE TRICARBONYL</b>		17
<b>METHYL DIETHANOLAMINE</b>		17
4-Methyl-1,3-dioxolan-2-one	PROPYLENE CARBONATE	17
Methyl disulphide	DIMETHYL DISULPHIDE	17
Methylenebis(4-isocyanatobenzene)	DIPHENYLMETHANE DIISOCYANATE	17
Methylenebis(4-phenyl isocyanate)	DIPHENYLMETHANE DIISOCYANATE	17
Methylenebis(4-phenylene isocyanate)	DIPHENYLMETHANE DIISOCYANATE	17
Methylenebis(p-phenylene isocyanate)	DIPHENYLMETHANE DIISOCYANATE	17
4,4'-Methylenebis(4-phenyl isocyanate)	DIPHENYLMETHANE DIISOCYANATE	17
Methylene bromide	DIBROMOMETHANE	17
Methylene chloride	DICHLOROMETHANE	17
4,4'-Methylenedi(phenyl isocyanate)	DIPHENYLMETHANE DIISOCYANATE	17
Methylene dichloride	DICHLOROMETHANE	17
4,4'-Methylenediphenyl diisocyanate	DIPHENYLMETHANE DIISOCYANATE	17
Methylenedi-p-phenylene diisocyanate	DIPHENYLMETHANE DIISOCYANATE	17
2-Methylenepropionic acid	METHACRYLIC ACID	17
Methyl ethanoate	METHYL ACETATE	17
1-Methylethyl acetate	ISOPROPYL ACETATE	17
1-Methylethylamine	ISOPROPYLAMINE	17
<b>2-METHYL-6-ETHYL ANILINE</b>		17
Methylethylcarbinol	SEC-BUTYL ALCOHOL	18
Methylethylene glycol	PROPYLENE GLYCOL	18
Methylethylene oxide	PROPYLENE OXIDE	17
<b>METHYL ETHYL KETONE</b>		17
N-(1-Methylethyl)propan-2-amine	DIISOPROPYLAMINE	17

Index Name	Product Name	Chapter
<b>2-METHYL-5-ETHYL PYRIDINE</b>		17
<b>METHYL FORMATE</b>		17
<b>N-METHYLGLUCAMINE SOLUTION (70% OR LESS)</b>		17
N-methyl-D-glucamine solution (70% or less)	<b>N-METHYLGLUCAMINE SOLUTION (70% OR LESS)</b>	17
<b>2-METHYLGLUTARONITRILE WITH 2-ETHYLSUCCINONITRILE (12% OR LESS)</b>		17
Methyl glycol	<b>PROPYLENE GLYCOL</b>	18
5-Methylheptan-3-one	<b>ETHYL AMYL KETONE</b>	17
5-Methyl-3-heptanone	<b>ETHYL AMYL KETONE</b>	17
Methylhexylcarbinol	<b>OCTANOL (ALL ISOMERS)</b>	17
Methyl 2-hydroxybenzoate	<b>METHYL SALICYLATE</b>	17
Methyl o-hydroxybenzoate	<b>METHYL SALICYLATE</b>	17
<b>2-METHYL-2-HYDROXY-3-BUTYNE</b>		17
2-Methyl-2-hydroxy-3-butyne	<b>METHYLBUTYNOL</b>	17
2,2'-(Methylimino)diethanol	<b>METHYL DIETHANOLAMINE</b>	17
N-Methyl-2,2'-iminodiethanol	<b>METHYL DIETHANOLAMINE</b>	17
Methyl isoamyl ketone	<b>METHYL AMYL KETONE</b>	17
Methyl isobutenyl ketone	<b>MESITYL OXIDE</b>	17
Methylisobutylcarbinol	<b>METHYLAMYL ALCOHOL</b>	17
Methylisobutylcarbinol acetate	<b>METHYLAMYL ACETATE</b>	17
<b>METHYL ISOBUTYL KETONE</b>		17
p-Methylisopropyl benzene	<b>P-CYMENE</b>	17
2-Methylactonitrile	<b>ACETONE CYANOHYDRIN</b>	17
methyl mercaptopropionaldehyde	<b>3-(METHYLTHIO)PROPIONALDEHYDE</b>	17
<b>METHYL METHACRYLATE</b>		17
Methyl methanoate	<b>METHYL FORMATE</b>	17
<b>3-METHYL-3-METHOXYBUTANOL</b>		17
Methyl alpha-methylacrylate	<b>METHYL METHACRYLATE</b>	17
7-Methyl-3-methylene-1,6-octadiene	<b>MYRCENE</b>	17
Methyl 2-methylprop-2-enoate	<b>METHYL METHACRYLATE</b>	17
<b>METHYL NAPHTHALENE (MOLTEN)</b>		17
alpha-Methylnaphthalene (molten) (a)	<b>METHYL NAPHTHALENE (MOLTEN)</b>	17
beta-Methylnaphthalene (molten) (a)	<b>METHYL NAPHTHALENE (MOLTEN)</b>	17
(o- and p-) Methylnitrobenzene	<b>O- OR P-NITROTOLUENES</b>	17
8-Methylnonan-1-ol	<b>DECYL ALCOHOL (ALL ISOMERS)</b>	17
Methylolpropane	<b>N-BUTYL ALCOHOL</b>	18
alpha-Methyl-omega-methoxypoly(ethylene oxide)	<b>POLYETHYLENE GLYCOL DIMETHYL ETHER</b>	17
alpha-Methyl-omega-methoxypoly(oxy-1,2-ethanediyl)	<b>POLYETHYLENE GLYCOL DIMETHYL ETHER</b>	17
alpha-Methyl-omega-methoxypoly(oxyethylene)	<b>POLYETHYLENE GLYCOL DIMETHYL ETHER</b>	17
Methyloxirane	<b>PROPYLENE OXIDE</b>	17
2-Methyl-2,4-pentanediol	<b>HEXYLENE GLYCOL</b>	17
2-Methylpentane-2,4-diol	<b>HEXYLENE GLYCOL</b>	17
4-Methylpentanol-2	<b>METHYLAMYL ALCOHOL</b>	17
4-Methylpentan-2-ol	<b>METHYLAMYL ALCOHOL</b>	17
4-Methyl-2-pentanol acetate	<b>METHYLAMYL ACETATE</b>	17
4-Methyl-2-pentanone	<b>METHYL ISOBUTYL KETONE</b>	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
4-Methylpentan-2-one	METHYL ISOBUTYL KETONE	17
2-Methylpentene (a)	HEXENE (ALL ISOMERS)	17
2-Methylpent-1-ene (a)	HEXENE (ALL ISOMERS)	17
2-Methyl-1-pentene (a)	HEXENE (ALL ISOMERS)	17
4-Methyl-1-pentene (a)	HEXENE (ALL ISOMERS)	17
4-Methyl-3-penten-2-one	MESITYL OXIDE	17
4-Methylpent-3-en-2-one	MESITYL OXIDE	17
4-Methyl-2-pentyl acetate	METHYLAMYL ACETATE	17
Methylpentyl acetates	METHYLAMYL ACETATE	17
Methyl tert-pentyl ether	TERT-AMYL METHYL ETHER	17
Methyl pentyl ketone	METHYL AMYL KETONE	17
2-Methyl-m-phenylenediamine (a)	TOLUENEDIAMINE	17
4-Methyl-m-phenylenediamine (a)	TOLUENEDIAMINE	17
Methylphenylene diisocyanate	TOLUENE DIISOCYANATE	17
4-methyl-1,3-phenylene diisocyanate	TOLUENE DIISOCYANATE	17
4-Methyl-m-phenylene diisocyanate	TOLUENE DIISOCYANATE	17
2-Methyl-2-phenylpropane (a)	BUTYLBENZENE (ALL ISOMERS)	17
2-Methylpropanal (a)	BUTYRALDEHYDE (ALL ISOMERS)	17
<b>2-METHYL-1,3-PROPANEDIOL</b>		17
2-Methylpropan-1-ol	ISOBUTYL ALCOHOL	17
2-Methyl-1-propanol	ISOBUTYL ALCOHOL	17
2-Methylpropan-2-ol	TERT-BUTYL ALCOHOL	17
2-Methyl-2-propanol	TERT-BUTYL ALCOHOL	17
2-Methylprop-2-enenitrile	METHACRYLONITRILE	17
2-Methylpropenoic acid	METHACRYLIC ACID	17
alpha-Methylpropenoic acid	METHACRYLIC ACID	17
2-Methylprop-1-enyl methyl ketone	MESITYL OXIDE	17
2-Methylpropyl acrylate (a)	BUTYL ACRYLATE (ALL ISOMERS)	17
2-Methyl-1-propyl alcohol	ISOBUTYL ALCOHOL	17
2-Methyl-2-propyl alcohol	TERT-BUTYL ALCOHOL	17
Methylpropylcarbinol	SEC-AMYL ALCOHOL	17
2-Methylpropyl formate	ISOBUTYL FORMATE	17
<b>METHYL PROPYL KETONE</b>		17
<b>2-METHYLPYRIDINE</b>		17
<b>3-METHYLPYRIDINE</b>		17
<b>4-METHYLPYRIDINE</b>		17
alpha-Methylpyridine	2-METHYLPYRIDINE	17
1-Methylpyrrolidin-2-one	N-METHYL-2-PYRROLIDONE	17
1-Methyl-2-pyrrolidinone	N-METHYL-2-PYRROLIDONE	17
N-Methylpyrrolidinone	N-METHYL-2-PYRROLIDONE	17
1-Methyl-2-pyrrolidone	N-METHYL-2-PYRROLIDONE	17
<b>N-METHYL-2-PYRROLIDONE</b>		17
<b>METHYL SALICYLATE</b>		17
Methyl soyate	SOYBEAN OIL FATTY ACID METHYL ESTER	17
Methylstyrene (all isomers)	VINYLTOLUENE	17
<b>ALPHA-METHYLSTYRENE</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>3-(METHYLTHIO)PROPIONALDEHYDE</b>		17
2-Methyltrimethylene glycol	<b>2-METHYL-1,3-PROPANEDIOL</b>	17
Metolachlor	<b>N-(2-METHOXY-1-METHYL ETHYL)-2-ETHYL-6-METHYL CHLOROACETANILIDE</b>	17
<b>MICROSILICA SLURRY</b>		18
Middle oil	<b>CARBOLIC OIL</b>	17
Milk acid	<b>LACTIC ACID</b>	17
Milk of magnesia	<b>MAGNESIUM HYDROXIDE SLURRY</b>	18
Mineral wax	<b>HYDROCARBON WAX</b>	17
Mixed aliphatic oxygenated hydrocarbons, primary aliphatic alcohols and aliphatic ethers: mol wt: >200 (a)	<b>OXYGENATED ALIPHATIC HYDROCARBON MIXTURE</b>	17
<b>MOLASSES</b>		18
<b>MOLYBDENUM POLYSULPHIDE LONG CHAIN ALKYL DITHIOCARBAMIDE COMPLEX</b>		17
Monochlorobenzene	<b>CHLOROBENZENE</b>	17
Monochlorobenzol	<b>CHLOROBENZENE</b>	17
Monoethanolamine	<b>ETHANOLAMINE</b>	17
Monoethylamine	<b>ETHYLAMINE (*)</b>	17
Monoethylamine solutions, 72% or less	<b>ETHYLAMINE SOLUTIONS (72% OR LESS)</b>	17
Monoisopropanolamine	<b>ISOPROPANOLAMINE</b>	17
Monoisopropylamine	<b>ISOPROPYLAMINE</b>	17
Monomethylamine solutions, 42% or less	<b>METHYLAMINE SOLUTIONS (42% OR LESS)</b>	17
Monopropylamine	<b>N-PROPYLAMINE</b>	17
Monopropylene glycol	<b>PROPYLENE GLYCOL</b>	18
<b>MORPHOLINE</b>		17
<b>MOTOR FUEL ANTI-KNOCK COMPOUND (CONTAINING LEAD ALKYL)</b>		17
Muriatic acid	<b>HYDROCHLORIC ACID (*)</b>	17
<b>MYRCENE</b>		17
Naphtha, coal tar	<b>COAL TAR NAPHTHA SOLVENT</b>	17
<b>NAPHTHALENE (MOLTEN)</b>		17
<b>NAPHTHALENE CRUDE (MOLTEN)</b>		17
<b>NAPHTHALENESULPHONIC ACID-FORMALDEHYDE COPOLYMER, SODIUM SALT SOLUTION</b>		17
Naphtha (petroleum), Light Steam-cracked Aromatics (a)	<b>ALKYLBENZENE MIXTURES (CONTAINING AT LEAST 50% OF TOLUENE)</b>	17
Naphtha safety solvent	<b>WHITE SPIRIT, LOW (15-20%) AROMATIC</b>	17
<b>NEODECANOIC ACID</b>		17
Neodecanoic acid, 2,3-epoxypropyl ester	<b>GLYCIDYL ESTER OF C10 TRIALKYLACETIC ACID</b>	17
Neodecanoic acid, glycidyl ester	<b>GLYCIDYL ESTER OF C10 TRIALKYLACETIC ACID</b>	17
Neodecanoic acid vinyl ester	<b>VINYL NEODECANOATE</b>	17
Neopentane (a)	<b>PENTANE (ALL ISOMERS)</b>	17
Neopentanoic acid	<b>TRIMETHYLACETIC ACID</b>	17
Neopentylene glycol	<b>2,2-DIMETHYLPROPANE-1,3-DIOL (MOLTEN OR SOLUTION)</b>	17
<b>NITRATING ACID (MIXTURE OF SULPHURIC AND NITRIC ACIDS)</b>		17
<b>NITRIC ACID (70% AND OVER)</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>NITRIC ACID (LESS THAN 70%)</b>		17
Nitric acid, fuming (a)	<b>NITRIC ACID (70% AND OVER)</b>	17
Nitric acid, red fuming	<b>NITRIC ACID (70% AND OVER)</b>	17
<b>NITRILOTRIACETIC ACID, TRISODIUM SALT SOLUTION</b>		17
2,2',2''-Nitrilotriethanol	<b>TRIETHANOLAMINE</b>	17
Nitrilo-2,2',2''-triethanol	<b>TRIETHANOLAMINE</b>	17
1,1',1''-Nitrilotripropan-2-ol	<b>TRIISOPROPANOLAMINE</b>	17
1,1',1''-Nitrilotri-2-propanol	<b>TRIISOPROPANOLAMINE</b>	17
<b>NITROBENZENE</b>		17
Nitrobenzol	<b>NITROBENZENE</b>	17
o-Nitrochlorobenzene	<b>O-CHLORONITROBENZENE</b>	17
<b>NITROETHANE</b>		17
<b>NITROETHANE(80%)/ NITROPROPANE(20%)</b>		17
<b>NITROETHANE, 1-NITROPROPANE (EACH 15% OR MORE) MIXTURE</b>		17
ortho-Nitrophenol (molten)	<b>O-NITROPHENOL (MOLTEN)</b>	17
2-Nitrophenol (molten)	<b>O-NITROPHENOL (MOLTEN)</b>	17
<b>O-NITROPHENOL (MOLTEN)</b>		17
<b>1- OR 2-NITROPROPANE</b>		17
<b>NITROPROPANE (60%)/NITROETHANE (40%) MIXTURE</b>		17
2-Nitrotoluene (a)	<b>O- OR P-NITROTOLUENES</b>	17
4-Nitrotoluene (a)	<b>O- OR P-NITROTOLUENES</b>	17
o-Nitrotoluene (a)	<b>O- OR P-NITROTOLUENES</b>	17
p-Nitrotoluene (a)	<b>O- OR P-NITROTOLUENES</b>	17
<b>O- OR P-NITROTOLUENES</b>		17
<b>NONANE (ALL ISOMERS)</b>		17
1-Nonanecarboxylic acid	<b>DECANOIC ACID</b>	17
n-Nonane (a)	<b>NONANE (ALL ISOMERS)</b>	17
<b>NONANOIC ACID (ALL ISOMERS)</b>		17
Nonanols	<b>NONYL ALCOHOL (ALL ISOMERS)</b>	17
<b>NON-EDIBLE INDUSTRIAL GRADE PALM OIL</b>		17
<b>NONENE (ALL ISOMERS)</b>		17
<b>NONYL ALCOHOL (ALL ISOMERS)</b>		17
Nonylcarbinol	<b>DECYL ALCOHOL (ALL ISOMERS)</b>	17
Nonylene (a)	<b>NONENE (ALL ISOMERS)</b>	17
Nonyl hydride (a)	<b>NONANE (ALL ISOMERS)</b>	17
<b>NONYL METHACRYLATE MONOMER</b>		17
<b>NONYLPHENOL</b>		17
<b>NONYLPHENOL POLY(4+)ETHOXYLATE</b>		17
alpha-4-Nonylphenyl-omega-hydroxypoly(oxyethylene) (b)	<b>ALKARYL POLYETHERS (C9-C20)</b>	17
Nopinene	<b>BETA-PINENE</b>	17
Nopinene	<b>BETA-PINENE</b>	17
<b>NOXIOUS LIQUID, NF, (1) N.O.S. (TRADE NAME ....., CONTAINS .....) ST1, CAT. X</b>		17
<b>NOXIOUS LIQUID, F, (2) N.O.S. (TRADE NAME ....., CONTAINS .....) ST1, CAT. X</b>		17

Index Name	Product Name	Chapter
NOXIOUS LIQUID, NF, (3) N.O.S. (TRADE NAME ....., CONTAINS .....) ST2, CAT. X		17
NOXIOUS LIQUID, F, (4) N.O.S. (TRADE NAME ....., CONTAINS .....) ST2, CAT. X		17
NOXIOUS LIQUID, NF, (5) N.O.S. (TRADE NAME ....., CONTAINS .....) ST2, CAT. Y		17
NOXIOUS LIQUID, F, (6) N.O.S. (TRADE NAME ....., CONTAINS .....) ST2, CAT. Y		17
NOXIOUS LIQUID, NF, (7) N.O.S. (TRADE NAME ....., CONTAINS .....) ST3, CAT. Y		17
NOXIOUS LIQUID, F, (8) N.O.S. (TRADE NAME ....., CONTAINS .....) ST3, CAT. Y		17
NOXIOUS LIQUID, NF, (9) N.O.S. (TRADE NAME ....., CONTAINS .....) ST3, CAT. Z		17
NOXIOUS LIQUID, F, (10) N.O.S. (TRADE NAME ....., CONTAINS .....) ST3, CAT. Z		17
NOXIOUS LIQUID, (11) N.O.S. (TRADE NAME ....., CONTAINS .....) CAT. Z		18
NON NOXIOUS LIQUID, (12) N.O.S. (TRADE NAME ....., CONTAINS .....) CAT. OS		18
Octadecan-1-ol	ALCOHOLS (C14-C18), PRIMARY, LINEAR AND ESSENTIALLY LINEAR	17
1-Octadecanol	ALCOHOLS (C14-C18), PRIMARY, LINEAR AND ESSENTIALLY LINEAR	17
<b>OCTAMETHYLCYCLOTETRASIOXANE</b>		17
Octanal (a)	OCTYL ALDEHYDES	17
<b>OCTANE (ALL ISOMERS)</b>		17
1-Octanethiol	N-OCTYL MERCAPTAN	17
<b>OCTANOIC ACID (ALL ISOMERS)</b>		17
<b>OCTANOL (ALL ISOMERS)</b>		17
Octan-1-ol (a)	OCTANOL (ALL ISOMERS)	17
<b>OCTENE (ALL ISOMERS)</b>		17
Octic acid (a)	OCTANOIC ACID (ALL ISOMERS)	17
Octoic acid (a)	OCTANOIC ACID (ALL ISOMERS)	17
Octyl acetate	N-OCTYL ACETATE	17
<b>N-OCTYL ACETATE</b>		17
Octyl acrylate	2-ETHYLHEXYL ACRYLATE	17
Octyl adipate	DI-(2-ETHYLHEXYL) ADIPATE	17
Octyl alcohol (a)	OCTANOL (ALL ISOMERS)	17
<b>OCTYL ALDEHYDES</b>		17
Octylcarbinol	NONYL ALCOHOL (ALL ISOMERS)	17
<b>OCTYL DECYL ADIPATE</b>		17
Octyl decyl phthalate (a)	DIALKYL (C7-C13) PHTHALATES	17
Octylic acid (a)	OCTANOIC ACID (ALL ISOMERS)	17
<b>N-OCTYL MERCAPTAN</b>		17
Octyl nitrate	ALKYL (C7-C9) NITRATES	17
Octyl nitrates (all isomers)	ALKYL (C7-C9) NITRATES	17
Octyl phthalate (a)	DIALKYL (C7-C13) PHTHALATES	17
Oenanthic acid	N-HEPTANOIC ACID	17
Oenanthylic acid	N-HEPTANOIC ACID	17
<b>OFFSHORE CONTAMINATED BULK LIQUID P*</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>OFFSHORE CONTAMINATED BULK LIQUID S*</b>		17
Oil of Mirbane	<b>NITROBENZENE</b>	17
Oil of Myrbane	<b>NITROBENZENE</b>	17
Oil of turpentine	<b>TURPENTINE</b>	17
Oil of vitriol	<b>SULPHURIC ACID</b>	17
Oil of wintergreen	<b>METHYL SALICYLATE</b>	17
Oleamine	<b>OLEYLAMINE</b>	17
<b>OLEFIN-ALKYL ESTER COPOLYMER (MOLECULAR WEIGHT 2000+)</b>		17
<b>OLEFIN MIXTURE (C7-C9) C8 RICH, STABILIZED</b>		17
<b>OLEFIN MIXTURES (C5-C7)</b>		17
<b>OLEFIN MIXTURES (C5-C15)</b>		17
<b>OLEFINS (C13+, ALL ISOMERS)</b>		17
<b>ALPHA-OLEFINS (C6-C18) MIXTURES</b>		17
<b>OLEIC ACID</b>		17
<b>OLEUM</b>		17
<b>OLEYLAMINE</b>		17
<b>OLIVE OIL</b>		17
<b>ORANGE JUICE (CONCENTRATED)</b>		18
<b>ORANGE JUICE (NOT CONCENTRATED)</b>		18
Orthophosphoric acid	<b>PHOSPHORIC ACID</b>	17
Oxal	<b>GLYOXAL SOLUTION (40% OR LESS)</b>	17
Oxalaldehyde	<b>GLYOXAL SOLUTION (40% OR LESS)</b>	17
3-Oxapentane-1,5-diol	<b>DIETHYLENE GLYCOL</b>	17
1,4-Oxazinane	<b>MORPHOLINE</b>	17
2-Oxetanone	<b>BETA-PROPIOLACTONE</b>	17
Oxoacetic acid	<b>GLYOXYLIC ACID SOLUTION (50 % OR LESS)</b>	17
Oxoethanoic acid	<b>GLYOXYLIC ACID SOLUTION (50 % OR LESS)</b>	17
2,2'-Oxybis(1-chloropropane)	<b>2,2'-DICHLOROISOPROPYL ETHER</b>	17
2,2'-Oxybis(ethyleneoxy)diethanol	<b>TETRAETHYLENE GLYCOL</b>	17
2,2'-Oxybispropane	<b>ISOPROPYL ETHER</b>	17
2,2'-Oxydiethanol	<b>DIETHYLENE GLYCOL</b>	17
1,1'-Oxydipropan-2-ol	<b>DIPROPYLENE GLYCOL</b>	17
<b>OXYGENATED ALIPHATIC HYDROCARBON MIXTURE</b>		17
Oxymethylene	<b>FORMALDEHYDE SOLUTIONS (45% OR LESS)</b>	17
<b>PALM ACID OIL</b>		17
<b>PALM FATTY ACID DISTILLATE</b>		17
<b>PALM KERNEL ACID OIL</b>		17
<b>PALM KERNEL FATTY ACID DISTILLATE</b>		17
<b>PALM KERNEL OIL</b>		17
<b>PALM KERNEL OLEIN</b>		17
<b>PALM KERNEL STEARIN</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>PALM MID-FRACTION</b>		17
<b>PALM OIL</b>		17
<b>PALM OIL FATTY ACID METHYL ESTER</b>		17
<b>PALM OLEIN</b>		17
<b>PALM STEARIN</b>		17
Paraffin	<b>HYDROCARBON WAX</b>	17
C9-C11 n-Paraffin	<b>N-ALKANES (C9-C11)</b>	17
Paraffin, food grade	<b>PARAFFIN WAX, HIGHLY-REFINED</b>	17
n-Paraffin (C9-C11)	<b>N-ALKANES (C9-C11)</b>	17
n-Paraffins (C10-C20) (a)	<b>N-ALKANES (C10-C20)</b>	17
Paraffin wax	<b>HYDROCARBON WAX</b>	17
Paraffin wax, cosmetic	<b>PARAFFIN WAX, HIGHLY-REFINED</b>	17
Paraffin wax feedstock	<b>PARAFFIN WAX, SEMI-REFINED</b>	17
<b>PARAFFIN WAX, HIGHLY-REFINED</b>		17
<b>PARAFFIN WAX, SEMI-REFINED</b>		17
Paraffin wax, technical	<b>PARAFFIN WAX, SEMI-REFINED</b>	17
<b>PARALDEHYDE</b>		17
<b>PARALDEHYDE-AMMONIA REACTION PRODUCT</b>		17
Petrolatum	<b>HYDROCARBON WAX</b>	17
Pelargonic acid	<b>NONANOIC ACID (ALL ISOMERS)</b>	17
Pelargonic alcohol	<b>NONYL ALCOHOL (ALL ISOMERS)</b>	17
<b>PENTACHLOROETHANE</b>		17
Pentadecanol (a)	<b>ALCOHOLS (C13+)</b>	17
1-Pentadecene	<b>OLEFINS (C13+, ALL ISOMERS)</b>	17
Pentadec-1-ene (a)	<b>OLEFINS (C13+, ALL ISOMERS)</b>	17
<b>1,3-PENTADIENE</b>		17
Penta-1,3-diene	<b>1,3-PENTADIENE</b>	17
<b>1,3-PENTADIENE (GREATER THAN 50%), CYCLOPENTENE AND ISOMERS, MIXTURES</b>		17
Pentaethylene glycol (a)	<b>POLYETHYLENE GLYCOL</b>	17
<b>PENTAETHYLENEHEXAMINE</b>		17
Pentalin	<b>PENTACHLOROETHANE</b>	17
Pentamethylene	<b>CYCLOPENTANE</b>	17
Pentanal	<b>VALERALDEHYDE (ALL ISOMERS)</b>	17
Pentane (a)	<b>PENTANE (ALL ISOMERS)</b>	17
<b>PENTANE (ALL ISOMERS)</b>		17
Pentanedial solutions, 50% or less	<b>GLUTARALDEHYDE SOLUTIONS (50% OR LESS)</b>	17
n-Pentane (a)	<b>PENTANE (ALL ISOMERS)</b>	17
<b>PENTANOIC ACID</b>		17
<b>N-PENTANOIC ACID (64%)/2-METHYL BUTYRIC ACID (36%) MIXTURE</b>		17
tert-Pentanoic acid	<b>TRIMETHYLACETIC ACID</b>	17
1-Pentanol	<b>N-AMYL ALCOHOL</b>	17
Pentan-1-ol	<b>N-AMYL ALCOHOL</b>	17
2-Pentanol	<b>SEC-AMYL ALCOHOL</b>	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Pentan-2-ol	SEC-AMYL ALCOHOL	17
3-Pentanol	SEC-AMYL ALCOHOL	17
Pentan-3-ol	SEC-AMYL ALCOHOL	17
1-Pentanol acetate (a)	AMYL ACETATE (ALL ISOMERS)	17
n-Pentanol	N-AMYL ALCOHOL	17
sec-Pentanol	SEC-AMYL ALCOHOL	17
tert-Pentanol	TERT-AMYL ALCOHOL	17
2-Pentanone	METHYL PROPYL KETONE	17
Pentan-2-one	METHYL PROPYL KETONE	17
Pentasodium diethylenetriaminepentaacetate solution	DIETHYLENTRIAMINEPENTAACETIC ACID, PENTASODIUM SALT SOLUTION	17
<b>PENTENE (ALL ISOMERS)</b>		17
Pent-1-ene (a)	PENTENE (ALL ISOMERS)	17
n-Pentene (a)	PENTENE (ALL ISOMERS)	17
Pentenes	PENTENE (ALL ISOMERS)	17
Pentyl acetate (a)	AMYL ACETATE (ALL ISOMERS)	17
sec-Pentyl acetate (a)	AMYL ACETATE (ALL ISOMERS)	17
Pentyl alcohol	N-AMYL ALCOHOL	17
sec-Pentyl alcohol	SEC-AMYL ALCOHOL	17
tert-Pentyl alcohol	TERT-AMYL ALCOHOL	17
Pentyl propanoate	N-PENTYL PROPIONATE	17
<b>N-PENTYL PROPIONATE</b>		17
<b>PERCHLOROETHYLENE</b>		17
Perchloromethane	CARBON TETRACHLORIDE	17
Perhydroazepine	HEXAMETHYLENEIMINE	17
Petrolatum, highly-refined	PARAFFIN WAX, HIGHLY-REFINED	17
Petrolatum, industrial grade	PARAFFIN WAX, SEMI-REFINED	17
Petrolatum, USP-grade	PARAFFIN WAX, HIGHLY-REFINED	17
Petroleum jelly, technical	PARAFFIN WAX, SEMI-REFINED	17
Phene	BENZENE AND MIXTURES HAVING 10% BENZENE OR MORE (I)	17
Phenic acid	PHENOL	17
<b>PHENOL</b>		17
2-Phenoxyethanol	ETHYLENE GLYCOL PHENYL ETHER	17
Phenyl alkane(C10-C21)sulphonate (a)	ALKYL SULPHONIC ACID ESTER OF PHENOL	17
Phenylamine	ANILINE	17
N-Phenylaniline	DIPHENYLAMINE (MOLTEN)	17
N-Phenylbenzenamine	DIPHENYLAMINE (MOLTEN)	17
1-Phenylbutane (a)	BUTYLBENZENE (ALL ISOMERS)	17
2-Phenylbutane (a)	BUTYLBENZENE (ALL ISOMERS)	17
Phenyl carbinol	BENZYL ALCOHOL	17
Phenyl 'cellosolve'	ETHYLENE GLYCOL PHENYL ETHER	17
Phenyl chloride	CHLOROBENZENE	17
1-Phenyldecane (b)	ALKYL(C9+)BENZENES	17
1-Phenyldodecane	ALKYL(C9+)BENZENES	17
Phenylethane	ETHYLBENZENE	17
Phenyl ether	DIPHENYL ETHER	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Phenylethylene	STYRENE MONOMER	17
1-(Phenylethyl)xylene	1-PHENYL-1-XYLYL ETHANE	17
Phenyl hydride	BENZENE AND MIXTURES HAVING 10% BENZENE OR MORE (I)	17
Phenyl hydroxide	PHENOL	17
Phenylic acid	PHENOL	17
Phenylmethane	TOLUENE	17
Phenylmethanol	BENZYL ALCOHOL	17
Phenylmethyl acetate	BENZYL ACETATE	17
1-Phenylpropane (a)	PROPYLBENZENE (ALL ISOMERS)	17
2-Phenylpropane (a)	PROPYLBENZENE (ALL ISOMERS)	17
2-Phenylpropene	ALPHA-METHYLSTYRENE	17
1-Phenyltetradecane	ALKYL(C9+)BENZENES	17
1-Phenyltridecane	ALKYL(C9+)BENZENES	17
1-Phenylundecane	ALKYL(C9+)BENZENES	17
Phenylxylethane	1-PHENYL-1-XYLYL ETHANE	17
<b>1-PHENYL-1-XYLYL ETHANE</b>		17
1-Phenyl-1-(2,5-xylyl)ethane (a)	1-PHENYL-1-XYLYL ETHANE	17
1-Phenyl-1-(3,4-xylyl)ethane (a)	1-PHENYL-1-XYLYL ETHANE	17
<b>PHOSPHATE ESTERS, ALKYL (C12-C14) AMINE</b>		17
L-alpha-Phosphatidyl choline	LECITHIN	18
N-(phosphonomethyl)glycine	GLYPHOSATE SOLUTION (NOT CONTAINING SURFACTANT)	17
<b>PHOSPHORIC ACID</b>		17
<b>PHOSPHORUS, YELLOW OR WHITE (*)</b>		17
Phthalandione (molten)	PTHALIC ANHYDRIDE (MOLTEN)	17
Phthalic acid anhydride (molten)	PTHALIC ANHYDRIDE (MOLTEN)	17
Phthalic acid, diundecyl ester	DIUNDECYL PHTHALATE	17
<b>PTHALIC ANHYDRIDE (MOLTEN)</b>		17
2-Picoline	2-METHYLPYRIDINE	17
3-Picoline	3-METHYLPYRIDINE	17
4-Picoline	4-METHYLPYRIDINE	17
alpha-Picoline	2-METHYLPYRIDINE	17
beta-Picoline	3-METHYLPYRIDINE	17
gamma-Picoline	4-METHYLPYRIDINE	17
Pimelic ketone	CYCLOHEXANONE	17
2-Pinene	ALPHA-PINENE	17
2(10)-Pinene	BETA-PINENE	17
<b>ALPHA-PINENE</b>		17
<b>BETA-PINENE</b>		17
<b>PINE OIL</b>		17
<b>PIPERAZINE, 68% SOLUTION</b>		17
2-Piperazin-1-ylethylamine	N-AMINOETHYLPYPERAZINE	17
Piperylene	1,3-PENTADIENE	17
Piperylene concentrates (Mixed)	1,3-PENTADIENE (GREATER THAN 50%), CYCLOPENTENE AND ISOMERS, MIXTURES	17
Pivalic acid	TRIMETHYLACETIC ACID	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Poly(oxyethylene)	<b>POLYETHER (MOLECULAR WEIGHT 1350+)</b>	17
Poly(oxyethyleneoxyethyleneoxyphthaloyl)	<b>DIETHYLENE GLYCOL PHTHALATE</b>	17
Poly(sodium carboxylatoethylene)	<b>SODIUM POLY(4+)ACRYLATE SOLUTIONS</b>	17
<b>POLYACRYLIC ACID SOLUTION (40% OR LESS)</b>		17
<b>POLYALKYL (C18-C22) ACRYLATE IN XYLENE</b>		17
<b>POLYALKYLALKENAMINESUCCINIMIDE, MOLYBDENUM OXYSULPHIDE</b>		17
<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER</b>		17
<b>POLY(2-8)ALKYLENE GLYCOL MONOALKYL (C1-C6) ETHER ACETATE</b>		17
Poly (2-8) alkylene (C2-C3) glycols / Polyalkylene (C2-C10) glycol monoalkyl (C1-C4) ethers and their borate esters (a)	<b>BRAKE FLUID BASE MIX: POLY(2-8)ALKYLENE (C2-C3) GLYCOLS/POLYALKYLENE (C2-C10) GLYCOLS MONOALKYL (C1-C4) ETHERS AND THEIR BORATE ESTERS</b>	17
<b>POLYALKYL (C10-C20) METHACRYLATE</b>		17
<b>POLYALKYL (C10-C18) METHACRYLATE/ETHYLENE-PROPYLENE COPOLYMER MIXTURE</b>		17
<b>POLYALUMINIUM CHLORIDE SOLUTION</b>		17
<b>POLYBUTENE</b>		17
<b>POLYBUTENYL SUCCINIMIDE</b>		17
<b>POLY(2+)CYCLIC AROMATICS</b>		17
<b>POLYETHER (MOLECULAR WEIGHT 1350+)</b>		17
<b>POLYETHYLENE GLYCOL</b>		17
Poly(4-12)ethylene glycol alkyl(C7-C11)phenyl ether	<b>NONYLPHENOL POLY(4+)ETHOXYLATE</b>	17
<b>POLYETHYLENE GLYCOL DIMETHYL ETHER</b>		17
<b>POLY(ETHYLENE GLYCOL) METHYLBUTENYL ETHER (MW&gt;1000)</b>		17
Polyethylene glycols, mono(p-nonylphenyl) ether (b)	<b>ALKARYL POLYETHERS (C9-C20)</b>	17
Poly(ethylene oxide) (molecular weight 1350+) (a)	<b>POLYETHER (MOLECULAR WEIGHT 1350+)</b>	17
<b>POLYETHYLENE POLYAMINES</b>		17
<b>POLYETHYLENE POLYAMINES (MORE THAN 50% C5 -C20 PARAFFIN OIL)</b>		17
<b>POLYFERRIC SULPHATE SOLUTION</b>		17
Polyglucitol	<b>HYDROGENATED STARCH HYDROLYSATE</b>	18
<b>POLYGLYCERIN, SODIUM SALT SOLUTION (CONTAINING LESS THAN 3% SODIUM HYDROXIDE)</b>		17
Polyglycitol syrup	<b>HYDROGENATED STARCH HYDROLYSATE</b>	18
<b>POLY(IMINOETHYLENE)-GRAFT-N-POLY(ETHYLENEOXY) SOLUTION (90% OR LESS)</b>		17
<b>POLYISOBUTENAMINE IN ALIPHATIC (C10-C14) SOLVENT</b>		17
<b>(POLYISOBUTENE) AMINO PRODUCTS IN ALIPHATIC HYDROCARBONS</b>		17
<b>POLYISOBUTENYL ANHYDRIDE ADDUCT</b>		17
<b>POLY(4+)ISOBUTYLENE (MW&gt;224)</b>		17
<b>POLYISOBUTYLENE (MW≤224)</b>		17
<b>POLYMETHYLENE POLYPHENYL ISOCYANATE</b>		17
<b>POLYOLEFIN (MOLECULAR WEIGHT 300+)</b>		17
<b>POLYOLEFIN AMIDE ALKENEAMINE (C17+)</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>POLYOLEFIN AMIDE ALKENEAMINE BORATE (C28-C250)</b>		17
<b>POLYOLEFIN AMIDE ALKENEAMINE POLYOL</b>		17
<b>POLYOLEFINAMINE (C28-C250)</b>		17
<b>POLYOLEFINAMINE IN ALKYL (C2-C4) BENZENES</b>		17
<b>POLYOLEFINAMINE IN AROMATIC SOLVENT</b>		17
<b>POLYOLEFIN AMINOESTER SALTS (MOLECULAR WEIGHT 2000+)</b>		17
<b>POLYOLEFIN ANHYDRIDE</b>		17
<b>POLYOLEFIN ESTER (C28-C250)</b>		17
<b>POLYOLEFIN PHENOLIC AMINE (C28-C250)</b>		17
<b>POLYOLEFIN PHOSPHOROSULPHIDE, BARIUM DERIVATIVE (C28-C250)</b>		17
Poly(oxyalkylene)alkenyl ether (MW>1000)	<b>POLY(ETHYLENE GLYCOL) METHYLBUTENYL ETHER (MW&gt;1000)</b>	17
Poly(oxy-1,2-ethanediyl), alpha-(3-methyl-3-butenyl)-, omega-hydroxy-	<b>POLY(ETHYLENE GLYCOL) METHYLBUTENYL ETHER (MW&gt;1000)</b>	17
<b>POLY(20)OXYETHYLENE SORBITAN MONOOLEATE</b>		17
Poly(oxypropylene) (molecular weight 1350+) (a)	<b>POLYETHER (MOLECULAR WEIGHT 1350+)</b>	17
poly[(phenyl isocyanate)-alt-formaldehyde] (a)	<b>POLYMETHYLENE POLYPHENYL ISOCYANATE</b>	17
Poly[(phenyl isocyanate)-co-formaldehyde] (a)	<b>POLYMETHYLENE POLYPHENYL ISOCYANATE</b>	17
Poly[propene oxide]	<b>POLYETHER (MOLECULAR WEIGHT 1350+)</b>	17
Polypropylene	<b>POLY(5+)PROPYLENE</b>	17
<b>POLY(5+)PROPYLENE</b>		17
<b>POLYPROPYLENE GLYCOL</b>		17
<b>POLYSILOXANE</b>		17
Potash lye solution	<b>POTASSIUM HYDROXIDE SOLUTION (*)</b>	17
Potassium chloride brine (<26%)	<b>POTASSIUM CHLORIDE SOLUTION (LESS THAN 26%)</b>	18
Potassium chloride drilling brine	<b>POTASSIUM CHLORIDE SOLUTION</b>	17
<b>POTASSIUM CHLORIDE SOLUTION</b>		17
<b>POTASSIUM CHLORIDE SOLUTION (LESS THAN 26%)</b>		18
<b>POTASSIUM FORMATE SOLUTIONS (*)</b>		17
<b>POTASSIUM HYDROXIDE SOLUTION (*)</b>		17
<b>POTASSIUM OLEATE</b>		17
<b>POTASSIUM THIOSULPHATE (50% OR LESS)</b>		17
Propanal	<b>PROPIONALDEHYDE</b>	17
Propan-1-amine	<b>N-PROPYLAMINE</b>	17
2-Propanamine	<b>ISOPROPYLAMINE</b>	17
1,2-Propanediol	<b>PROPYLENE GLYCOL</b>	18
Propane-1,2-diol	<b>PROPYLENE GLYCOL</b>	18
1,2-Propanediol cyclic carbonate	<b>PROPYLENE CARBONATE</b>	17
Propanenitrile	<b>PROPIONITRILE</b>	17
1,2,3-Propanetriol	<b>GLYCERINE</b>	17
Propane-1,2,3-triol	<b>GLYCERINE</b>	17
1,2,3-Propanetriol triacetate	<b>GLYCERYL TRIACETATE</b>	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Propanoic acid	PROPIONIC ACID	17
Propanoic anhydride	PROPIONIC ANHYDRIDE	17
Propanol	N-PROPYL ALCOHOL	17
1-Propanol	N-PROPYL ALCOHOL	17
Propan-1-ol	N-PROPYL ALCOHOL	17
2-Propanol	ISOPROPYL ALCOHOL	18
Propan-2-ol	ISOPROPYL ALCOHOL	18
<b>N-PROPANOLAMINE</b>		17
3-Propanolide	BETA-PROPIOLACTONE	17
n-Propanol	N-PROPYL ALCOHOL	17
Propanone	ACETONE	18
2-Propanone	ACETONE	18
Propan-2-one	ACETONE	18
Propenamide solution, 50% or less	ACRYLAMIDE SOLUTION (50% OR LESS)	17
<b>2-PROPENE-1-AMINIUM, N,N-DIMETHYL-N-2-PROPENYL-, CHLORIDE, HOMOPOLYMER SOLUTION</b>		17
Propenenitrile	ACRYLONITRILE	17
Propene oxide	PROPYLENE OXIDE	17
Propenoic acid	ACRYLIC ACID	17
2-Propenoic acid, homopolymer solution (40% or less)	POLYACRYLIC ACID SOLUTION (40% OR LESS)	17
1-Propenol-3	ALLYL ALCOHOL	17
2-Propen-1-ol	ALLYL ALCOHOL	17
Prop-2-en-1-ol	ALLYL ALCOHOL	17
Propenyl alcohol	ALLYL ALCOHOL	17
Propiolactone	BETA-PROPIOLACTONE	17
<b>BETA-PROPIOLACTONE</b>		17
<b>PROPIONALDEHYDE</b>		17
<b>PROPIONIC ACID</b>		17
Propionic aldehyde	PROPIONALDEHYDE	17
<b>PROPIONIC ANHYDRIDE</b>		17
<b>PROPIONITRILE</b>		17
beta-Propionolactone	BETA-PROPIOLACTONE	17
Propionitrile	PROPIONITRILE	17
Propionyl oxide	PROPIONIC ANHYDRIDE	17
1-Propoxypropan-2-ol (a)	PROPYLENE GLYCOL MONOALKYL ETHER	17
Propyl acetate	N-PROPYL ACETATE	17
<b>N-PROPYL ACETATE</b>		17
Propyl acetone	METHYL BUTYL KETONE	17
Propyl alcohol	N-PROPYL ALCOHOL	17
2-Propyl alcohol	ISOPROPYL ALCOHOL	18
<b>N-PROPYL ALCOHOL</b>		17
sec-Propyl alcohol	ISOPROPYL ALCOHOL	18
Propyl aldehyde	PROPIONALDEHYDE	17
Propylamine	N-PROPYLAMINE	17
<b>N-PROPYLAMINE</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>PROPYLBENZENE (ALL ISOMERS)</b>		17
n-Propylbenzene (a)	<b>PROPYLBENZENE (ALL ISOMERS)</b>	17
Propylcarbinol	<b>N-BUTYL ALCOHOL</b>	18
Propylene aldehyde	<b>CROTONALDEHYDE</b>	17
2,2'-[Propylenebis(nitrilomethylene)]diphenol in aromatic solvent	<b>ALKYL (C8-C9) PHENYLAMINE IN AROMATIC SOLVENTS</b>	17
<b>PROPYLENE CARBONATE</b>		17
Propylene chloride	<b>1,2-DICHLOROPROPANE</b>	17
Propylene dichloride	<b>1,2-DICHLOROPROPANE</b>	17
alpha,alpha'- (Propylenedinitrilo)di-o-cresol in aromatic solvent	<b>ALKYL (C8-C9) PHENYLAMINE IN AROMATIC SOLVENTS</b>	17
Propylene epoxide	<b>PROPYLENE OXIDE</b>	17
<b>PROPYLENE GLYCOL</b>		18
1,2-Propylene glycol	<b>PROPYLENE GLYCOL</b>	18
Propylene glycol n-butyl ether (a)	<b>PROPYLENE GLYCOL MONOALKYL ETHER</b>	17
Propylene glycol ethyl ether (a)	<b>PROPYLENE GLYCOL MONOALKYL ETHER</b>	17
Propylene glycol methyl ether (a)	<b>PROPYLENE GLYCOL MONOALKYL ETHER</b>	17
<b>PROPYLENE GLYCOL METHYL ETHER ACETATE</b>		17
<b>PROPYLENE GLYCOL MONOALKYL ETHER</b>		17
Propylene glycol monobutyl ether (a)	<b>PROPYLENE GLYCOL MONOALKYL ETHER</b>	17
Propylene glycol beta-monoethyl ether	<b>PROPYLENE GLYCOL MONOALKYL ETHER</b>	17
Propylene glycol monomethyl ether (a)	<b>PROPYLENE GLYCOL MONOALKYL ETHER</b>	17
<b>PROPYLENE GLYCOL PHENYL ETHER</b>		17
Propylene glycol propyl ether (a)	<b>PROPYLENE GLYCOL MONOALKYL ETHER</b>	17
Propylene glycol trimer	<b>TRIPROPYLENE GLYCOL</b>	17
1,2-Propylene glycol trimer	<b>TRIPROPYLENE GLYCOL</b>	17
<b>PROPYLENE OXIDE</b>		17
<b>PROPYLENE TETRAMER</b>		17
<b>PROPYLENE TRIMER</b>		17
Propylethylene (a)	<b>PENTENE (ALL ISOMERS)</b>	17
Propyl methyl ketone	<b>METHYL PROPYL KETONE</b>	17
N-Propyl-1-propanamine	<b>DI-N-PROPYLAMINE</b>	17
Pseudobutylene glycol	<b>BUTYLENE GLYCOL</b>	17
Pseudocumene	<b>TRIMETHYLBENZENE (ALL ISOMERS)</b>	17
Pseudopinene	<b>BETA-PINENE</b>	17
Psuedopinene	<b>BETA-PINENE</b>	17
Pygas	<b>PYROLYSIS GASOLINE (CONTAINING BENZENE)</b>	17
<b>PYRIDINE</b>		17
Pyroacetic acid	<b>ACETONE</b>	18
Pyroacetic ether	<b>ACETONE</b>	18
<b>PYROLYSIS GASOLINE (CONTAINING BENZENE)</b>		17
Pyrolysis gasoline (steam-cracked naphtha)	<b>BENZENE AND MIXTURES HAVING 10% BENZENE OR MORE (I)</b>	17
Pyrolysis gasoline, containing 10% or more benzene	<b>BENZENE AND MIXTURES HAVING 10% BENZENE OR MORE (I)</b>	17
Pyromucic aldehyde	<b>FURFURAL</b>	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
<b>RAPESEED OIL</b>		17
<b>RAPESEED OIL (LOW ERUCIC ACID CONTAINING LESS THAN 4% FREE FATTY ACIDS)</b>		17
<b>RAPE SEED OIL FATTY ACID METHYL ESTERS</b>		17
Refined, bleached, deodorized grape seed oil (RBD)	<b>GRAPE SEED OIL</b>	17
<b>RESIN OIL, DISTILLED</b>		17
<b>RICE BRAN OIL</b>		17
<b>ROSIN</b>		17
<b>SAFFLOWER OIL</b>		17
Saturated fatty acid (C13 and above) (a)	<b>FATTY ACID (SATURATED C13+)</b>	17
<b>SHEA BUTTER</b>		17
Silicofluoric acid solution (20-30%)	<b>FLUOROSILICIC ACID SOLUTION (20-30%)</b>	17
Slack wax	<b>HYDROCARBON WAX</b>	17
Sludge acid	<b>SULPHURIC ACID, SPENT</b>	17
SME	<b>SOYBEAN OIL FATTY ACID METHYL ESTER</b>	17
Soda ash solution	<b>SODIUM CARBONATE SOLUTION (*)</b>	17
Soda lye solution	<b>SODIUM HYDROXIDE SOLUTION (*)</b>	17
<b>SODIUM ACETATE SOLUTIONS</b>		18
Sodium acid sulphite solution (45% or less)	<b>SODIUM HYDROGEN SULPHITE SOLUTION (45% OR LESS)</b>	17
Sodium alkylbenzene sulphonate solution	<b>ALKYLBENZENE SULPHONIC ACID, SODIUM SALT SOLUTION</b>	17
<b>SODIUM ALKYL (C14-C17) SULPHONATES (60-65% SOLUTION)</b>		17
<b>SODIUM ALUMINOSILICATE SLURRY</b>		17
Sodium aminoacetate solution	<b>GLYCINE, SODIUM SALT SOLUTION</b>	17
<b>SODIUM BENZOATE</b>		17
Sodium 1,3-benzothiazole-2-thiolate solution	<b>MERCAPTOBENZOTHIAZOL, SODIUM SALT SOLUTION</b>	17
Sodium 1,3-benzothiazol-2-yl sulphide solution	<b>MERCAPTOBENZOTHIAZOL, SODIUM SALT SOLUTION</b>	17
<b>SODIUM BICARBONATE SOLUTION (LESS THAN 10%)</b>		18
Sodium bichromate solution (70% or less)	<b>SODIUM DICHROMATE SOLUTION (70% OR LESS)</b>	17
Sodium bisulphide solution (45% or less)	<b>SODIUM HYDROSULPHIDE SOLUTION (45% OR LESS) (*)</b>	17
<b>SODIUM BOROHYDRIDE (15% OR LESS)/SODIUM HYDROXIDE SOLUTION (*)</b>		17
<b>SODIUM BROMIDE SOLUTION (LESS THAN 50%) (*)</b>		17
<b>SODIUM CARBONATE SOLUTION (*)</b>		17
Sodium carboxylate solution	<b>CYCLOHEXANE OXIDATION PRODUCTS, SODIUM SALTS SOLUTION</b>	17
<b>SODIUM CHLORATE SOLUTION (50% OR LESS) (*)</b>		17
Sodium cresylate solution	<b>CRESYLIC ACID, SODIUM SALT SOLUTION</b>	17
<b>SODIUM DICHROMATE SOLUTION (70% OR LESS)</b>		17
Sodium glycinate solution	<b>GLYCINE, SODIUM SALT SOLUTION</b>	17
Sodium hydrate solution	<b>SODIUM HYDROXIDE SOLUTION (*)</b>	17
<b>SODIUM HYDROGEN SULPHIDE (6% OR LESS)/SODIUM CARBONATE (3% OR LESS) SOLUTION</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Sodium hydrogensulphide solution (45% or less)	<b>SODIUM HYDROSULPHIDE SOLUTION (45% OR LESS) (*)</b>	17
<b>SODIUM HYDROGEN SULPHITE SOLUTION (45% OR LESS)</b>		17
<b>SODIUM HYDROSULPHIDE/AMMONIUM SULPHIDE SOLUTION (*)</b>		17
<b>SODIUM HYDROSULPHIDE SOLUTION (45% OR LESS) (*)</b>		17
<b>SODIUM HYDROXIDE SOLUTION (*)</b>		17
<b>SODIUM HYPOCHLORITE SOLUTION (15% OR LESS)</b>		17
Sodium lignosulphonate	<b>LIGNINSULPHONIC ACID, SODIUM SALT SOLUTION</b>	17
Sodium methanolate	<b>SODIUM METHYLATE 21-30% IN METHYL ALCOHOL</b>	17
Sodium methoxide	<b>SODIUM METHYLATE 21-30% IN METHYL ALCOHOL</b>	17
<b>SODIUM METHYLATE 21-30% IN METHYL ALCOHOL</b>		17
Sodium methylcarbomethioate	<b>METAM SODIUM SOLUTION</b>	17
Sodium N-methyldithiocarbamate	<b>METAM SODIUM SOLUTION</b>	17
Sodium methylthiocarbamate solution	<b>METAM SODIUM SOLUTION</b>	17
<b>SODIUM NITRITE SOLUTION</b>		17
<b>SODIUM PETROLEUM SULPHONATE</b>		17
<b>SODIUM POLY(4+)ACRYLATE SOLUTIONS</b>		17
Sodium rhodanate solution (56% or less)	<b>SODIUM THIOCYANATE SOLUTION (56% OR LESS)</b>	17
Sodium rhodanide solution (56% or less)	<b>SODIUM THIOCYANATE SOLUTION (56% OR LESS)</b>	17
Sodium salt of sulphonated naphthalene - formaldehyde condensate	<b>NAPHTHALENESULPHONIC ACID-FORMALDEHYDE COPOLYMER, SODIUM SALT SOLUTION</b>	17
<b>SODIUM SILICATE SOLUTION</b>		17
<b>SODIUM SULPHATE SOLUTIONS</b>		17
<b>SODIUM SULPHIDE SOLUTION (15% OR LESS)</b>		17
<b>SODIUM SULPHITE SOLUTION (25% OR LESS)</b>		17
Sodium sulphocyanate solution (56% or less)	<b>SODIUM THIOCYANATE SOLUTION (56% OR LESS)</b>	17
Sodium sulphocyanide solution (56% or less)	<b>SODIUM THIOCYANATE SOLUTION (56% OR LESS)</b>	17
Sodium tetrahydroborate (15% or less) / sodium hydroxide solution	<b>SODIUM BOROHYDRIDE (15% OR LESS)/SODIUM HYDROXIDE SOLUTION (*)</b>	17
<b>SODIUM THIOCYANATE SOLUTION (56% OR LESS)</b>		17
Sodium tolyl oxides solution	<b>CRESYLIC ACID, SODIUM SALT SOLUTION</b>	17
'D-D Soil fumigant'	<b>DICHLOROPROPENE/DICHLOROPROPANE MIXTURES</b>	17
d-Sorbitol solution	<b>SORBITOL SOLUTION</b>	18
<b>SORBITOL SOLUTION</b>		18
d-Sorbitol solution	<b>SORBITOL SOLUTION</b>	18
<b>SOYABEAN OIL</b>		17
Soya Methyl Ester (SME)	<b>SOYBEAN OIL FATTY ACID METHYL ESTER</b>	17
<b>SOYBEAN OIL FATTY ACID METHYL ESTER</b>		17
Soybean Oil Methyl Ester	<b>SOYBEAN OIL FATTY ACID METHYL ESTER</b>	17
Spirit of turpentine	<b>TURPENTINE</b>	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Spirits of wine	ETHYL ALCOHOL	18
Stoddard solvent	WHITE SPIRIT, LOW (15-20%) AROMATIC	17
<b>STYRENE MONOMER</b>		17
Styrol	STYRENE MONOMER	17
Suberane	CYCLOHEPTANE	17
Sulfonic acid, alkane(C10-C21) phenyl ester (a)	ALKYL SULPHONIC ACID ESTER OF PHENOL	17
<b>SULPHOHYDROCARBON (C3-C88)</b>		17
<b>SULPHOLANE</b>		17
<b>SULPHONATED POLYACRYLATE SOLUTION</b>		18
<b>SULPHUR (MOLTEN) (*)</b>		17
<b>SULPHURIC ACID</b>		17
Sulphuric acid, fuming	OLEUM	17
<b>SULPHURIC ACID, SPENT</b>		17
Sulphuric chlorohydrin	CHLOROSULPHONIC ACID	17
Sulphuric ether	DIETHYL ETHER (*)	17
<b>SULPHURIZED FAT (C14-C20)</b>		17
<b>SULPHURIZED POLYOLEFINAMIDE ALKENE (C28-C250) AMINE</b>		17
<b>SUNFLOWER SEED OIL</b>		17
Sweet-birch oil	METHYL SALICYLATE	17
sym-Dichloroethane	ETHYLENE DICHLORIDE	17
sym-Dichloroethyl ether	DICHLOROETHYL ETHER	17
sym-Diisopropylacetone	DIISOBUTYL KETONE	17
sym-Dimethylethylene glycol	BUTYLENE GLYCOL	17
sym-Tetrachloroethane	TETRACHLOROETHANE	17
sym-Trioxane	1,3,5-TRIOXANE	17
<b>TALL OIL, CRUDE</b>		17
<b>TALL OIL, DISTILLED</b>		17
<b>TALL OIL FATTY ACID (RESIN ACIDS LESS THAN 20%)</b>		17
<b>TALL OIL PITCH</b>		17
<b>TALL OIL SOAP, CRUDE</b>		17
<b>TALLOW</b>		17
<b>TALLOW FATTY ACID</b>		17
Tar acids (cresols)	CREOLS (ALL ISOMERS)	17
Tar camphor	NAPHTHALENE (MOLTEN)	17
Terephthalic acid, dibutyl ester	DIBUTYL TEREPHTHALATE	17
3,6,9,12-Tetraazatetradecamethylenediamine	PENTAETHYLENEHEXAMINE	17
3,6,9,12-Tetraazatetradecane-1,14-diamine	PENTAETHYLENEHEXAMINE	17
1,3,5,7-Tetraazatricyclo[3.3.1.1 <sup>3,7</sup> ]decane	HEXAMETHYLENETETRAMINE SOLUTIONS	17
<b>TETRACHLOROETHANE</b>		17
1,1,2,2-Tetrachloroethane	TETRACHLOROETHANE	17
Tetrachloroethylene	PERCHLOROETHYLENE	17
1,1,2,2-tetrachloroethylene	PERCHLOROETHYLENE	17
Tetrachloromethane	CARBON TETRACHLORIDE	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Tetradecan-1-ol	ALCOHOLS (C14-C18), PRIMARY, LINEAR AND ESSENTIALLY LINEAR	17
1-Tetradecanol	ALCOHOLS (C14-C18), PRIMARY, LINEAR AND ESSENTIALLY LINEAR	17
Tetradecene (a)	OLEFINS (C13+, ALL ISOMERS)	17
Tetradecylbenzene	ALKYL(C9+)BENZENES	17
<b>TETRAETHYLENE GLYCOL</b>		17
<b>TETRAETHYLENE PENTAMINE</b>		17
Tetraethyllead	MOTOR FUEL ANTI-KNOCK COMPOUND (CONTAINING LEAD ALKYL)	17
Tetraethylplumbane	MOTOR FUEL ANTI-KNOCK COMPOUND (CONTAINING LEAD ALKYL)	17
<b>TETRAETHYL SILICATE MONOMER/OLIGOMER (20% IN ETHANOL)</b>		18
3a,4,7,7a-Tetrahydro-3,5-dimethyl-4,7-methano-1H-indene	METHYLCYCLOPENTADIENE DIMER	17
<b>TETRAHYDROFURAN</b>		17
<b>TETRAHYDRONAPHTHALENE</b>		17
1,2,3,4-Tetrahydronaphthalene	TETRAHYDRONAPHTHALENE	17
Tetrahydro-1,4-oxazine	MORPHOLINE	17
2H-Tetrahydro-1,4-oxazine	MORPHOLINE	17
Tetrahydro-2H-1,4-oxazine	MORPHOLINE	17
Tetrahydrothiophene-1-dioxide	SULPHOLANE	17
Tetrahydrothiophene 1,1-dioxide	SULPHOLANE	17
Tetralin	TETRAHYDRONAPHTHALENE	17
<b>TETRAMETHYLBENZENE (ALL ISOMERS)</b>		17
1,2,3,4-Tetramethylbenzene (a)	TETRAMETHYLBENZENE (ALL ISOMERS)	17
1,2,3,5-Tetramethylbenzene (a)	TETRAMETHYLBENZENE (ALL ISOMERS)	17
1,2,4,5-Tetramethylbenzene (a)	TETRAMETHYLBENZENE (ALL ISOMERS)	17
Tetramethylene cyanide	ADIPONITRILE	17
Tetramethylene dicyanide	ADIPONITRILE	17
Tetramethylene glycol (a)	BUTYLENE GLYCOL	17
Tetramethylene oxide	TETRAHYDROFURAN	17
Tetramethylenesulphone	SULPHOLANE	17
Tetramethyllead	MOTOR FUEL ANTI-KNOCK COMPOUND (CONTAINING LEAD ALKYL)	17
Tetrapropylbenzene	ALKYL(C9+)BENZENES	17
Tetrapropylenebenzene	DODECYLBENZENE	17
Tetryl formate	ISOBUTYL FORMATE	17
4-thiapentanal	3-(METHYLTHIO)PROPIONALDEHYDE	17
Thiophan sulphone	SULPHOLANE	17
Thiosulphuric acid, dipotassium salt (50% or less)	POTASSIUM THIOSULPHATE (50% OR LESS)	17
Titanium(IV) oxide slurry	TITANIUM DIOXIDE SLURRY	17
<b>TITANIUM DIOXIDE SLURRY</b>		17
<b>TOLUENE</b>		17
<b>TOLUENEDIAMINE</b>		17
2,4-Toluenediamine (a)	TOLUENEDIAMINE	17
2,6-Toluenediamine (a)	TOLUENEDIAMINE	17
<b>TOLUENE DIISOCYANATE</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
2-Toluidine	O-TOLUIDINE	17
<b>O-TOLUIDINE</b>		17
Toluol	TOLUENE	17
o-Tolylamine	O-TOLUIDINE	17
2,4-Tolylenediamine (a)	TOLUENEDIAMINE	17
2,6-Tolylenediamine (a)	TOLUENEDIAMINE	17
Tolylenediisocyanate	TOLUENE DIISOCYANATE	17
2,4-Tolylene diisocyanate	TOLUENE DIISOCYANATE	17
m-Tolylene diisocyanate	TOLUENE DIISOCYANATE	17
Toxilic anhydride	MALEIC ANHYDRIDE	17
Treacle (a)	MOLASSES	18
Triacetin	GLYOXAL SOLUTION (40% OR LESS)	17
3,6,9-Triazaundecamethylenediamine	TETRAETHYLENE PENTAMINE	17
3,6,9-Triazaundecane-1,11-diamine	TETRAETHYLENE PENTAMINE	17
<b>TRIBUTYL PHOSPHATE</b>		17
<b>1,2,3-TRICHLOROENZENE (MOLTEN)</b>		17
<b>1,2,4-TRICHLOROENZENE</b>		17
<b>1,1,1-TRICHLOROETHANE</b>		17
<b>1,1,2-TRICHLOROETHANE</b>		17
beta-Trichloroethane	1,1,2-TRICHLOROETHANE	17
Trichloroethene	TRICHLOROETHYLENE	17
<b>TRICHLOROETHYLENE</b>		17
Trichloromethane	CHLOROFORM	17
<b>1,2,3-TRICHLOROPROPANE</b>		17
<b>1,1,2-TRICHLORO-1,2,2-TRIFLUOROETHANE</b>		17
<b>TRICRESYL PHOSPHATE (CONTAINING 1% OR MORE ORTHO-ISOMER)</b>		17
<b>TRICRESYL PHOSPHATE (CONTAINING LESS THAN 1% ORTHO-ISOMER)</b>		17
<b>TRIDECANE</b>		17
<b>TRIDECANOIC ACID</b>		17
Tridecanol (a)	ALCOHOLS (C13+)	17
Tridecene (a)	OLEFINS (C13+, ALL ISOMERS)	17
Tridecoic acid	TRIDECANOIC ACID	17
<b>TRIDECYL ACETATE</b>		17
Tridecyl alcohol (a)	ALCOHOLS (C13+)	17
Tridecylbenzene	ALKYL(C9+)BENZENES	17
Tridecylic acid	TRIDECANOIC ACID	17
Tridecylic acid (a)	FATTY ACID (SATURATED C13+)	17
Tri(dimethylphenyl) phosphate (all isomers)	TRIXYLYL PHOSPHATE	17
<b>TRIETHANOLAMINE</b>		17
<b>TRIETHYLAMINE</b>		17
<b>TRIETHYLBENZENE</b>		17
<b>TRIETHYLENE GLYCOL</b>		18
Triethylene glycol butyl ether (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Triethylene glycol ethyl ether (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
Triethylene glycol methyl ether (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
Triethylene glycol monobutyl ether (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17
<b>TRIETHYLENETETRAMINE</b>		17
<b>TRIETHYL PHOSPHATE</b>		17
<b>TRIETHYL PHOSPHITE</b>		17
Triformol	1,3,5-TRIOXANE	17
Triglycol	TRIETHYLENE GLYCOL	18
Trihydroxypropane	GLYCERINE	17
Trihydroxytriethylamine	TRIETHANOLAMINE	17
<b>TRISOPROPANOLAMINE</b>		17
<b>TRISOPROPYLATED PHENYL PHOSPHATES</b>		17
<b>TRIMETHYLACETIC ACID</b>		17
<b>TRIMETHYLAMINE SOLUTION (30% OR LESS)</b>		17
<b>TRIMETHYLBENZENE (ALL ISOMERS)</b>		17
1,2,3-Trimethylbenzene (a)	TRIMETHYLBENZENE (ALL ISOMERS)	17
1,2,4-Trimethylbenzene (a)	TRIMETHYLBENZENE (ALL ISOMERS)	17
1,3,5-Trimethylbenzene (a)	TRIMETHYLBENZENE (ALL ISOMERS)	17
2,6,6-Trimethylbicyclo[3.1.1]hept-2-ene	ALPHA-PINENE	17
Trimethylcarbinol	TERT-BUTYL ALCOHOL	17
1,1,3-Trimethyl-3-cyclohexene-5-one	ISOPHORONE	17
3,5,5-Trimethylcyclohex-2-enone	ISOPHORONE	17
3,5,5-Trimethylcyclohex-2-en-one	ISOPHORONE	17
<b>TRIMETHYLOL PROPANE PROPOXYLATED</b>		17
2,2,4-Trimethylpentane (a)	OCTANE (ALL ISOMERS)	17
<b>2,2,4-TRIMETHYL-1,3-PENTANEDIOL DIISOBUTYRATE</b>		17
2,2,4-Trimethylpentane-1,3-diol diisobutyrate	2,2,4-TRIMETHYL-1,3-PENTANEDIOL DIISOBUTYRATE	17
<b>2,2,4-TRIMETHYL-1,3-PENTANEDIOL-1-ISOBUTYRATE</b>		17
2,4,4-Trimethylpentene-1	DIISOBUTYLENE	17
2,4,4-Trimethylpent-1-ene	DIISOBUTYLENE	17
2,4,4-Trimethylpentene-2	DIISOBUTYLENE	17
2,4,4-Trimethylpent-2-ene	DIISOBUTYLENE	17
2,4,6-Trimethyl-1,3,5-trioxane	PARALDEHYDE	17
2,4,6-Trimethyl-s-trioxane	PARALDEHYDE	17
Trioxan	1,3,5-TRIOXANE	17
<b>1,3,5-TRIOXANE</b>		17
5,8,11-Trioxapentadecane	DIETHYLENE GLYCOL DIBUTYL ETHER	17
3,6,9-Trioxaundecane	DIETHYLENE GLYCOL DIETHYL ETHER	17
Trioxymethylene	1,3,5-TRIOXANE	17
Tripropylene	PROPYLENE TRIMER	17
<b>TRIPROPYLENE GLYCOL</b>		17
Tripropylene glycol methyl ether (a)	POLY(2-8)ALKYLENE GLYCOL MONOALKYL(C1-C6) ETHER	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
Tris(dimethylphenyl) phosphate (all isomers)	TRIXYLYL PHOSPHATE	17
Tris(2-hydroxyethyl)amine	TRIETHANOLAMINE	17
2,4-D-tris(2-hydroxy-2-methylethyl)ammonium	2,4-DICHLOROPHENOXYACETIC ACID, TRIISOPROPANOLAMINE SALT SOLUTION	17
Tris(2-hydroxypropyl)amine	TRIISOPROPANOLAMINE	17
Tris(2-hydroxy-1-propyl)amine	TRIISOPROPANOLAMINE	17
Tris(2-hydroxypropyl)ammonium 2,4-dichlorophenoxyacetate solution	2,4-DICHLOROPHENOXYACETIC ACID, TRIISOPROPANOLAMINE SALT SOLUTION	17
Trisodium 2-[carboxylatomethyl(2-hydroxyethyl)amino]ethyliminodi(acetate) solution	N-(HYDROXYETHYL)ETHYLENEDIAMINETRIACETIC ACID, TRISODIUM SALT SOLUTION	17
Trisodium N-(carboxymethyl)-N'-(2-hydroxyethyl)-N,N'-ethylenediglycine solution	N-(HYDROXYETHYL)ETHYLENEDIAMINETRIACETIC ACID, TRISODIUM SALT SOLUTION	17
Trisodium N-(2-hydroxyethyl)ethylenediamine-N,N',N'-triacetate solution	N-(HYDROXYETHYL)ETHYLENEDIAMINETRIACETIC ACID, TRISODIUM SALT SOLUTION	17
Trisodium nitrilotriacetate solution	NITRILOTRIACETIC ACID, TRISODIUM SALT SOLUTION	17
Tritolyl phosphate, containing less than 1% ortho- isomer	TRICRESYL PHOSPHATE (CONTAINING LESS THAN 1% ORTHO-ISOMER)	17
Tritolyl phosphate, containing 1% or more ortho- isomer	TRICRESYL PHOSPHATE (CONTAINING 1% OR MORE ORTHO-ISOMER)	17
Trixylenyl phosphate	TRIXYLYL PHOSPHATE	17
<b>TRIXYLYL PHOSPHATE</b>		17
<b>TUNG OIL</b>		17
<b>TURPENTINE</b>		17
Turpentine oil	TURPENTINE	17
Turps	TURPENTINE	17
Type A Zeolite slurry (a)	SODIUM ALUMINOSILICATE SLURRY	17
1-Undecanecarboxylic acid	LAURIC ACID	17
N-Undecane (a)	N-ALKANES (C10-C20)	17
<b>UNDECANOIC ACID</b>		17
Undecan-1-ol	UNDECYL ALCOHOL	17
<b>1-UNDECENE</b>		17
Undec-1-ene	1-UNDECENE	17
<b>UNDECYL ALCOHOL</b>		17
Undecylbenzene	ALKYL(C9+)BENZENES	17
Undecylic acid	UNDECANOIC ACID	17
n-Undecylic acid	UNDECANOIC ACID	17
uns-Trimethylbenzene (a)	TRIMETHYLBENZENE (ALL ISOMERS)	17
unsym-Trichlorobenzene	1,2,4-TRICHLOROBENZENE	17
<b>UREA/AMMONIUM NITRATE SOLUTION</b>		17
<b>UREA/AMMONIUM PHOSPHATE SOLUTION</b>		17
<b>UREA SOLUTION</b>		17
<b>USED COOKING OIL (M)</b>		17
<b>USED COOKING OIL (TRIGLYCERIDES, C16-C18 AND C18 UNSATURATED)** (M)</b>		17
Valeral	VALERALDEHYDE (ALL ISOMERS)	17
<b>VALERALDEHYDE (ALL ISOMERS)</b>		17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
n-Valeraldehyde	VALERALDEHYDE (ALL ISOMERS)	17
Valerianic acid	PENTANOIC ACID	17
Valeric acid	PENTANOIC ACID	17
n-Valeric acid	PENTANOIC ACID	17
Valeric aldehyde	VALERALDEHYDE (ALL ISOMERS)	17
Valerone	DIISOBUTYL KETONE	17
Vaseline (cosmetic)	PARAFFIN WAX, HIGHLY-REFINED	17
<b>VEGETABLE ACID OILS (M)</b>		17
<b>VEGETABLE FATTY ACID DISTILLATES (M)</b>		17
<b>VEGETABLE OIL MIXTURES, CONTAINING LESS THAN 15% FREE FATTY ACID (M)</b>		17
<b>VEGETABLE PROTEIN SOLUTION (HYDROLYSED)</b>		18
Vinegar acid	ACETIC ACID	17
Vinegar naphtha	ETHYL ACETATE	17
<b>VINYL ACETATE</b>		17
Vinylbenzene	STYRENE MONOMER	17
Vinylcarbinol	ALLYL ALCOHOL	17
Vinyl cyanide	ACRYLONITRILE	17
vinyl ethanoate	VINYL ACETATE	17
<b>VINYL ETHYL ETHER</b>		17
Vinylformic acid	ACRYLIC ACID	17
<b>VINYLDENE CHLORIDE</b>		17
<b>VINYL NEODECANOATE</b>		17
<b>VINYLTOLUENE</b>		17
Vinyltoluene (all isomers)	VINYLTOLUENE	17
Vinyl trichloride	1,1,2-TRICHLOROETHANE	17
Vitriol brown oil	SULPHURIC ACID	17
<b>WATER</b>		18
Water glass solutions	SODIUM SILICATE SOLUTION	17
White bole	KAOLIN SLURRY	18
White caustic solution	SODIUM HYDROXIDE SOLUTION (*)	17
<b>WHITE SPIRIT, LOW (15-20%) AROMATIC</b>		17
White tar	NAPHTHALENE (MOLTEN)	17
Wine (a)	ALCOHOLIC BEVERAGES, N.O.S.	18
Wintergreen oil	METHYL SALICYLATE	17
Wood alcohol	METHYL ALCOHOL (*)	17
<b>WOOD LIGNIN WITH SODIUM ACETATE/OXALATE</b>		17
Wood naphtha	METHYL ALCOHOL (*)	17
Wood spirit	METHYL ALCOHOL (*)	17
<b>XYLENES</b>		17
<b>XYLENES/ETHYLBENZENE (10% OR MORE) MIXTURE</b>		17
<b>XYLENOL</b>		17
Xylenol (all isomers)	XYLENOL	17
2,3-Xylenol (a)	XYLENOL	17
2,4-Xylenol (a)	XYLENOL	17

<b>Index Name</b>	<b>Product Name</b>	<b>Chapter</b>
2,5-Xylenol (a)	<b>XYLENOL</b>	17
2,6-Xylenol (a)	<b>XYLENOL</b>	17
3,4-Xylenol (a)	<b>XYLENOL</b>	17
3,5-Xylenol (a)	<b>XYLENOL</b>	17
Xylols	<b>XYLENES</b>	17
<b>ZINC ALKARYL DITHIOPHOSPHATE (C7-C16)</b>		17
<b>ZINC ALKENYL CARBOXAMIDE</b>		17
<b>ZINC ALKYL DITHIOPHOSPHATE (C3-C14)</b>		17
Zinc bromide drilling brine	<b>DRILLING BRINES (CONTAINING ZINC CHLORIDE)</b>	17
z-Octadec-9-enamine	<b>OLEYLAMINE</b>	17
(Z)-Octadec-9-enoic acid	<b>OLEIC ACID</b>	17
Z-Octadec-9-enoic acid	<b>OLEIC ACID</b>	17
(Z)-Octadec-9-enylamine	<b>OLEYLAMINE</b>	17

”

7 The complete text of chapter 21 is replaced by the following:

## **"Chapter 21**

### **Criteria for assigning carriage requirements for products subject to the IBC Code**

#### **21.1 Introduction**

21.1.1 The following criteria are used for the determination of pollution classification and assignment of appropriate carriage requirements for bulk liquid cargoes being assessed for entry into the IBC Code or lists 1, 3 or 4 of the MEPC.2/Circular.

21.1.2 In developing such criteria, every effort has been made to follow the criteria and cut-off points developed under the Globally Harmonized System (GHS).

21.1.3 Although the criteria are intended to be closely defined in order to establish a uniform approach, it must be emphasized that where human experience or other factors indicate the need for alternative arrangements, these shall always be taken into account. Where deviations from the criteria have been recognized, they shall be properly recorded with justifications.

#### **21.2 Contents**

21.2.1 This chapter contains the following:

- .1 minimum safety and pollution criteria for products subject to chapter 17 of the IBC Code;
- .2 criteria used to assign the minimum carriage requirements for products that meet the safety or pollution criteria to make them subject to chapter 17 of the IBC Code;
- .3 criteria used for determining special requirements in chapter 15 of the IBC Code to be included in *column o* of chapter 17 of the IBC Code;
- .4 criteria used for determining special requirements in chapter 16 of the IBC Code to be included in *column o* of chapter 17 of the IBC Code;
- .5 definitions of properties used within this chapter;
- .6 information on the use of the GESAMP Hazard Ratings; and
- .7 information on the application of the SVC/LC<sub>50</sub> ratio method.

21.2.2 The information included in parentheses following the classification criteria throughout this chapter refers to the GESAMP Hazard Profile ratings set out in appendix I of MARPOL Annex II under the "Abbreviated legend to the revised GESAMP Hazard Evaluation procedure". The full listing of GESAMP Hazard Profile ratings for evaluated substances are published annually in the GESAMP Composite List as a PPR circular. It should be noted that ratings in parentheses (based on estimation methods applied by GESAMP) are considered as equivalent to ratings without parentheses for the purpose of assigning carriage requirements.

### **21.3 Minimum safety and pollution criteria for products subject to chapter 17 of the IBC Code**

21.3.1 Products are deemed to be hazardous and subject to chapter 17 of the IBC Code if they meet one or more of the following criteria:

- .1 inhalation  $LC_{50}/ATE \leq 20$  mg/L/4h (see paragraph 21.7.1.3) (C3 = 1, 2, 3 or 4);
- .2 dermal  $LD_{50}/ATE \leq 2000$  mg/kg (see paragraph 21.7.1.2) (C2 = 1, 2, 3, or 4);
- .3 oral  $LD_{50}/ATE \leq 2000$  mg/kg (see paragraph 21.7.1.1) (C1 = 1, 2, 3, or 4);
- .4 toxic to mammals by prolonged exposure (see paragraph 21.7.2) (D3 = C, M, R, N, T, or I);
- .5 cause skin sensitization (see paragraph 21.7.3) (D3 = Ss);
- .6 cause respiratory sensitization (see paragraph 21.7.4) (D3 = Sr);
- .7 corrosive to skin (see paragraph 21.7.5) (D1 = 3, 3A, 3B, or 3C);
- .8 with a Water Reactive Index (WRI) of  $\geq 1$  (see paragraph 21.7.6);
- .9 require inertion, inhibition, stabilization, temperature control or tank environmental control in order to prevent a hazardous reaction (see definitions in paragraph 21.7.10);
- .10 flashpoint  $< 23^{\circ}C$ ; and have an explosive/flammability range (expressed as a percentage by volume in air) of  $\geq 20\%$ ;
- .11 auto-ignition temperature of  $\leq 200^{\circ}C$ ; and
- .12 classified as pollution category X or Y or meeting the criteria for rules 11 to 13 in table 2 in paragraph 21.4.5.2.

### **21.4 Criteria used to assign the minimum carriage requirements for products that meet the minimum safety or pollution criteria to make them subject to chapter 17 of the IBC Code**

#### **21.4.1 Column a – Product name**

21.4.1.1 A standardized chemical name, preferably assigned on the basis of the Chemical Abstracts Service (CAS) or the International Union of Pure and Applied Chemistry (IUPAC) system, shall be used as far as possible. However, where this is unnecessarily complex, then a technically correct and unambiguous alternative name may be used.

#### **21.4.2 Column b – Deleted**

#### **21.4.3 Column c – Pollution category**

21.4.3.1 *Column c* identifies the pollution category assigned to each product in accordance with MARPOL Annex II, based on table 1 below (see MARPOL Annex II, appendix I).

**Table 1 – Guidelines for the categorization of Noxious Liquid Substances**

Rule	A1 Bio- accumulation	A2 Bio- degradation	B1 Acute toxicity	B2 Chronic toxicity	D3 Long-term health effects	E2 Effects on marine wildlife and on benthic habitats	Cat
1			≥ 5				X
2	≥ 4		4				
3		NR	4				
4	≥ 4	NR			CMRTNI <sup>1</sup>		Y
5			4				
6			3				
7			2				
8	≥ 4	NR		Not 0			
9				≥ 1			
10						Fp, F or S If not Inorganic	
11					CMRTNI <sup>1</sup>		
12	Any product not meeting the criteria of rules 1 to 11 and 13						Z
13	All products identified as: ≤ 2 in column A1; R in column A2; blank in column D3; not Fp, F or S (if not organic) in column E2; and 0 (zero) in all other columns of the GESAMP Hazard Profile						OS

#### 21.4.4 Column d – Hazards

21.4.4.1 An "S" is assigned to *column d* if any of the safety criteria described in paragraphs 21.3.1.1 to 21.3.1.11 are met.

21.4.4.2 A "P" is assigned to *column d* if the product meets the criteria for assigning Ship Type 1 to 3 as defined by rules 1 to 14 in the table 2.

#### 21.4.5 Column e – Ship Type

21.4.5.1 Assignment of Ship Types is carried out from both a pollution and safety perspective. The basic criteria for assigning Ship Types from a pollution perspective is carried out based on the GESAMP Hazard Profile, shown in table 2. An explanation of the details in the columns is provided in appendix I of MARPOL Annex II.

21.4.5.2 The following criteria are used to assign the Ship Type:

##### *Ship Type 1:*

- Inhalation LC<sub>50</sub>/ATE ≤ 0.5 mg/L/4h (C3 = 4) and SVC/LC<sub>50</sub> ≥ 20; and/or
- Dermal LD<sub>50</sub>/ATE ≤ 50 mg/kg (C2 = 4); and/or
- WRI = 3; and/or
- Auto-ignition temperature ≤ 65°C; and/or
- Explosive range ≥ 50% v/v in air and the flashpoint < 23°C; and/or
- Rules 1 or 2 of the table 2 shown in 21.4.5.2 (below).

<sup>1</sup> Applies if the D3 rating contains any of these letters or any combination thereof.

**Ship Type 2:**

Inhalation LC<sub>50</sub>/ATE ≤ 0.5 mg/L/4h (C3 = 4) and SVC/LC<sub>50</sub> < 20; or  
 Inhalation LC<sub>50</sub>/ATE > 0.5 mg/L/4h – ≤ 2mg/L/4h (C3 = 3) and SVC/LC<sub>50</sub> ≥ 2 (see note); and/or  
 Dermal LD<sub>50</sub>/ATE > 50 mg/kg – ≤ 200 mg/kg (C2 = 3); and/or  
 WRI = 2; and/or  
 Auto-ignition temperature ≤ 200°C; and/or  
 Explosive range ≥ 40% v/v in air and the flashpoint < 23°C; and/or  
 Any product meeting the criteria of rules 3 to 10 in table 2.

**Note:** Products with a density >1025 kg/m<sup>3</sup> (sinkers) or a water solubility of >50% (dissolvers) that are assigned to Ship Type 2 based on the inhalation toxicity criteria, may be re-assigned to Ship Type 3.

**Ship Type 3:**

Any of the minimum safety or pollution criteria for bulk liquid cargoes subject to chapter 17 of the IBC Code not meeting the requirements for Ship Types 1 or 2 and not meeting rule 15 of table 2 shown in 21.4.5.2 (below).

**Table 2 – Assignment of Ship Types based on the GESAMP Hazard Profile**

Rule	A1	A2	B1	B2	D3	E2	Ship Type
1			≥ 5				1
2	≥ 4	NR	4		CMRTNI <sup>2</sup>		
3	≥ 4	NR			CMRTNI <sup>2</sup>		
4			4				2
5	≥ 4		3				
6		NR	3				
7				≥ 1			
8						Fp	
9					CMRTNI <sup>2</sup>	F	
10			≥ 2			S	3
11	≥ 4						
12		NR					
13			≥ 1				
14	All other category Y Substances						NA
15	All other category Z Substances All "Other Substances" (OS)						

**21.4.6 Column f – Tank type**

21.4.6.1 The tank type is assigned according to the following criteria:

Tank type 1G: Inhalation LC<sub>50</sub>/ATE ≤ 0.5 mg/L/4h (C3 = 4) and SVC/LC<sub>50</sub> ≥ 1000; and/or  
 Dermal LD<sub>50</sub>/ATE ≤ 50 mg/kg (C2 = 4); and/or;  
 WRI=3; and/or  
 Auto-ignition temperature ≤ 65°C; and/or

<sup>2</sup> Applies if the D3 rating contains any of these letters or any combination thereof.

Explosive range  $\geq 40\%$  v/v in air and the flashpoint  $< 23^{\circ}\text{C}$ .  
Based on expert judgement, tank type 1G may be required for specific products (e.g. for molten sulphur, hydrochloric acid).

Tank type 2G: Any of the minimum safety or pollution criteria for bulk liquid cargoes subject to chapter 17 or the IBC Code not meeting the requirements for tank type 1G.

#### **21.4.7 Column g – Tank vents**

21.4.7.1 The tank venting arrangements are assigned according to the following criteria:

Controlled: Inhalation  $\text{LC}_{50}/\text{ATE} \leq 10 \text{ mg/L/4h}$  (C3 = 2, 3 or 4), unless in accordance with 21.7.12; and/or  
Toxic to mammals by prolonged exposure (D3 = C, M, R, T, N, or I); and/or  
Respiratory sensitizer (D3 = Sr, see also paragraph 21.7.4); and/or  
Special carriage control needed; and/or  
Flashpoint  $\leq 60^{\circ}\text{C}$ ; and  
Corrosive to skin ( $\leq 4\text{h}$  exposure). (D1 = 3A, 3B, or 3C).

Open: Any of the minimum safety or pollution criteria for bulk liquid cargoes subject to chapter 17 or the IBC Code not meeting the requirements for controlled tank vents.

#### **21.4.8 Column h – Tank environmental control**

21.4.8.1 The tank environmental control conditions are assigned according to the following criteria:

Inert: Auto-ignition temperature  $\leq 200^{\circ}\text{C}$ ; and/or  
Reacts with air to cause a hazard; and/or  
Explosive range  $\geq 40\%$  and the flashpoint  $< 23^{\circ}\text{C}$ .  
Dry: WRI  $> 1$   
Pad: Only applies to specific products identified on a case by case basis.  
Vent: Only applies to specific products identified on a case by case basis.  
No: Where the above criteria do not apply (inerting requirements may be required under SOLAS).

#### **21.4.9 Column i – Electrical equipment**

21.4.9.1 If the flashpoint of the product is  $\leq 60^{\circ}\text{C}$  or the product is heated to within  $15^{\circ}\text{C}$  of its flashpoint then the electrical equipment required are assigned according to the following criteria, otherwise "-" is assigned in column *i'* and *i''*:

##### **.1 Column i' – Temperature class:**

T1	Auto-ignition temperature $\geq 450^{\circ}\text{C}$
T2	Auto-ignition temperature $\geq 300^{\circ}\text{C}$ but $< 450^{\circ}\text{C}$
T3	Auto-ignition temperature $\geq 200^{\circ}\text{C}$ but $< 300^{\circ}\text{C}$
T4	Auto-ignition temperature $\geq 135^{\circ}\text{C}$ but $< 200^{\circ}\text{C}$
T5	Auto-ignition temperature $\geq 100^{\circ}\text{C}$ but $< 135^{\circ}\text{C}$
T6	Auto-ignition temperature $\geq 85^{\circ}\text{C}$ but $< 100^{\circ}\text{C}$

.2 **Column i'' – Apparatus group:**

Apparatus group	MESG at 20°C (mm)	MIC ratio product/methane
IIA	> 0.90	> 0.80
IIB	> 0.50 to ≤ 0.90	> 0.45 to ≤ 0.80
IIC	≤ 0.50	≤ 0.45

- .1 The tests shall be carried out in accordance with the procedures described in IEC 60079-1-1:2002 and IEC 79-3.
- .2 For gases and vapours it is sufficient to make only one determination of either the Maximum Experimental Safe Gap (MESG) or the Minimum Igniting Current (MIC) provided that:
- for Group IIA: the MESG > 0.90 mm or the MIC ratio > 0.80  
for Group IIB: the MESG is > 0.50 mm and ≤ 0.90 mm; or the MIC ratio is > 0.50 and ≤ 0.80  
for Group IIC: the MESG is ≤ 0.50 mm or the MIC ratio is ≤ 0.45
- .3 It is necessary to determine both the MESG and the MIC ratio when:
- .1 the MIC ratio determination only has been made, and the ratio is between 0.80 and 0.90, when an MESG determination will be required;
- .2 the MIC ratio determination only has been made, and the ratio is between 0.45 and 0.50, when an MESG determination will be required; or
- .3 the MESG only has been found, and is between 0.50 mm and 0.55 mm, when an MIC ratio determination will be required.

.3 **Column i''' Flashpoint:**

> 60°C	Yes
≤ 60°C	No
Non-flammable	NF

**21.4.10 Column j – Gauging**

21.4.10.1 The gauging equipment is assigned according to the following criteria:

- Closed: Inhalation LC<sub>50</sub>/ATE ≤ 2 mg/L/4h (C3 = 3 or 4), unless in accordance with 21.7.12; and/or  
Dermal LD<sub>50</sub>/ATE ≤ 1000 mg/kg (C2 = 2, 3 or 4); and/or  
Toxic to mammals by prolonged exposure (D3 = C, M, R, T, N, or I); and/or  
Respiratory sensitizer (D3 = Sr, see also paragraph 21.7.4); and/or  
Severely corrosive to skin (≤ 3 min exposure) (D1= 3C).

- Restricted: Inhalation LC<sub>50</sub>/ATE >2 - ≤10 mg/L/4h (C3 = 2), unless in accordance with 21.7.12; and/or  
Special carriage control indicates inerting required; and/or  
Highly corrosive to skin (> 3 min - ≤1h exposure) (D1 = 3B); and/or  
Flashpoint ≤ 60°C.
- Open: Any of the minimum safety or pollution criteria for bulk liquid cargoes subject to chapter 17 or the IBC Code not meeting the requirements for closed or restricted gauging.

#### 21.4.11 *Column k* – Vapour detection

21.4.11.1 The vapour detection equipment is assigned according to the following criteria:

- Toxic (T): Inhalation LC<sub>50</sub>/ATE ≤ 10 mg/L/4h (C3 = 2, 3, or 4), unless in accordance with 21.7.12, and/or  
Respiratory sensitizer (D3 = Sr, see also paragraph 21.7.4); and/or  
Toxic to mammals by prolonged exposure (D3 = C, M, R, T, N, or I).
- Flammable (F): Flashpoint ≤ 60°C
- No (No): Where the above criteria do not apply

#### 21.4.12 *Column l* – Fire protection equipment

21.4.12.1 The appropriate firefighting media are defined as being appropriate according to the following criteria related to the properties of the product:

- |                                  |    |  |
|----------------------------------|----|--|
| Solubility > 10% (> 100000 mg/L) | A  | Alcohol-resistant foam.  |
| Solubility ≤ 10% (≤ 100000 mg/L) | A  | Alcohol-resistant foam; and/or   |
|                                  | B  | Regular foam.  |
| WRI = 0                          | C  | Water spray (generally used as a coolant and can be used with A and/or B providing that the WRI = 0).                      |
|                                  | D  | Dry chemical.  |
| WRI ≥1                           | No | No requirements under this Code. This applies where a product is identified as NF in column i" (see paragraph 21.4.9.1.3). |

**Note:** all appropriate media shall be listed.

#### 21.4.13 *Column m* – Deleted

#### **21.4.14 Column n – Emergency equipment**

21.4.14.1 The requirement to have personnel emergency equipment on board is identified by "Yes" in *column n* according to the following criteria:

Inhalation  $LC_{50}/ATE \leq 2$  mg/L/4h (C3 = 3 or 4); unless in accordance with 21.7.12;  
and/or  
Respiratory sensitizer (D3 = Sr, see also paragraph 21.7.4); and/or  
Severely corrosive to skin ( $\leq 3$  min exposure) (D1 = 3C); and/or  
WRI = 2

No: indicates that the above criteria do not apply.

#### **21.5 Column o – Criteria for special requirements in chapter 15**

21.5.1 The assignment of special requirements in *column o* shall normally follow clear criteria based on the data supplied in the reporting form. Where it is considered appropriate to deviate from such criteria, this shall be clearly documented in such a way that it can easily be retrieved on demand.

21.5.2 The criteria for making reference to the special requirements identified in chapters 15 and 16 are defined below with comments where relevant.

##### **21.5.3 Paragraphs 15.2 to 15.10 and 15.20**

21.5.3.1 Paragraphs 15.2 to 15.10 and 15.20 identify specific products by name with special carriage requirements that cannot be easily accommodated in any other way.

##### **21.5.4 Paragraph 15.11 – Acids**

21.5.4.1 Paragraph 15.11 applies to all acids unless they:

- .1 are organic acids – when only paragraphs 15.11.2 to 15.11.4 and paragraphs 15.11.6 to 15.11.8 apply; or
- .2 do not evolve hydrogen – when paragraph 15.11.5 need not apply.

##### **21.5.5 Paragraph 15.12 – Toxic products**

21.5.5.1 All of paragraph 15.12 is added to *column o* according to the following criteria:

Inhalation  $LC_{50}/ATE \leq 2$  mg/L/4h (C3 = 3 or 4), unless in accordance with 21.7.12;  
and/or  
the product is a respiratory sensitizer (D3 = Sr, see also paragraph 21.7.4); and/or  
the product is toxic to mammals by prolonged exposure (D3 = C, M, R, T, N, or I).

21.5.5.2 Paragraphs 15.12.3 and 15.12.4 are added to *column o* according to the following criterion:

Inhalation  $LC_{50}/ATE > 2 - \leq 10$  mg/L/4h (C3 = 2), unless in accordance with 21.7.12.

21.5.5.3 Paragraph 15.12.3.2 is added to *column o* according to the following criteria:

Dermal  $LD_{50}/ATE \leq 1000$  mg/kg (C2 = 2, 3, or 4); and/or  
Oral  $LD_{50}/ATE \leq 300$  mg/kg (C1 = 2, 3, or 4).

### **21.5.6 Paragraph 15.13 – Cargoes protected by additives**

21.5.6.1 The requirement to assign paragraph 15.13 to *column o* is based on the information related to the product's tendency to polymerize, decompose, oxidize or undergo other chemical changes which may cause a hazard under normal carriage conditions, but which would be prevented by the addition of appropriate additives.

### **21.5.7 Paragraph 15.14 – Cargoes with a vapour pressure greater than atmospheric at 37.8°C**

21.5.7.1 The requirement to assign paragraph 15.14 to *column o* is based on the following criterion:

Boiling point  $\leq 37.8^{\circ}\text{C}$

### **21.5.8 Paragraph 15.16 – Cargo contamination**

21.5.8.1 Paragraph 15.16.1 is deleted.

21.5.8.2 Paragraph 15.16.2 is added to *column o* according to the following criterion:

WRI > 1

### **21.5.9 Paragraph 15.17 – Increased ventilation requirements**

21.5.9.1 Paragraph 15.17 shall be added to *column o* according to the following criteria:

Inhalation  $\text{LC}_{50}/\text{ATE} > 0.5 - \leq 2 \text{ mg/L/4h}$  (C3 = 3), unless in accordance with 21.7.12; and/or  
Respiratory sensitizer (D3 = Sr, see also paragraph 21.7.4); and/or  
Toxic to mammals by prolonged exposure (D3 = C, M, R, T, N, or I); and/or  
Highly to severely corrosive to skin ( $\leq 1\text{h}$  exposure time) (D1 = 3B or 3C).

### **21.5.10 Paragraph 15.18 – Special cargo pump-room requirements**

21.5.10.1 Paragraph 15.18 shall be added to *column o* according to the following criterion:  
Inhalation  $\text{LC}_{50}/\text{ATE} \leq 0.5 \text{ mg/L/4h}$  (C3 = 4), unless in accordance with 21.7.12

### **21.5.11 Paragraph 15.19 – Overflow control**

21.5.11.1 Paragraph 15.19 shall be added to *column o* according to the following criteria:

Inhalation  $\text{LC}_{50}/\text{ATE} \leq 2 \text{ mg/L/4h}$  (C3 = 3 or 4), unless in accordance with 21.7.12; and/or  
Dermal  $\text{LD}_{50}/\text{ATE} \leq 1000 \text{ mg/kg}$  (C2 = 2, 3, or 4); and/or  
Oral  $\text{LD}_{50}/\text{ATE} \leq 300 \text{ mg/kg}$  (C1 = 2, 3, or 4); and/or  
Respiratory sensitizer (D3 = Sr, see also paragraph 21.7.4); and/or  
Severely corrosive to skin ( $\leq 3 \text{ min}$  exposure) (D1 = 3C); and/or  
Auto-ignition temperature  $\leq 200^{\circ}\text{C}$ ; and/or  
Explosive range  $\geq 40\% \text{ v/v}$  in air and flashpoint  $< 23^{\circ}\text{C}$ ; and/or  
Classified as Ship Type 1 on pollution grounds.

21.5.11.2 Only paragraph 15.19.6 shall apply if the product has any of the following properties:

Inhalation  $LC_{50}/ATE > 2 \text{ mg/L/4h} - \leq 10 \text{ mg/L/4h}$  ( $C3 = 2$ ), unless in accordance with 21.7.12; and/or  
Dermal  $LD_{50}/ATE > 1000 \text{ mg/kg} - \leq 2000 \text{ mg/kg}$  ( $C2 = 1$ ); and/or  
Oral  $LD_{50}/ATE > 300 \text{ mg/kg} - \leq 2000 \text{ mg/kg}$  ( $C1 = 1$ ); and/or  
Skin sensitizer ( $D3=Ss$ ); and/or  
Highly corrosive to skin ( $> 3 \text{ min} - \leq 1 \text{ h}$  exposure) ( $D1 = 3B$ ); and/or  
Flashpoint  $\leq 60^{\circ}\text{C}$ ; and/or  
Classified as Ship Type 2 on pollution grounds; and/or  
Pollution category X or Y.

### **21.5.12 Paragraph 15.21 –Temperature sensors**

21.5.12.1 Paragraph 15.21 is added to *column o* according to the heat sensitivity of the product. This requirement is related to pumps in cargo pump-rooms only.

### **21.6 Column o – Criteria for special requirements in chapter 16**

#### **21.6.1 Paragraphs 16.1 to 16.2.5 and 16.3 to 16.5**

21.6.1.1 These apply to all cargoes and so are not referenced specifically in *column o*.

#### **21.6.2 Paragraph 16.2.6**

21.6.2.1 Paragraph 16.2.6 is added to *column o* for products which meet the following criteria: Pollution Category X or Y and viscosity  $\geq 50 \text{ mPa}\cdot\text{s}$  at  $20^{\circ}\text{C}$ .

#### **21.6.3 Paragraph 16.2.9**

21.6.3.1 Paragraph 16.2.9 is added to *column o* for products which meet the following criterion: Melting point  $\geq 0^{\circ}\text{C}$ .

#### **21.6.4 Paragraph 16.6 – Cargo not to be exposed to excessive heat**

21.6.4.1 Paragraphs 16.6.2 to 16.6.4 are added to *column o* for products which are identified as requiring temperature control during carriage.

#### **21.6.5 Paragraph 16.2.7 – Persistent floaters**

Paragraph 16.2.7 is added to *column o* for products which meet the following criteria: Pollution Category Y that are persistent floaters ( $E2 = Fp$ ) with a viscosity greater than or equal to  $50 \text{ mPa}\cdot\text{s}$  at  $20^{\circ}\text{C}$  and/or with a melting point greater than or equal to  $0^{\circ}\text{C}$ .

### **21.7 Definitions**

#### **21.7.1 Acute mammalian toxicity**

$LC_{50}$  is the concentration in air,  $LD_{50}$  is the amount (dose) of test substance, which causes mortality to 50% of a test species. ATE refers to a dose (concentration) range or extrapolated dose (concentration) leading to lethal effects in mammals, equivalent to an  $LC_{50}$  or  $LD_{50}$ .

### 21.7.1.1 Acutely toxic if swallowed

Oral toxicity (LD <sub>50</sub> /ATE)		GESAMP Hazard Profile Rating C1
Hazard Level	mg/kg	
High	≤ 5	4
Moderately High	> 5 - ≤ 50	3
Moderate	> 50 - ≤ 300	2
Slight	> 300 - ≤ 2000	1
Negligible	> 2000	0

### 21.7.1.2 Acutely toxic in contact with skin

Dermal toxicity (LD <sub>50</sub> /ATE)		GESAMP Hazard Profile Rating C2
Hazard Level	mg/kg	
High	≤ 50	4
Moderately high	> 50 - ≤ 200	3
Moderate	> 200 - ≤ 1000	2
Slight	> 1000 - ≤ 2000	1
Negligible	> 2000	0

### 21.7.1.3 Acutely toxic by inhalation

All inhalation toxicity data are assumed to be for vapours and not mists or sprays, unless otherwise indicated.

Inhalation toxicity (LC <sub>50</sub> /ATE)		GESAMP Hazard Profile Rating C3
Hazard level	mg/L/4h	
High	≤ 0.5	4
Moderately high	> 0.5 - ≤ 2	3
Moderate	> 2 - ≤ 10	2
Slight	> 10 - ≤ 20	1
Negligible	> 20	0

## 21.7.2 Toxic to mammals by prolonged exposure

21.7.2.1 A product is classified as *toxic to mammals by prolonged exposure* if it meets any of the following criteria: it is known to be, or suspected of being carcinogenic, mutagenic, reprotoxic, neurotoxic, immunotoxic or exposure below the lethal dose is known to cause Specific Target Organ Toxicity.

21.7.2.2 Such effects may be identified from the GESAMP Hazard Profile of the product (D3 = C, M, R, T, N, or I) or other recognized sources of such information.

## 21.7.3 Skin sensitization

21.7.3.1 A product is classified as a *skin sensitizer*:

- .1 if there is evidence in humans that the substance can induce sensitization by skin contact in a substantial number of persons; or
- .2 where there are positive results from an appropriate test.

21.7.3.2 Such effects are identified in the GESAMP Hazard Profile for the product (D3 = Ss).

#### 21.7.4 Respiratory sensitization

21.7.4.1 A product is classified as a *respiratory sensitizer*:

- .1 if there is evidence in humans that the substance can induce specific respiratory hypersensitivity; and/or
- .2 where there are positive results from an appropriate test; and/or
- .3 where the product does not have a GESAMP Hazard Profile and is identified as a skin sensitizer and there is no evidence to show that it is not a respiratory sensitizer.

21.7.4.2 Such effects are identified in the GESAMP Hazard Profile for the product (D3 = Sr) or other recognized sources of such information, if no profile exists.

#### 21.7.5 Corrosive to skin<sup>3</sup>

Hazard Level	Exposure time to cause full thickness necrosis of skin	GESAMP Hazard Profile Rating D1
Severely corrosive to skin	≤ 3 min	3C
Highly corrosive to skin	> 3 min - ≤ 1h	3B
Moderately corrosive to skin	> 1h - ≤ 4h	3A

**Note:** A rating of 3 or (3) in the D1 column of the GESAMP Hazard Profile without any additional letter notation (A, B or C), means that the severity of corrosivity has not been established. For such cases, a rating of 3 or (3) is understood to be equivalent to a rating of 3B for the purpose of assigning carriage requirements.

#### 21.7.6 Water reactive substances

21.7.6.1 These are classified as follows:

Water Reactive Index (WRI)	Definition
3	Any chemical which is extremely reactive with water and produces large quantities of flammable, toxic or corrosive gas or aerosol
2	Any chemical which, in contact with water, may produce a toxic, flammable or corrosive gas or aerosol
1	Any chemical which, in contact with water, may generate heat or produce a non-toxic, non-flammable or non-corrosive gas
0	Any chemical which, in contact with water, would not undergo a reaction to justify a value of 1, 2 or 3

<sup>3</sup> Products that are corrosive to skin are also deemed to be corrosive by inhalation.

### 21.7.7 Air reactive substances

21.7.7.1 Air reactive substances are products that react with air to cause a potentially hazardous situation, e.g. the formation of peroxides that may cause an explosive reaction.

### 21.7.8 Electrical apparatus – Temperature class

(for products which either have a flashpoint of  $\leq 60^{\circ}\text{C}$  or are heated to within  $15^{\circ}\text{C}$  of their flashpoint)

21.7.8.1 The temperature class is defined by the International Electrotechnical Commission (IEC) as:

"The highest temperature attained under practical conditions of operation within the rating of the apparatus (and recognized overloads, if any, associated therewith) by any part of any surface, the exposure of which to an explosive atmosphere may involve a risk."

21.7.8.2 The temperature class of the electrical apparatus is assigned by selecting the Maximum Surface Temperature which is closest to, but less than, the product's auto-ignition temperature (see 21.4.9.1.1).

### 21.7.9 Electrical apparatus – Apparatus group

(for products with a flashpoint of  $\leq 60^{\circ}\text{C}$ )

21.7.9.1 This refers to intrinsically safe and associated electrical apparatus for explosive gas atmospheres which the IEC divide into the following groups:

Group I: for mines susceptible to firedamp (not used by IMO); and

Group II: for applications in other industries – further sub-divided according to its Maximum Experimental Safe Gap (MESG) and/or the Minimum Igniting Current (MIC) of the gas/vapour into groups IIA, IIB and IIC.

21.7.9.2 This property cannot be determined from other data associated with the product; it has to be either measured or assigned by assimilation with related products in a homologous series.

### 21.7.10 Special carriage control conditions

21.7.10.1 Special carriage control conditions refer to specific measures that need to be taken in order to prevent a hazardous reaction. They include:

- .1 *Inhibition*: the addition of a compound (usually organic) that retards or stops an undesired chemical reaction such as corrosion, oxidation or polymerization;
- .2 *Stabilization*: the addition of a substance (stabilizer) that tends to keep a compound, mixture or solution from changing its form or chemical nature. Such stabilizers may retard a reaction rate, preserve a chemical equilibrium, act as antioxidants, keep pigments and other components in emulsion form or prevent the particles in colloidal suspension from precipitating;
- .3 *Inertion*: the addition of a gas (usually nitrogen) in the ullage space of a tank that prevents the formation of a flammable cargo/air mixture;

- .4 *Temperature control*: the maintenance of a specific temperature range for the cargo in order to prevent a hazardous reaction or to keep the viscosity low enough to allow the product to be pumped; and
- .5 *Padding and venting*: only applies to specific products identified on a case by case basis.

### 21.7.11 Flammable cargoes

21.7.11.1 A cargo is defined as flammable according to the following criteria:

IBC Code descriptor	Flashpoint (degrees Centigrade)
Highly flammable	< 23
Flammable	≤ 60 but ≥ 23

21.7.11.2 It should be noted that flashpoints of mixtures and aqueous solutions need to be measured unless all of the components are non-flammable.

21.7.11.3 It should be noted that the carriage of bulk liquid cargoes that have a flashpoint of ≤ 60°C are subject to other SOLAS regulations.

### 21.7.12 Application of the SVC/LC<sub>50</sub> ratio method

21.7.12.1 If the vapour pressure and the molecular weight of a substance are known, an estimate of the maximum vapour concentration in a closed compartment (e.g. a tank) can be calculated. This is called the Saturated Vapour Concentration (SVC).

21.7.12.2 The hazard quotient SVC/LC<sub>50</sub><sup>4</sup> is a substance specific value for the velocity of a vapour for achieving a hazardous concentration when emerging from a liquid source (e.g. leak, spillage or tank ventilation), and can be used in the assignment of specific carriage requirements related to inhalation toxicity.

21.7.12.3 If a solid substance is transported in an aqueous solution, the vapour pressure<sup>5</sup> of this solid rather than that of water may be used in the calculation of the SVC/LC<sub>50</sub> ratio.

#### 21.7.12.4 Application of the SVC/LC<sub>50</sub> ratio for assigning Ship Type and Tank type

21.7.12.4.1 For the assignment of Ship Type and tank type, as set out in paragraphs 21.4.5 and 21.4.6, the application of the SVC/LC<sub>50</sub> ratio method is optional. Should this method be used, the vapour pressure at 20°C shall be used when calculating the SVC/LC<sub>50</sub> ratio.

21.7.12.4.2 The SVC mg/L of a substance should be calculated as follows:

$$SVC(mg / L) = \left( \frac{\text{Vapour pressure @ } 20^{\circ} C (Pa)}{101300 (Pa)} \times 10^6 \right) \times \frac{M_w \left( \frac{g}{mol} \right)}{24(L / mol) \times 1000}$$

---

<sup>4</sup> ATE values can be considered as equivalent to LC<sub>50</sub> values. See paragraph 21.7.1.

<sup>5</sup> If this data is not available, an estimate may be used.

where  $M_w$  is the molecular weight of the substance.

21.7.12.4.3 The SVC/LC<sub>50</sub> ratio should be calculated as follows:

$$SVC/LC_{50} = \frac{SVC(mg/L)}{LC_{50}mg/L/4h}$$

### 21.7.12.5 Application of the SVC/LC<sub>50</sub> ratio for assigning carriage requirements

21.7.12.5.1 For the carriage requirements listed in 21.7.12.5.5, the application of the SVC/LC<sub>50</sub> ratio method is optional. If the SVC/LC<sub>50</sub> ratio method is used in the assignment of these carriage requirements, the vapour pressure at 40°C shall be used when calculating the SVC/LC<sub>50</sub> ratio. If the carriage temperature is higher than 40°C, then the SVC/LC<sub>50</sub> ratio should be calculated at that temperature.

21.7.12.5.2 The SVC (mg/l) of a substance should be calculated as follows:

$$SVC(mg/L) = \left( \frac{\text{Vapour pressure@ } 40^{\circ} C (Pa)}{101300(Pa)} \times 10^6 \right) \times \frac{M_w \left( \frac{g}{mol} \right)}{26 (L/mol) \times 1000}$$

where  $M_w$  is the molecular weight of the substance.

21.7.12.5.3 The SVC/LC<sub>50</sub> ratio should be calculated as follows:

$$SVC/LC_{50} = \frac{SVC(mg/L)}{LC_{50}mg/L/4h}$$

21.7.12.5.4 The SVC (mg/L) formula described in 21.7.12.5.2 is standardized for calculations at 40°C. When using the vapour pressure at higher temperatures in the calculations, the formula must be amended accordingly.

21.7.12.5.5 For the following carriage requirements, the SVC/LC<sub>50</sub> ratio method, calculated at 40°C or higher, may be used as an alternative to the acute inhalation toxicity criteria given in paragraphs 21.4 and 21.5:

#### .1 **Column g – Tank vents**

Assignment of controlled venting is not required based on the inhalation hazard only, if:

Inhalation LC<sub>50</sub>/ATE ≤ 10 mg/L/4h (C3 = 2, 3, or 4) and SVC/LC<sub>50</sub> < 0.2

#### .2 **Column j – Gauging**

Closed gauging is not required based on the inhalation hazard only, if:

Inhalation LC<sub>50</sub>/ATE ≤ 2 mg/L/4h (C3 = 3 or 4) and SVC/LC<sub>50</sub> < 0.2 but restricted gauging is required.

Restricted gauging is not required based on the inhalation hazard only, if:

Inhalation  $LC_{50}/ATE > 2 - \leq 10$  mg/L/4h (C3 = 2) and  $SVC/LC_{50} < 0.2$

.3 **Column k – Vapour detection**

Assignment of toxic vapour detection is not required based on the inhalation hazard only, if:

Inhalation  $LC_{50}/ATE \leq 10$  mg/L/4h (C3 = 2, 3, or 4) and  $SVC/LC_{50} < 0.2$

.4 **Column n – Emergency Equipment**

Inhalation  $LC_{50}/ATE \leq 2$  mg/L/4h (C3 = 3 or 4) and  $SVC/LC_{50} < 0.2$

.5 **Column o – Special requirements in chapter 15**

15.12.1 and 15.12.2 are not required based on the inhalation hazard only, if:

Inhalation  $LC_{50}/ATE \leq 2$  mg/L/4h (C3 = 3 or 4) and  $SVC/LC_{50} < 0.2$

15.12.3 and 15.12.4 are not required based on the inhalation hazard only, if:

Inhalation  $LC_{50}/ATE > 2 - \leq 10$  mg/L/4h (C3 = 2) and  $SVC/LC_{50} < 0.2$

15.17 is not required based on the inhalation hazard only, if:

Inhalation  $LC_{50}/ATE \leq 0.5$  mg/L/4h (C3 = 4) and  $SVC/LC_{50} < 0.2$

15.18 is not required based on the inhalation hazard only if:

Inhalation  $LC_{50}/ATE \leq 0.5$  mg/L/4h (C3 = 4) and  $SVC/LC_{50} < 0.2$

15.19 is not required based on the inhalation hazard only, if:

Inhalation  $LC_{50}/ATE \leq 2$  mg/L/4h (C3 = 3 or 4) and  $SVC/LC_{50} < 0.2$ , but 15.19.6 applies

15.19.6 is not required based on the inhalation hazard only, if:

Inhalation  $LC_{50}/ATE > 2 - \leq 10$  mg/L/4h (C3 = 2) and  $SVC/LC_{50} < 0.2$ "

\*\*\*